# Diagnostic List honda_v9.13

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Vehicle | Area | System | Function | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | | Read Info. | Read DTC | Clear DTC | Data Stream | Actuation Test | Special Function | Remark |
| HONDA | Canada | Engine System | - | √ | √ | √ | √ | √ | |
| HONDA | Canada | Automatic Transmission System | - | √ | √ | √ | √ | √ | |
| HONDA | Canada | Supplemental Inflatable Restraint Syst | √ | √ | √ | √ | √ | √ | |
| HONDA | Canada | Anti-lock Braking System | - | √ | √ | √ | √ | √ | |
| HONDA | Canada | Brake System | - | √ | √ | √ | √ | √ | |
| HONDA | Canada | Driving Support | - | √ | √ | √ | √ | √ | |
| HONDA | Canada | Body Electric System | - | √ | √ | √ | √ | √ | |
| HONDA | Canada | Electric Power Steering | - | √ | √ | √ | √ | - | |
| HONDA | Canada | Tire Pressure Monitor System | - | √ | √ | √ | √ | - | |
| HONDA | Canada | SH-AWD | - | √ | √ | √ | √ | - | |
| HONDA | Canada | SMART-H | - | √ | √ | √ | √ | - | |
| HONDA | Canada | Immobilizer System | - | - | - | √ | - | - | |
| HONDA | Canada | Integrated Motor Assist System | - | √ | √ | √ | - | - | |
| HONDA | Canada | VTM 4 | - | √ | √ | √ | - | - | |
| HONDA | Canada | Adaptive Cruise Control | - | √ | √ | √ | √ | - | |
| HONDA | Canada | Hydraulic Booster | - | √ | √ | √ | √ | - | |
| HONDA | Canada | Electric Vacuum Pump System | - | √ | √ | √ | - | - | |
| HONDA | Canada | Pop-up Engine Cover | - | √ | √ | √ | - | - | |
| HONDA | Canada | Active Shock Absorber System | - | √ | √ | √ | - | - | |
| HONDA | Canada | Active Engine Control Mount | - | √ | √ | √ | √ | - | |
| HONDA | Canada | Active Damper System | - | √ | √ | √ | - | - | |
| HONDA | Canada | Real Time AWD | - | √ | √ | √ | - | √ | |

# Diagnostic List honda_v9.13

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Vehicle | Area | System | Function | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | | Read Info. | Read DTC | Clear DTC | Data Stream | Actuation Test | Special Function | Remark |
| HONDA | Canada | Acoustic Vehicle Alerting System | - | √ | √ | √ | - | - | |
| HONDA | Canada | CAN Gateway | - | √ | √ | - | - | - | |
| HONDA | Canada | Precision All Wheel Steer | - | √ | √ | √ | √ | √ | |
| HONDA | Canada | EDLC | - | √ | √ | √ | √ | - | |
| HONDA | Canada | R/C ENG Starter | - | - | - | √ | - | - | |
| HONDA | Canada | SVT | - | √ | √ | √ | √ | √ | |
| HONDA | Europ | Engine System | - | √ | √ | √ | √ | √ | |
| HONDA | Europ | Automatic Transmission System | - | √ | √ | √ | √ | √ | |
| HONDA | Europ | Supplemental Inflatable Restraint Syst | √ | √ | √ | √ | √ | √ | |
| HONDA | Europ | Anti-lock Braking System | - | √ | √ | √ | √ | √ | |
| HONDA | Europ | Body Electric System | - | √ | √ | √ | √ | √ | |
| HONDA | Europ | Electric Power Steering | - | √ | √ | √ | √ | - | |
| HONDA | Europ | Tire Pressure Monitor System | - | √ | √ | √ | √ | - | |
| HONDA | Europ | SH-AWD | - | √ | √ | √ | √ | - | |
| HONDA | Europ | SMART-H | - | √ | √ | √ | √ | - | |
| HONDA | Europ | Immobilizer System | - | - | - | √ | - | - | |
| HONDA | Europ | Integrated Motor Assist System | - | √ | √ | √ | - | - | |
| HONDA | Europ | VTM 4 | - | √ | √ | √ | - | - | |
| HONDA | Europ | Adaptive Cruise Control | - | √ | √ | √ | √ | - | |
| HONDA | Europ | Hydraulic Booster | - | √ | √ | √ | √ | - | |
| HONDA | Europ | Electric Vacuum Pump System | - | √ | √ | √ | - | - | |
| HONDA | Europ | Pop-up Engine Cover | - | √ | √ | √ | - | - | |

# Diagnostic List honda_v9.13

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Vehicle | Area | System | Function | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | | Read Info. | Read DTC | Clear DTC | Data Stream | Actuation Test | Special Function | Remark |
| HONDA | Europ | Active Shock Absorber System | - | √ | √ | √ | - | - | |
| HONDA | Europ | Brake System | - | √ | √ | √ | √ | √ | |
| HONDA | Europ | Driving Support | - | √ | √ | √ | √ | √ | |
| HONDA | Europ | Active Damper System | - | √ | √ | √ | - | - | |
| HONDA | Europ | Real Time AWD | - | √ | √ | √ | - | √ | |
| HONDA | Europ | Acoustic Vehicle Alerting System | - | √ | √ | √ | - | - | |
| HONDA | Europ | CAN Gateway | - | √ | √ | - | - | - | |
| HONDA | Europ | Precision All Wheel Steer | - | √ | √ | √ | √ | √ | |
| HONDA | Europ | EDLC | - | √ | √ | √ | √ | - | |
| HONDA | Europ | Active Engine Control Mount | - | √ | √ | √ | √ | - | |
| HONDA | Europ | 4ws | - | √ | √ | √ | √ | √ | |
| HONDA | Europ | i-Shift | - | √ | √ | √ | - | - | |
| HONDA | Europ | SVT | - | √ | √ | √ | - | - | |
| HONDA | General | Engine System | - | √ | √ | √ | √ | √ | |
| HONDA | General | Automatic Transmission System | - | √ | √ | √ | √ | √ | |
| HONDA | General | Supplemental Inflatable Restraint Syst | √ | √ | √ | √ | √ | √ | |
| HONDA | General | Anti-lock Braking System | - | √ | √ | √ | √ | √ | |
| HONDA | General | Body Electric System | - | √ | √ | √ | √ | √ | |
| HONDA | General | Electric Power Steering | - | √ | √ | √ | √ | - | |
| HONDA | General | Tire Pressure Monitor System | - | √ | √ | √ | √ | - | |
| HONDA | General | SH-AWD | - | √ | √ | √ | √ | - | |
| HONDA | General | SMART-H | - | √ | √ | √ | √ | - | |

# Diagnostic List honda_v9.13

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Vehicle | Area | System | Function | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | | Read Info. | Read DTC | Clear DTC | Data Stream | Actuation Test | Special Function | Remark |
| HONDA | General | Immobilizer System | - | - | - | √ | - | - | |
| HONDA | General | Integrated Motor Assist System | - | √ | √ | √ | - | - | |
| HONDA | General | VTM 4 | - | √ | √ | √ | - | - | |
| HONDA | General | Adaptive Cruise Control | - | √ | √ | √ | √ | - | |
| HONDA | General | Hydraulic Booster | - | √ | √ | √ | √ | - | |
| HONDA | General | Electric Vacuum Pump System | - | √ | √ | √ | - | - | |
| HONDA | General | Pop-up Engine Cover | - | √ | √ | √ | - | - | |
| HONDA | General | Active Shock Absorber System | - | √ | √ | √ | - | - | |
| HONDA | General | Active Engine Control Mount | - | √ | √ | √ | √ | - | |
| HONDA | General | Brake System | - | √ | √ | √ | √ | √ | |
| HONDA | General | Driving Support | - | √ | √ | √ | √ | √ | |
| HONDA | General | Active Damper System | - | √ | √ | √ | - | - | |
| HONDA | General | Real Time AWD | - | √ | √ | √ | - | √ | |
| HONDA | General | Acoustic Vehicle Alerting System | - | √ | √ | √ | - | - | |
| HONDA | General | CAN Gateway | - | √ | √ | - | - | - | |
| HONDA | General | Precision All Wheel Steer | - | √ | √ | √ | √ | √ | |
| HONDA | General | EDLC | - | √ | √ | √ | √ | - | |
| HONDA | General | Active Engine Control Mount | - | √ | √ | √ | √ | - | |
| HONDA | General | 4ws | - | √ | √ | √ | √ | √ | |
| HONDA | General | R/C ENG Starter | - | - | - | √ | - | - | |
| HONDA | General | SVT | - | √ | √ | √ | - | - | |
| HONDA | Japan | Engine System | - | √ | √ | √ | √ | √ | |

# Diagnostic List honda_v9.13

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Vehicle | Area | System | Function | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | | Read Info. | Read DTC | Clear DTC | Data Stream | Actuation Test | Special Function | Remark |
| HONDA | Japan | Automatic Transmission System | - | √ | √ | √ | √ | √ | |
| HONDA | Japan | Supplemental Inflatable Restraint Syst | √ | √ | √ | √ | √ | √ | |
| HONDA | Japan | Anti-lock Braking System | - | √ | √ | √ | √ | √ | |
| HONDA | Japan | Body Electric System | - | √ | √ | √ | √ | √ | |
| HONDA | Japan | Electric Power Steering | - | √ | √ | √ | √ | - | |
| HONDA | Japan | Tire Pressure Monitor System | - | √ | √ | √ | √ | - | |
| HONDA | Japan | SH-AWD | - | √ | √ | √ | √ | - | |
| HONDA | Japan | SMART-H | - | √ | √ | √ | √ | - | |
| HONDA | Japan | Immobilizer System | - | - | - | √ | - | - | |
| HONDA | Japan | Integrated Motor Assist System | - | √ | √ | √ | - | - | |
| HONDA | Japan | VTM 4 | - | √ | √ | √ | - | - | |
| HONDA | Japan | Adaptive Cruise Control | - | √ | √ | √ | √ | - | |
| HONDA | Japan | Hydraulic Booster | - | √ | √ | √ | √ | - | |
| HONDA | Japan | Electric Vacuum Pump System | - | √ | √ | √ | - | - | |
| HONDA | Japan | Pop-up Engine Cover | - | √ | √ | √ | - | - | |
| HONDA | Japan | Active Shock Absorber System | - | √ | √ | √ | - | - | |
| HONDA | Japan | Active Engine Control Mount | - | √ | √ | √ | √ | - | |
| HONDA | Japan | Brake System | - | √ | √ | √ | √ | √ | |
| HONDA | Japan | Driving Support | - | √ | √ | √ | √ | √ | |
| HONDA | Japan | Active Damper System | - | √ | √ | √ | - | - | |
| HONDA | Japan | Real Time AWD | - | √ | √ | √ | - | √ | |
| HONDA | Japan | Acoustic Vehicle Alerting System | - | √ | √ | √ | - | - | |

# Diagnostic List honda_v9.13

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Vehicle | Area | System | Function | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | | Read Info. | Read DTC | Clear DTC | Data Stream | Actuation Test | Special Function | Remark |
| HONDA | Japan | CAN Gateway | - | √ | √ | - | - | - | |
| HONDA | Japan | Precision All Wheel Steer | - | √ | √ | √ | √ | √ | |
| HONDA | Japan | EDLC | - | √ | √ | √ | √ | - | |
| HONDA | Japan | Active Engine Control Mount | - | √ | √ | √ | √ | - | |
| HONDA | Japan | 4ws | - | √ | √ | √ | √ | √ | |
| HONDA | Japan | R/C ENG Starter | - | - | - | √ | - | - | |
| HONDA | Japan | SVT | - | √ | √ | √ | - | - | |
| HONDA | Latin America | Engine System | - | √ | √ | √ | √ | √ | |
| HONDA | Latin America | Automatic Transmission System | - | √ | √ | √ | √ | √ | |
| HONDA | Latin America | Supplemental Inflatable Restraint Syst | √ | √ | √ | √ | √ | √ | |
| HONDA | Latin America | Anti-lock Braking System | - | √ | √ | √ | √ | √ | |
| HONDA | Latin America | Body Electric System | - | √ | √ | √ | √ | √ | |
| HONDA | Latin America | Electric Power Steering | - | √ | √ | √ | √ | - | |
| HONDA | Latin America | Tire Pressure Monitor System | - | √ | √ | √ | √ | - | |
| HONDA | Latin America | SH-AWD | - | √ | √ | √ | √ | - | |
| HONDA | Latin America | SMART-H | - | √ | √ | √ | √ | - | |
| HONDA | Latin America | Immobilizer System | - | - | - | √ | - | - | |
| HONDA | Latin America | Integrated Motor Assist System | - | √ | √ | √ | - | - | |
| HONDA | Latin America | VTM 4 | - | √ | √ | √ | - | - | |
| HONDA | Latin America | Adaptive Cruise Control | - | √ | √ | √ | √ | - | |
| HONDA | Latin America | Hydraulic Booster | - | √ | √ | √ | √ | - | |
| HONDA | Latin America | Electric Vacuum Pump System | - | √ | √ | √ | - | - | |

# Diagnostic List honda_v9.13

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Vehicle | Area | System | Function | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | | Read Info. | Read DTC | Clear DTC | Data Stream | Actuation Test | Special Function | Remark |
| HONDA | Latin America | Pop-up Engine Cover | - | √ | √ | √ | - | - | |
| HONDA | Latin America | Active Shock Absorber System | - | √ | √ | √ | - | - | |
| HONDA | Latin America | Active Engine Control Mount | - | √ | √ | √ | √ | - | |
| HONDA | Latin America | Brake System | - | √ | √ | √ | √ | √ | |
| HONDA | Latin America | Driving Support | - | √ | √ | √ | √ | √ | |
| HONDA | Latin America | Active Damper System | - | √ | √ | √ | - | - | |
| HONDA | Latin America | Real Time AWD | - | √ | √ | √ | - | √ | |
| HONDA | Latin America | Acoustic Vehicle Alerting System | - | √ | √ | √ | - | - | |
| HONDA | Latin America | CAN Gateway | - | √ | √ | - | - | - | |
| HONDA | Latin America | Precision All Wheel Steer | - | √ | √ | √ | √ | √ | |
| HONDA | Latin America | EDLC | - | √ | √ | √ | √ | - | |
| HONDA | Latin America | Active Engine Control Mount | - | √ | √ | √ | √ | - | |
| HONDA | Latin America | R/C ENG Starter | - | - | - | √ | - | - | |
| HONDA | Latin America | SVT | - | √ | √ | √ | - | - | |
| HONDA | United States | Engine System | - | √ | √ | √ | √ | √ | |
| HONDA | United States | Automatic Transmission System | - | √ | √ | √ | √ | √ | |
| HONDA | United States | Supplemental Inflatable Restraint Sys | √ | √ | √ | √ | √ | √ | |
| HONDA | United States | Anti-lock Braking System | - | √ | √ | √ | √ | √ | |
| HONDA | United States | Body Electric System | - | √ | √ | √ | √ | √ | |
| HONDA | United States | Electric Power Steering | - | √ | √ | √ | √ | - | |
| HONDA | United States | Tire Pressure Monitor System | - | √ | √ | √ | √ | - | |
| HONDA | United States | SH-AWD | - | √ | √ | √ | √ | - | |

# Diagnostic List honda_v9.13

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Vehicle | Area | System | Function | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | | Read Info. | Read DTC | Clear DTC | Data Stream | Actuation Test | Special Function | Remark |
| HONDA | United States | SMART-H | - | √ | √ | √ | √ | - | |
| HONDA | United States | Immobilizer System | - | - | - | √ | - | - | |
| HONDA | United States | Integrated Motor Assist System | - | √ | √ | √ | - | - | |
| HONDA | United States | VTM 4 | - | √ | √ | √ | - | - | |
| HONDA | United States | Adaptive Cruise Control | - | √ | √ | √ | √ | - | |
| HONDA | United States | Hydraulic Booster | - | √ | √ | √ | √ | - | |
| HONDA | United States | Electric Vacuum Pump System | - | √ | √ | √ | - | - | |
| HONDA | United States | Pop-up Engine Cover | - | √ | √ | √ | - | - | |
| HONDA | United States | Active Shock Absorber System | - | √ | √ | √ | - | - | |
| HONDA | United States | Active Engine Control Mount | - | √ | √ | √ | √ | - | |
| HONDA | United States | Brake System | - | √ | √ | √ | √ | √ | |
| HONDA | United States | Driving Support | - | √ | √ | √ | √ | √ | |
| HONDA | United States | Active Damper System | - | √ | √ | √ | - | - | |
| HONDA | United States | Real Time AWD | - | √ | √ | √ | - | √ | |
| HONDA | United States | Acoustic Vehicle Alerting System | - | √ | √ | √ | - | - | |
| HONDA | United States | CAN Gateway | - | √ | √ | - | - | - | |
| HONDA | United States | Precision All Wheel Steer | - | √ | √ | √ | √ | √ | |
| HONDA | United States | EDLC | - | √ | √ | √ | √ | - | |
| HONDA | United States | Active Engine Control Mount | - | √ | √ | √ | √ | - | |
| HONDA | United States | R/C ENG Starter | - | - | - | √ | - | - | |
| HONDA | United States | SVT | - | √ | √ | √ | - | - | |