PEUGEOT_V9.60 Model function table

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
106R		engines	Petrol	CDY BOSCH MA3.1		Read ECU Information		Y		
106R		engines	Petrol	CDY BOSCH MA3.1		Read Fault Code		Y		
106R		engines	Petrol	CDY BOSCH MA3.1		Erase Fault Code		Y		
106R		engines	Petrol	CDY BOSCH MA3.1		Live Data		Y		
106R		engines	Petrol	CDZ BOSCH MA3.1		Read ECU Information		Y		
106R		engines	Petrol	CDZ BOSCH MA3.1		Read Fault Code		Y		
106R		engines	Petrol	CDZ BOSCH MA3.1		Erase Fault Code		Y		
106R		engines	Petrol	CDZ BOSCH MA3.1		Live Data		Y		
106R		engines	Petrol	HDY BOSCH MA3.1		Read ECU Information		Y		
106R		engines	Petrol	HDY BOSCH MA3.1		Read Fault Code		Y		
106R		engines	Petrol	HDY BOSCH MA3.1		Erase Fault Code		Y		
106R		engines	Petrol	HDY BOSCH MA3.1		Live Data		Y		
106R		engines	Petrol	HDZ BOSCH MA3.1		Read ECU Information		Y		
106R		engines	Petrol	HDZ BOSCH MA3.1		Read Fault Code		Y		
106R		engines	Petrol	HDZ BOSCH MA3.1		Erase Fault Code		Y		
106R		engines	Petrol	HDZ BOSCH MA3.1		Live Data		Y		
106R		engines	Petrol	HFX BOSCH M7.4.4		Read ECU Information		Y		
106R		engines	Petrol	HFX BOSCH M7.4.4		Read Fault Code		Y		
106R		engines	Petrol	HFX BOSCH M7.4.4		Erase Fault Code		Y		
106R		engines	Petrol	HFX BOSCH M7.4.4		Live Data		Y		
106R		engines	Petrol	HFX BOSCH M7.4.4		Special Function	Initialising the autoadaptives	Y		
106R		engines	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
106R		engines	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
106R		engines	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
106R		engines	Petrol	KFW SAGEM S2000		Live Data		Y		
106R		engines	Petrol	KFW SAGEM S2000		Actuation Test		Y		
106R		engines	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
106R		engines	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
106R		engines	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
106R		engines	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
106R		engines	Petrol	KFW SAGEM S2000		Live Data		Y		
106R		engines	Petrol	KFW SAGEM S2000		Actuation Test		Y		
106R		engines	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
106R		engines	Petrol	KFX BOSCH MP7.3		Read ECU Information		Y		
106R		engines	Petrol	KFX BOSCH MP7.3		Read Fault Code		Y		
106R		engines	Petrol	KFX BOSCH MP7.3		Erase Fault Code		Y		
106R		engines	Petrol	KFX BOSCH MP7.3		Live Data		Y		
106R		engines	Petrol	KFX BOSCH MP7.3		Actuation Test		Y		
106R		engines	Petrol	KFX BOSCH MP7.3		Special Function	Injection ECU initialisation	Y		
106R		engines	Petrol	KFX MM1AP		Read ECU Information		Y		
106R		engines	Petrol	KFX MM1AP		Read Fault Code		Y		
106R		engines	Petrol	KFX MM1AP		Erase Fault Code		Y		
106R		engines	Petrol	KFX MM1AP		Live Data		Y		
106R		engines	Petrol	KFX MM1AP		Actuation Test		Y		
106R		engines	Petrol	KFX MM1AP		Special Function	Ignition advance setting	Y		
106R		engines	Petrol	KFX MM1AP		Special Function	Injection ECU initialisation	Y		
106R		engines	Petrol	NFX MM1AP		Read ECU Information		Y		
106R		engines	Petrol	NFX MM1AP		Read Fault Code		Y		
106R		engines	Petrol	NFX MM1AP		Erase Fault Code		Y		
106R		engines	Petrol	NFX MM1AP		Live Data		Y		
106R		engines	Petrol	NFX MM1AP		Actuation Test		Y		
106R		engines	Petrol	NFX MM1AP		Special Function	Ignition advance setting	Y		
106R		engines	Petrol	NFX MM1AP		Special Function	Injection ECU initialisation	Y		
106R		engines	Petrol	NFX MM48P		Read ECU Information		Y		
106R		engines	Petrol	NFX MM48P		Read Fault Code		Y		
106R		engines	Petrol	NFX MM48P		Erase Fault Code		Y		
106R		engines	Petrol	NFX MM48P		Live Data		Y		
106R		engines	Petrol	NFX MM48P		Actuation Test		Y		
106R		engines	Petrol	NFX MM48P		Special Function	Injection ECU initialisation	Y		
106R		engines	Petrol	NFX MM48P		Special Function	Initialising the autoadaptives	Y		
106R		engines	Petrol	NFZ BOSCH MP5.2		Read Fault Code		Y		

106R		engines	Petrol	NFZ BOSCH MP5.2		Erase Fault Code		Y		
106R		engines	Petrol	NFZ BOSCH MP5.2		Live Data		Y		
106R		engines	Diesel	VJU BOSCH VP20		Read ECU Information		Y		
106R		engines	Diesel	VJU BOSCH VP20		Read Fault Code		Y		
106R		engines	Diesel	VJU BOSCH VP20		Erase Fault Code		Y		
106R		engines	Diesel	VJU BOSCH VP20		Live Data		Y		
106R		engines	Diesel	VJX BOSCH VP20		Read ECU Information		Y		
106R		engines	Diesel	VJX BOSCH VP20		Read Fault Code		Y		
106R		engines	Diesel	VJX BOSCH VP20		Erase Fault Code		Y		
106R		engines	Diesel	VJX BOSCH VP20		Live Data		Y		
106R		Air bag and seat belt				Read ECU Information		Y		
106R		Air bag and seat belt				Read Fault Code		Y		
106R		Air bag and seat belt				Erase Fault Code		Y		
106R		Active safety	Anti-lock brakes TEVES			Read ECU Information		Y		
106R		Active safety	Anti-lock brakes TEVES			Read Fault Code		Y		
106R		Active safety	Anti-lock brakes TEVES			Erase Fault Code		Y		
106R		Active safety	Anti-lock brakes TEVES			Live Data		Y		
106R		Active safety	Anti-lock brakes TEVES			Special Function	Bleeding	Y		
106R		Active safety	Anti-lock brakes TEVES			Read ECU Information		Y		
106R		Active safety	Anti-lock brakes TEVES			Read Fault Code		Y		
106R		Active safety	Anti-lock brakes TEVES			Erase Fault Code		Y		
106R		Active safety	Anti-lock brakes TEVES			Live Data		Y		
106R		Active safety	Anti-lock brakes TEVES			Special Function	Bleeding	Y		
107		Engine ECU	petrol	CFA BOSCH ME7.9.5		Read Fault Code		Y		
107		Engine ECU	petrol	CFA BOSCH ME7.9.5		Erase Fault Code		Y		
107		Engine ECU	Diesel	8HT SIEMENS SID805		Read ECU Information		Y		
107		Engine ECU	Diesel	8HT SIEMENS SID805		Read Fault Code		Y		
107		Engine ECU	Diesel	8HT SIEMENS SID805		Erase Fault Code		Y		
107		Engine ECU	Diesel	8HT SIEMENS SID805		Live Data		Y		
107		Engine ECU	Diesel	8HT SIEMENS SID805		Actuation Test		Y		
107		Gearbox ECU				Read Fault Code		Y		
107		Gearbox ECU				Erase Fault Code		Y		
107		Gearbox ECU				Live Data		Y		
107		ABS or ESP ECU	ABS BOSCH 8.0 C1.			Read Fault Code		Y		
107		ABS or ESP ECU	ABS BOSCH 8.0 C1.			Erase Fault Code		Y		
107		ABS or ESP ECU	ABS BOSCH 8.0 C1.			Live Data		Y		
107		ABS or ESP ECU	ESP BOSCH 8.0 C1.			Read Fault Code		Y		
107		ABS or ESP ECU	ESP BOSCH 8.0 C1.			Erase Fault Code		Y		
107		ABS or ESP ECU	ESP BOSCH 8.0 C1.			Live Data		Y		
107		Airbag ECU				Read ECU Information		Y		
107		Airbag ECU				Read Fault Code		Y		
107		Airbag ECU				Erase Fault Code		Y		
107		Airbag ECU				Live Data		Y		
107		Power steering				Read ECU Information		Y		
107		Power steering				Read Fault Code		Y		
107		Power steering				Erase Fault Code		Y		
107		Power steering				Live Data		Y		
107		Coded anti-start				Read Fault Code		Y		
107		Coded anti-start				Erase Fault Code		Y		
107		Coded anti-start				Live Data		Y		
107		Radio				Read ECU Information		Y		
107		Radio				Read Fault Code		Y		
107		Radio				Erase Fault Code		Y		
107		Radio				Live Data		Y		
206	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
206	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
206	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
206	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Live Data		Y		
206	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read ECU Information		Y		

206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Special Function	Ignition advance setting	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Special Function	Injection ECU initialisation procedure	Y		

206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Special Function	Ignition advance setting	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Special Function	Ignition advance setting	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Read ECU Information		Y		

206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Special Function	Ignition advance setting	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Live Data		Y		

206	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Read ECU Information		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Read Fault Code		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Erase Fault Code		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Live Data		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Actuation Test		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Special Function	Bleeding	Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Read ECU Information		Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Read Fault Code		Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Erase Fault Code		Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Live Data		Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Actuation Test		Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Special Function	Configuration	Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Special Function	Bleeding	Y		
206	Production date before 13 September 2001	Airbags	Air bag and seat belt			Read ECU Information		Y		
206	Production date before 13 September 2001	Airbags	Air bag and seat belt			Read Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Air bag and seat belt			Erase Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(right side)			Read ECU Information		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(right side)			Read Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(right side)			Erase Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(right side)			Actuation Test		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(left side)			Read ECU Information		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(left side)			Read Fault Code		Y		

206	Production date before 13 September 2001	Airbags	Side airbag(left side)			Erase Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(left side)			Actuation Test		Y		
206	Production date before 13 September 2001	Programming of the built-in systems interface (Engine immobiliser code and keys)				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
206	Production date before 13 September 2001	Multifunction display				Read ECU Information		Y		
206	Production date before 13 September 2001	Multifunction display				Read Fault Code		Y		
206	Production date before 13 September 2001	Multifunction display				Erase Fault Code		Y		
206	Production date before 13 September 2001	Multifunction display				Actuation Test		Y		
206	Production date before 13 September 2001	On-board navigation system				Read ECU Information		Y		
206	Production date before 13 September 2001	On-board navigation system				Read Fault Code		Y		
206	Production date before 13 September 2001	On-board navigation system				Erase Fault Code		Y		
206	Production date before 13 September 2001	On-board navigation system				Live Data		Y		
206	Production date before 13 September 2001	Service module				Read ECU Information		Y		
206	Production date before 13 September 2001	Service module				Read Fault Code		Y		
206	Production date before 13 September 2001	Service module				Erase Fault Code		Y		
206	Production date before 13 September 2001	Service module				Live Data		Y		
206	Production date before 13 September 2001	Service module				Actuation Test		Y		
206	Production date before 13 September 2001	Electric retractable roof				Read ECU Information		Y		
206	Production date before 13 September 2001	Electric retractable roof				Read Fault Code		Y		
206	Production date before 13 September 2001	Electric retractable roof				Erase Fault Code		Y		
206	Production date before 13 September 2001	Electric retractable roof				Live Data		Y		
206	Production date before 13 September 2001	Electric retractable roof				Actuation Test		Y		
206	Production date before 13 September 2001	Heating/ventilation				Read ECU Information		Y		
206	Production date before 13 September 2001	Heating/ventilation				Read Fault Code		Y		
206	Production date before 13 September 2001	Heating/ventilation				Erase Fault Code		Y		
206	Production date before 13 September 2001	Heating/ventilation				Live Data		Y		
206	Production date before 13 September 2001	Heating/ventilation				Actuation Test		Y		
206	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
206	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
206	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
206	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Live Data		Y		
206	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read ECU Information		Y		

206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Special Function	Programming / Pairing	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Live Data		Y		

206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Special Function	Programming / Pairing	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Special Function	Initialising the autoadaptives	Y		

206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Special Function	Programming / Pairing	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Special Function	Re-centring of autoadaptive systems	Y		

206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Erase Fault Code		Y		

206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Special Function	Programming / Pairing	Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EUR03		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EUR03		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EUR03		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EUR03		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EUR03		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EUR04		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EUR04		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EUR04		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EUR04		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EUR04		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EUR04		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EUR04		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EUR04		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EUR04		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EUR04		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Special Function	After sales operation(Particle emission filter and fuel additive adding)	Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Read Fault Code		Y		

206	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Actuation Test		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA AL4 AT8			Read ECU Information		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA AL4 AT8			Read Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA AL4 AT8			Erase Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA AL4 AT8			Live Data		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA AL4 AT8			Actuation Test		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 1			Read ECU Information		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 1			Read Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 1			Erase Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 1			Live Data		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 1			Actuation Test		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 2			Read ECU Information		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 2			Read Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 2			Erase Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 2			Live Data		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 2			Actuation Test		Y		

206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Read ECU Information		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Read Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Erase Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Live Data		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Actuation Test		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Special Function	Accelerator pedal learing	Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Special Function	Oil wear counter	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Read ECU Information		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Read Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Erase Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Live Data		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Actuation Test		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Special Function	Bleeding	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Read ECU Information		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Read Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Erase Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Live Data		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Actuation Test		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Special Function	Configuration	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Special Function	Bleeding	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Read ECU Information		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Read Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Erase Fault Code		Y		

206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Live Data		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Actuation Test		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	Steering wheel angle sensor calibration	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	De-calibration of the steering wheel angle sensor	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	Bleeding	Y		
206	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Read ECU Information		Y		
206	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Read Fault Code		Y		
206	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Erase Fault Code		Y		
206	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Special Function	Locking	Y		
206	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Special Function	Unlocking	Y		
206	Production date after 13 September 2001	Programming of the built-in systems interface (Engine immobiliser code and keys)				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
206	Production date after 13 September 2001	Anti-theft alarm				Read ECU Information		Y		
206	Production date after 13 September 2001	Anti-theft alarm				Read Fault Code		Y		
206	Production date after 13 September 2001	Anti-theft alarm				Erase Fault Code		Y		
206	Production date after 13 September 2001	Anti-theft alarm				Live Data		Y		
206	Production date after 13 September 2001	Anti-theft alarm				Actuation Test		Y		
206	Production date after 13 September 2001	Display / Telematics	AMF			Read ECU Information		Y		
206	Production date after 13 September 2001	Display / Telematics	AMF			Read Fault Code		Y		
206	Production date after 13 September 2001	Display / Telematics	AMF			Erase Fault Code		Y		
206	Production date after 13 September 2001	Display / Telematics	AMF			Live Data		Y		
206	Production date after 13 September 2001	Display / Telematics	AMF			Actuation Test		Y		
206	Production date after 13 September 2001	Display / Telematics	RT3			Read ECU Information		Y		
206	Production date after 13 September 2001	Display / Telematics	RT3			Read Fault Code		Y		
206	Production date after 13 September 2001	Display / Telematics	RT3			Erase Fault Code		Y		
206	Production date after 13 September 2001	Display / Telematics	RT3			Live Data		Y		
206	Production date after 13 September 2001	Display / Telematics	RT3			Actuation Test		Y		
206	Production date after 13 September 2001	Radio	Radio			Special Function	Vehicle radio feed	Y		
206	Production date after 13 September 2001	Radio	RDE filament			Read ECU Information		Y		
206	Production date after 13 September 2001	Radio	RDE filament			Read Fault Code		Y		
206	Production date after 13 September 2001	Radio	RDE filament			Erase Fault Code		Y		

206	Production date after 13 September 2001	Radio	RDE filament			Live Data		Y		
206	Production date after 13 September 2001	Radio	RDE filament			Actuation Test		Y		
206	Production date after 13 September 2001	CD player				Read ECU Information		Y		
206	Production date after 13 September 2001	CD player				Read Fault Code		Y		
206	Production date after 13 September 2001	CD player				Erase Fault Code		Y		
206	Production date after 13 September 2001	CD player				Live Data		Y		
206	Production date after 13 September 2001	CD player				Actuation Test		Y		
206	Production date after 13 September 2001	Instrument panel				Read ECU Information		Y		
206	Production date after 13 September 2001	Instrument panel				Read Fault Code		Y		
206	Production date after 13 September 2001	Instrument panel				Erase Fault Code		Y		
206	Production date after 13 September 2001	Instrument panel				Live Data		Y		
206	Production date after 13 September 2001	Instrument panel				Actuation Test		Y		
206	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Read ECU Information		Y		
206	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Read Fault Code		Y		
206	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Erase Fault Code		Y		
206	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Live Data		Y		
206	Production date after 13 September 2001	On-board navigation system				Read ECU Information		Y		
206	Production date after 13 September 2001	On-board navigation system				Read Fault Code		Y		
206	Production date after 13 September 2001	On-board navigation system				Erase Fault Code		Y		
206	Production date after 13 September 2001	On-board navigation system				Live Data		Y		
206	Production date after 13 September 2001	Driving school				Read ECU Information		Y		
206	Production date after 13 September 2001	Driving school				Live Data		Y		
206	Production date after 13 September 2001	Driving school				Actuation Test		Y		
206	Production date after 13 September 2001	Rain and brightness sensor				Read ECU Information		Y		
206	Production date after 13 September 2001	Rain and brightness sensor				Read Fault Code		Y		
206	Production date after 13 September 2001	Rain and brightness sensor				Erase Fault Code		Y		
206	Production date after 13 September 2001	Electric retractable roof				Read ECU Information		Y		
206	Production date after 13 September 2001	Electric retractable roof				Read Fault Code		Y		
206	Production date after 13 September 2001	Electric retractable roof				Erase Fault Code		Y		
206	Production date after 13 September 2001	Electric retractable roof				Live Data		Y		
206	Production date after 13 September 2001	Electric retractable roof				Actuation Test		Y		
206	Production date after 13 September 2001	heating/ventilation				Read ECU Information		Y		
206	Production date after 13 September 2001	heating/ventilation				Read Fault Code		Y		

206	Production date after 13 September 2001	heating/ventilation				Erase Fault Code		Y		
206	Production date after 13 September 2001	heating/ventilation				Live Data		Y		
206	Production date after 13 September 2001	heating/ventilation				Actuation Test		Y		
206	Production date after 13 September 2001	Diesel fuel additive control unit				Read ECU Information		Y		
206	Production date after 13 September 2001	Diesel fuel additive control unit				Read Fault Code		Y		
206	Production date after 13 September 2001	Diesel fuel additive control unit				Erase Fault Code		Y		
206	Production date after 13 September 2001	Diesel fuel additive control unit				Live Data		Y		
206	Production date after 13 September 2001	Diesel fuel additive control unit				Actuation Test		Y		
206	Production date after 13 September 2001	Electric pump unit(power steering)				Read ECU Information		Y		
206	Production date after 13 September 2001	Electric pump unit(power steering)				Read Fault Code		Y		
206	Production date after 13 September 2001	Electric pump unit(power steering)				Erase Fault Code		Y		
206	Production date after 13 September 2001	Electric pump unit(power steering)				Live Data		Y		
206 MUX	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Live Data		Y		
206 MUX	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Erase Fault Code		Y		

206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Special Function	Ignition advance setting	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Special Function	Ignition advance setting	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Special Function	Ignition advance setting	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read ECU Information		Y		

206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Special Function	Ignition advance setting	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Erase Fault Code		Y		

206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Live Data		Y		

206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Special Function	Bleeding	Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Live Data		Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Special Function	Configuration	Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Special Function	Bleeding	Y		
206 MUX	Production date before 13 September 2001	Airbags	Air bag and seat belt			Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Airbags	Air bag and seat belt			Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Air bag and seat belt			Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(right side)			Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(right side)			Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(right side)			Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(right side)			Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(left side)			Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(left side)			Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(left side)			Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(left side)			Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Programming of the built-in systems interface (Engine immobiliser code and keys)				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
206 MUX	Production date before 13 September 2001	Multifunction display				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Multifunction display				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Multifunction display				Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Multifunction display				Actuation Test		Y		
206 MUX	Production date before 13 September 2001	On-board navigation system				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	On-board navigation system				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	On-board navigation system				Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	On-board navigation system				Live Data		Y		
206 MUX	Production date before 13 September 2001	Service module				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Service module				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Service module				Erase Fault Code		Y		

206 MUX	Production date before 13 September 2001	Service module				Live Data		Y		
206 MUX	Production date before 13 September 2001	Service module				Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Electric retractable roof				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Electric retractable roof				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Electric retractable roof				Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Electric retractable roof				Live Data		Y		
206 MUX	Production date before 13 September 2001	Electric retractable roof				Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Heating/ventilation				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Heating/ventilation				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Heating/ventilation				Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Heating/ventilation				Live Data		Y		
206 MUX	Production date before 13 September 2001	Heating/ventilation				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Live Data		Y		
206 MUX	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Special Function	Programming / Pairing	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Live Data		Y		

206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		

206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Special Function	Programming / Pairing	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Special Function	Programming / Pairing	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Initialising the autoadaptives	Y		

206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Erase Fault Code		Y		

206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Special Function	Programming / Pairing	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EUR03		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EUR03		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EUR03		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EUR03		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EUR03		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EUR04		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EUR04		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EUR04		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EUR04		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EUR04		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EUR04		Read ECU Information		Y		

206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Special Function	After sales operation(Particle emission filter and fuel additive adding)	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Read Fault Code		Y		

206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA AL4 AT8			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA AL4 AT8			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA AL4 AT8			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA AL4 AT8			Live Data		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA AL4 AT8			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 1			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 1			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 1			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 1			Live Data		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 1			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 2			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 2			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 2			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 2			Live Data		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 2			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Live Data		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Special Function	Accelerator pedal learing	Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4 3			Special Function	Oil wear counter	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Live Data		Y		

206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Special Function	Bleeding	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Live Data		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Special Function	Configuration	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Special Function	Bleeding	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Live Data		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	Steering wheel angle sensor calibration	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	De-calibration of the steering wheel angle sensor	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	Bleeding	Y		
206 MUX	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Special Function	Locking	Y		
206 MUX	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Special Function	Unlocking	Y		
206 MUX	Production date after 13 September 2001	Programming of the built-in systems interface (Engine immobiliser code and keys)				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
206 MUX	Production date after 13 September 2001	Anti-theft alarm				Read ECU Information		Y		

206 MUX	Production date after 13 September 2001	Anti-theft alarm				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-theft alarm				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-theft alarm				Live Data		Y		
206 MUX	Production date after 13 September 2001	Anti-theft alarm				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	AMF			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	AMF			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	AMF			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	AMF			Live Data		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	AMF			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	RT3			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	RT3			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	RT3			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	RT3			Live Data		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	RT3			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Radio	Radio			Special Function	Vehicle radio feed	Y		
206 MUX	Production date after 13 September 2001	Radio	RDE filament			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Radio	RDE filament			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Radio	RDE filament			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Radio	RDE filament			Live Data		Y		
206 MUX	Production date after 13 September 2001	Radio	RDE filament			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	CD player				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	CD player				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	CD player				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	CD player				Live Data		Y		
206 MUX	Production date after 13 September 2001	CD player				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Instrument panel				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Instrument panel				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Instrument panel				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Instrument panel				Live Data		Y		
206 MUX	Production date after 13 September 2001	Instrument panel				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Erase Fault Code		Y		

206 MUX	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Live Data		Y		
206 MUX	Production date after 13 September 2001	On-board navigation system				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	On-board navigation system				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	On-board navigation system				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	On-board navigation system				Live Data		Y		
206 MUX	Production date after 13 September 2001	Driving school				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Driving school				Live Data		Y		
206 MUX	Production date after 13 September 2001	Driving school				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Rain and brightness sensor				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Rain and brightness sensor				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Rain and brightness sensor				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Electric retractable roof				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Electric retractable roof				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Electric retractable roof				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Electric retractable roof				Live Data		Y		
206 MUX	Production date after 13 September 2001	Electric retractable roof				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	heating/ventilation				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	heating/ventilation				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	heating/ventilation				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	heating/ventilation				Live Data		Y		
206 MUX	Production date after 13 September 2001	heating/ventilation				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Diesel fuel additive control unit				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Diesel fuel additive control unit				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Diesel fuel additive control unit				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Diesel fuel additive control unit				Live Data		Y		
206 MUX	Production date after 13 September 2001	Diesel fuel additive control unit				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Electric pump unit(power steering)				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Electric pump unit(power steering)				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Electric pump unit(power steering)				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Electric pump unit(power steering)				Live Data		Y		
206 +		BSI(Built-in Systems				Read ECU Information		Y		
206 +		BSI(Built-in Systems				Read Fault Code		Y		
206 +		BSI(Built-in Systems				Erase Fault Code		Y		
206 +		BSI(Built-in Systems				Live Data		Y		
206 +		BSI(Built-in Systems				Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	ME745		Read ECU Information		Y		

206 +		Engine management ECU	Petrol engine	ME745		Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	ME745		Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	ME745		Live Data		Y		
206 +		Engine management ECU	Petrol engine	ME745		Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	ME745		Special Function	Initialising the autoadaptives	Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Read ECU Information		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Live Data		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Read ECU Information		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Live Data		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Read ECU Information		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Live Data		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Read ECU Information		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Live Data		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Live Data		Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Live Data		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Live Data		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Live Data		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Special Function	Pairing	Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Live Data		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Special Function	Pairing	Y		
206 +		Engine management ECU	Diesel engine	EDC17C10_BR2	8HR-DV4CTED-70 CV	Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	EDC17C10_BR2	8HR-DV4CTED-70 CV	Read Fault Code		Y		

206 +		Engine management ECU	Diesel engine	EDC17C10 BR2	8HR-DV4CTED-70 CV	Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC17C10 BR2	8HR-DV4CTED-70 CV	Live Data		Y		
206 +		Engine management ECU	Diesel engine	EDC17C10 BR2	8HR-DV4CTED-70 CV	Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	EDC17C10 BR2	8HR-DV4CTED-70 CV	Special Function	Configuration	Y		
206 +		Engine management ECU	Diesel engine	EDC17C10 BR2	8HR-DV4CTED-70 CV	Special Function	Pack Repair	Y		
206 +		gearbox				Read ECU Information		Y		
206 +		gearbox				Live Data		Y		
206 +		gearbox				Actuation Test		Y		
206 +		gearbox				Special Function	Configuration	Y		
206 +		gearbox				Special Function	Pack Repair	Y		
206 +		ABS/traction control	ABS MK70			Read ECU Information		Y		
206 +		ABS/traction control	ABS MK70			Read Fault Code		Y		
206 +		ABS/traction control	ABS MK70			Erase Fault Code		Y		
206 +		ABS/traction control	ABS MK70			Live Data		Y		
206 +		ABS/traction control	ABS MK70			Actuation Test		Y		
206 +		ABS/traction control	ABS MK70			Special Function	Replacement parts	Y		
206 +		ABS/traction control	ESP MK60			Read ECU Information		Y		
206 +		ABS/traction control	ESP MK60			Read Fault Code		Y		
206 +		ABS/traction control	ESP MK60			Erase Fault Code		Y		
206 +		ABS/traction control	ESP MK60			Live Data		Y		
206 +		ABS/traction control	ESP MK60			Actuation Test		Y		
206 +		ABS/traction control	ESP MK60			Special Function	Replacement parts	Y		
206 +		Driver and passenger airbags				Read ECU Information		Y		
206 +		Driver and passenger airbags				Read Fault Code		Y		
206 +		Driver and passenger airbags				Erase Fault Code		Y		
206 +		Driver and passenger airbags				Special Function	Replacement parts	Y		
206 +		Multifunction display	RT3			Read ECU Information		Y		
206 +		Multifunction display	RT3			Read Fault Code		Y		
206 +		Multifunction display	RT3			Erase Fault Code		Y		
206 +		Multifunction display	RT3			Actuation Test		Y		
206 +		Multifunction display	AMF			Read ECU Information		Y		
206 +		Multifunction display	AMF			Read Fault Code		Y		
206 +		Multifunction display	AMF			Erase Fault Code		Y		
206 +		Multifunction display	AMF			Live Data		Y		
206 +		Multifunction display	AMF			Actuation Test		Y		
206 +		Anti-theft alarm				Read ECU Information		Y		
206 +		Anti-theft alarm				Read Fault Code		Y		
206 +		Anti-theft alarm				Erase Fault Code		Y		
206 +		Anti-theft alarm				Actuation Test		Y		
206 +		Radio or radiotelephone(radio part)	Radio			Read ECU Information		Y		
206 +		Radio or radiotelephone(radio part)	Radio			Read Fault Code		Y		
206 +		Radio or radiotelephone(radio part)	Radio			Erase Fault Code		Y		
206 +		Radio or radiotelephone(radio part)	Radio			Live Data		Y		
206 +		Radio or radiotelephone(radio part)	Radio			Actuation Test		Y		
206 +		Radio or radiotelephone(radio part)	RDE			Read ECU Information		Y		
206 +		Radio or radiotelephone(radio part)	RDE			Read Fault Code		Y		
206 +		Radio or radiotelephone(radio part)	RDE			Erase Fault Code		Y		
206 +		Radio or radiotelephone(radio part)	RDE			Live Data		Y		
206 +		Radio or radiotelephone(radio part)	RDE			Actuation Test		Y		
206 +		CD player				Read ECU Information		Y		
206 +		CD player				Read Fault Code		Y		

206 +		CD player				Erase Fault Code		Y		
206 +		CD player				Live Data		Y		
206 +		CD player				Actuation Test		Y		
206 +		heating/ventilation				Read ECU Information		Y		
206 +		heating/ventilation				Read Fault Code		Y		
206 +		heating/ventilation				Erase Fault Code		Y		
206 +		heating/ventilation				Live Data		Y		
206 +		Instrument panel				Read ECU Information		Y		
206 +		Instrument panel				Read Fault Code		Y		
206 +		Instrument panel				Erase Fault Code		Y		
206 +		Instrument panel				Live Data		Y		
206 +		Instrument panel				Actuation Test		Y		
206 +		Rain and brightness sensor				Read ECU Information		Y		
206 +		Rain and brightness sensor				Read Fault Code		Y		
206 +		Rain and brightness sensor				Erase Fault Code		Y		
206 +		Switch module at the steering wheel				Read ECU Information		Y		
206 +		Switch module at the steering wheel				Read Fault Code		Y		
206 +		Switch module at the steering wheel				Erase Fault Code		Y		
206 +		Switch module at the steering wheel				Live Data		Y		
206 +		Power steering electric pump unit				Read ECU Information		Y		
206 +		Power steering electric pump unit				Read Fault Code		Y		
206 +		Power steering electric pump unit				Erase Fault Code		Y		
206 +		Power steering electric pump unit				Live Data		Y		
206 +		Services module				Read ECU Information		Y		
206 +		Services module				Read Fault Code		Y		
206 +		Services module				Erase Fault Code		Y		
206 +		Services module				Live Data		Y		
206 +		Services module				Actuation Test		Y		
207 VAN		Engine ECU	EDC15C2			Read ECU Information		Y		
207 VAN		Engine ECU	EDC15C2			Read Fault Code		Y		
207 VAN		Engine ECU	EDC15C2			Erase Fault Code		Y		
207 VAN		Engine ECU	EDC15C2			Live Data		Y		
207 VAN		Engine ECU	EDC15C2			Actuation Test		Y		
207 VAN		Engine ECU	EDC15C2			Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME745			Read ECU Information		Y		
207 VAN		Engine ECU	ME745			Read Fault Code		Y		
207 VAN		Engine ECU	ME745			Erase Fault Code		Y		
207 VAN		Engine ECU	ME745			Live Data		Y		
207 VAN		Engine ECU	ME745			Actuation Test		Y		
207 VAN		Engine ECU	ME745			Special Function	Initialising the autoadaptives	Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Special Function	Pack Repair	Y		

207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		

207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	J34P	J34P KFW		Read ECU Information		Y		
207 VAN		Engine ECU	J34P	J34P KFW		Read Fault Code		Y		
207 VAN		Engine ECU	J34P	J34P KFW		Erase Fault Code		Y		
207 VAN		Engine ECU	J34P	J34P KFW		Live Data		Y		
207 VAN		Engine ECU	J34P	J34P KFW		Actuation Test		Y		
207 VAN		Engine ECU	J34P	J34P KFW		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	J34P	J34P HFX		Read ECU Information		Y		
207 VAN		Engine ECU	J34P	J34P HFX		Read Fault Code		Y		
207 VAN		Engine ECU	J34P	J34P HFX		Erase Fault Code		Y		
207 VAN		Engine ECU	J34P	J34P HFX		Live Data		Y		
207 VAN		Engine ECU	J34P	J34P HFX		Actuation Test		Y		
207 VAN		Engine ECU	J34P	J34P HFX		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Read ECU Information		Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Read Fault Code		Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Erase Fault Code		Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Live Data		Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Actuation Test		Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Read ECU Information		Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Read Fault Code		Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Erase Fault Code		Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Live Data		Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Actuation Test		Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Read ECU Information		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Read Fault Code		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Erase Fault Code		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Live Data		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Actuation Test		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Special Function	Pairing	Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Read ECU Information		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Read Fault Code		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Erase Fault Code		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Live Data		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Actuation Test		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Special Function	Pairing	Y		
207 VAN		Engine ECU	V343	V343 HFV		Read ECU Information		Y		
207 VAN		Engine ECU	V343	V343 HFV		Read Fault Code		Y		
207 VAN		Engine ECU	V343	V343 HFV		Erase Fault Code		Y		
207 VAN		Engine ECU	V343	V343 HFV		Live Data		Y		
207 VAN		Engine ECU	V343	V343 HFV		Actuation Test		Y		
207 VAN		Engine ECU	V343	V343 HFV		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	V343	V343 KFT		Read ECU Information		Y		
207 VAN		Engine ECU	V343	V343 KFT		Read Fault Code		Y		
207 VAN		Engine ECU	V343	V343 KFT		Erase Fault Code		Y		
207 VAN		Engine ECU	V343	V343 KFT		Live Data		Y		
207 VAN		Engine ECU	V343	V343 KFT		Actuation Test		Y		
207 VAN		Engine ECU	V343	V343 KFT		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
207 VAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
207 VAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
207 VAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Live Data		Y		
207 VAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
207 VAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
207 VAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
207 VAN		gearbox				Read ECU Information		Y		
207 VAN		gearbox				Live Data		Y		
207 VAN		gearbox				Actuation Test		Y		

207 VAN		gearbox				Special Function	Configuration	Y		
207 VAN		gearbox				Special Function	Pack Repair	Y		
207 VAN		ABS/traction control	ABS MK70			Read ECU Information		Y		
207 VAN		ABS/traction control	ABS MK70			Read Fault Code		Y		
207 VAN		ABS/traction control	ABS MK70			Erase Fault Code		Y		
207 VAN		ABS/traction control	ABS MK70			Live Data		Y		
207 VAN		ABS/traction control	ABS MK70			Actuation Test		Y		
207 VAN		ABS/traction control	ABS MK70			Special Function	Replacement parts	Y		
207 VAN		ABS/traction control	ESP MK60			Read ECU Information		Y		
207 VAN		ABS/traction control	ESP MK60			Read Fault Code		Y		
207 VAN		ABS/traction control	ESP MK60			Erase Fault Code		Y		
207 VAN		ABS/traction control	ESP MK60			Live Data		Y		
207 VAN		ABS/traction control	ESP MK60			Actuation Test		Y		
207 VAN		ABS/traction control	ESP MK60			Special Function	Replacement parts	Y		
207 VAN		Driver and passenger airbags				Read ECU Information		Y		
207 VAN		Driver and passenger airbags				Read Fault Code		Y		
207 VAN		Driver and passenger airbags				Erase Fault Code		Y		
207 VAN		Driver and passenger airbags				Special Function	Replacement parts	Y		
207 VAN		Multifunction display	RT3			Read ECU Information		Y		
207 VAN		Multifunction display	RT3			Read Fault Code		Y		
207 VAN		Multifunction display	RT3			Erase Fault Code		Y		
207 VAN		Multifunction display	RT3			Actuation Test		Y		
207 VAN		Multifunction display	AMF			Read ECU Information		Y		
207 VAN		Multifunction display	AMF			Read Fault Code		Y		
207 VAN		Multifunction display	AMF			Erase Fault Code		Y		
207 VAN		Multifunction display	AMF			Live Data		Y		
207 VAN		Multifunction display	AMF			Actuation Test		Y		
207 VAN		Anti-theft alarm				Read ECU Information		Y		
207 VAN		Anti-theft alarm				Read Fault Code		Y		
207 VAN		Anti-theft alarm				Erase Fault Code		Y		
207 VAN		Anti-theft alarm				Actuation Test		Y		
207 VAN		Radio or radiotelephone(radio part)	Radio			Read ECU Information		Y		
207 VAN		Radio or radiotelephone(radio part)	Radio			Read Fault Code		Y		
207 VAN		Radio or radiotelephone(radio part)	Radio			Erase Fault Code		Y		
207 VAN		Radio or radiotelephone(radio part)	Radio			Live Data		Y		
207 VAN		Radio or radiotelephone(radio part)	Radio			Actuation Test		Y		
207 VAN		Radio or radiotelephone(radio part)	RDE			Read ECU Information		Y		
207 VAN		Radio or radiotelephone(radio part)	RDE			Read Fault Code		Y		
207 VAN		Radio or radiotelephone(radio part)	RDE			Erase Fault Code		Y		
207 VAN		Radio or radiotelephone(radio part)	RDE			Live Data		Y		
207 VAN		Radio or radiotelephone(radio part)	RDE			Actuation Test		Y		
207 VAN		Built-in Systems Interface (BSI)				Read ECU Information		Y		
207 VAN		Built-in Systems Interface (BSI)				Read Fault Code		Y		
207 VAN		Built-in Systems Interface (BSI)				Erase Fault Code		Y		
207 VAN		Built-in Systems Interface (BSI)				Live Data		Y		
207 VAN		Built-in Systems Interface (BSI)				Actuation Test		Y		
207 VAN		CD player				Read ECU Information		Y		
207 VAN		CD player				Read Fault Code		Y		
207 VAN		CD player				Erase Fault Code		Y		
207 VAN		CD player				Live Data		Y		
207 VAN		CD player				Actuation Test		Y		

207 VAN		heating/ventilation				Read ECU Information		Y		
207 VAN		heating/ventilation				Read Fault Code		Y		
207 VAN		heating/ventilation				Erase Fault Code		Y		
207 VAN		heating/ventilation				Live Data		Y		
207 VAN		Instrument panel				Read ECU Information		Y		
207 VAN		Instrument panel				Read Fault Code		Y		
207 VAN		Instrument panel				Erase Fault Code		Y		
207 VAN		Instrument panel				Live Data		Y		
207 VAN		Instrument panel				Actuation Test		Y		
207 VAN		Rain and brightness sensor				Read ECU Information		Y		
207 VAN		Rain and brightness sensor				Read Fault Code		Y		
207 VAN		Rain and brightness sensor				Erase Fault Code		Y		
207 VAN		Switch module at the steering wheel				Read ECU Information		Y		
207 VAN		Switch module at the steering wheel				Read Fault Code		Y		
207 VAN		Switch module at the steering wheel				Erase Fault Code		Y		
207 VAN		Switch module at the steering wheel				Live Data		Y		
207 VAN		Power steering electric pump unit				Read ECU Information		Y		
207 VAN		Power steering electric pump unit				Read Fault Code		Y		
207 VAN		Power steering electric pump unit				Erase Fault Code		Y		
207 VAN		Power steering electric pump unit				Live Data		Y		
207 VAN		Services module				Read ECU Information		Y		
207 VAN		Services module				Read Fault Code		Y		
207 VAN		Services module				Erase Fault Code		Y		
207 VAN		Services module				Live Data		Y		
207 VAN		Services module				Actuation Test		Y		
207 CAN		BSI (Built-in Systems Interface)				Read ECU Information		Y		
207 CAN		BSI (Built-in Systems Interface)				Read Fault Code		Y		
207 CAN		BSI (Built-in Systems Interface)				Erase Fault Code		Y		
207 CAN		BSI (Built-in Systems Interface)				Live Data		Y		
207 CAN		BSI (Built-in Systems Interface)				Actuation Test		Y		
207 CAN		BSI (Built-in Systems Interface)				Special Function	Changing the modeElectrical	Y		
207 CAN		BSI (Built-in Systems Interface)				Special Function	Learning	Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		

207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Live Data		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Actuation Test		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Read ECU Information		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Read Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Live Data		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Actuation Test		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Live Data		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Actuation Test		Y		
207 CAN		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Live Data		Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Live Data		Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Live Data		Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Live Data		Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Read Fault Code		Y		

207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Live Data		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Pairing	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Live Data		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Pairing	Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Read ECU Information		Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Read Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Erase Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Live Data		Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Actuation Test		Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Read ECU Information		Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Read Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Erase Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Live Data		Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Actuation Test		Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Read ECU Information		Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Read Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Erase Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Live Data		Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Actuation Test		Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Read ECU Information		Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Read Fault Code		Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Erase Fault Code		Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Live Data		Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Actuation Test		Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Special Function	Pack Repair	Y		

207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Read ECU Information		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Read Fault Code		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Erase Fault Code		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Live Data		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Actuation Test		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Special Function	Configuration	Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Read ECU Information		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Read Fault Code		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Erase Fault Code		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Live Data		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Actuation Test		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Special Function	Configuration	Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Read ECU Information		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Read Fault Code		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Erase Fault Code		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Live Data		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Actuation Test		Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Special Function	Configuration	Y		
207 CAN		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Read ECU Information		Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Read Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Live Data		Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Actuation Test		Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Read ECU Information		Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Read Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Live Data		Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Actuation Test		Y		
207 CAN		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	J34P	J34P KFW		Read ECU Information		Y		
207 CAN		Engine ECU	J34P	J34P KFW		Read Fault Code		Y		
207 CAN		Engine ECU	J34P	J34P KFW		Erase Fault Code		Y		
207 CAN		Engine ECU	J34P	J34P KFW		Live Data		Y		
207 CAN		Engine ECU	J34P	J34P KFW		Actuation Test		Y		
207 CAN		Engine ECU	J34P	J34P KFW		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	J34P	J34P KFV		Read ECU Information		Y		
207 CAN		Engine ECU	J34P	J34P KFV		Read Fault Code		Y		
207 CAN		Engine ECU	J34P	J34P KFV		Erase Fault Code		Y		
207 CAN		Engine ECU	J34P	J34P KFV		Live Data		Y		
207 CAN		Engine ECU	J34P	J34P KFV		Actuation Test		Y		
207 CAN		Engine ECU	J34P	J34P KFV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Read ECU Information		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Read Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Live Data		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Actuation Test		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Read ECU Information		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Read Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Live Data		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Actuation Test		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Read ECU Information		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Read Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Live Data		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Actuation Test		Y		
207 CAN		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HR		Read ECU Information		Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HR		Read Fault Code		Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HR		Erase Fault Code		Y		

207 CAN		Engine ECU	HDI SID807	HDI SID807 9HR		Live Data		Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HR		Actuation Test		Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HR		Special Function	Configuration	Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HR		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HL		Read ECU Information		Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HL		Read Fault Code		Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HL		Erase Fault Code		Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HL		Live Data		Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HL		Actuation Test		Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HL		Special Function	Configuration	Y		
207 CAN		Engine ECU	HDI SID807	HDI SID807 9HL		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	V341			Read ECU Information		Y		
207 CAN		Engine ECU	V341			Read Fault Code		Y		
207 CAN		Engine ECU	V341			Erase Fault Code		Y		
207 CAN		Engine ECU	V341			Live Data		Y		
207 CAN		Engine ECU	V341			Actuation Test		Y		
207 CAN		Engine ECU	V341			Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Read ECU Information		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Read Fault Code		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Live Data		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Actuation Test		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Read ECU Information		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Read Fault Code		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Live Data		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Actuation Test		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Read ECU Information		Y		
207 CAN		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Read Fault Code		Y		
207 CAN		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Erase Fault Code		Y		
207 CAN		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Live Data		Y		
207 CAN		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Actuation Test		Y		
207 CAN		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Special Function	Configuration	Y		
207 CAN		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Live Data		Y		
207 CAN		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Live Data		Y		
207 CAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
207 CAN		gearbox	BVA AL4			Read ECU Information		Y		
207 CAN		gearbox	BVA AL4			Read Fault Code		Y		
207 CAN		gearbox	BVA AL4			Erase Fault Code		Y		
207 CAN		gearbox	BVA AL4			Live Data		Y		
207 CAN		gearbox	BVA AL4			Actuation Test		Y		
207 CAN		gearbox	BVA AL4			Special Function	Configuration	Y		
207 CAN		gearbox	BVA AL4			Special Function	Pack Repair	Y		
207 CAN		gearbox	BVMP MA			Read ECU Information		Y		
207 CAN		gearbox	BVMP MA			Read Fault Code		Y		
207 CAN		gearbox	BVMP MA			Erase Fault Code		Y		
207 CAN		gearbox	BVMP MA			Live Data		Y		
207 CAN		gearbox	BVMP MA			Actuation Test		Y		
207 CAN		gearbox	BVMP MA			Special Function	Counters	Y		
207 CAN		gearbox	BVMP MA			Special Function	Pack Repair	Y		

207 CAN		ABS/traction control	ABS MK70 1			Read ECU Information		Y		
207 CAN		ABS/traction control	ABS MK70 1			Read Fault Code		Y		
207 CAN		ABS/traction control	ABS MK70 1			Erase Fault Code		Y		
207 CAN		ABS/traction control	ABS MK70 1			Live Data		Y		
207 CAN		ABS/traction control	ABS MK70 1			Actuation Test		Y		
207 CAN		ABS/traction control	ABS MK70 1			Special Function	Replacement parts	Y		
207 CAN		ABS/traction control	ESP MK60 0			Read ECU Information		Y		
207 CAN		ABS/traction control	ESP MK60 0			Read Fault Code		Y		
207 CAN		ABS/traction control	ESP MK60 0			Erase Fault Code		Y		
207 CAN		ABS/traction control	ESP MK60 0			Live Data		Y		
207 CAN		ABS/traction control	ESP MK60 0			Actuation Test		Y		
207 CAN		ABS/traction control	ESP MK60 0			Special Function	Pack Repair	Y		
207 CAN		Driver and passenger airbags				Read ECU Information		Y		
207 CAN		Driver and passenger airbags				Read Fault Code		Y		
207 CAN		Driver and passenger airbags				Erase Fault Code		Y		
207 CAN		Driver and passenger airbags				Live Data		Y		
207 CAN		Driver and passenger airbags				Special Function	Pack Repair	Y		
207 CAN		Electric power steering				Read ECU Information		Y		
207 CAN		Electric power steering				Read Fault Code		Y		
207 CAN		Electric power steering				Erase Fault Code		Y		
207 CAN		Electric power steering				Live Data		Y		
207 CAN		Diesel additive				Read ECU Information		Y		
207 CAN		Diesel additive				Read Fault Code		Y		
207 CAN		Diesel additive				Erase Fault Code		Y		
207 CAN		Diesel additive				Live Data		Y		
207 CAN		Diesel additive				Actuation Test		Y		
207 CAN		Under inflation detection				Read ECU Information		Y		
207 CAN		Under inflation detection				Read Fault Code		Y		
207 CAN		Under inflation detection				Erase Fault Code		Y		
207 CAN		Under inflation detection				Live Data		Y		
207 CAN		Battery charge status unit	BECB			Read ECU Information		Y		
207 CAN		Battery charge status unit	BECB			Live Data		Y		
207 CAN		Battery charge status unit	BECB GEN2			Read ECU Information		Y		
207 CAN		Battery charge status unit	BECB GEN2			Live Data		Y		
207 CAN		Headlamp height adjuster/directional				Read ECU Information		Y		
207 CAN		Headlamp height adjuster/directional				Read Fault Code		Y		
207 CAN		Headlamp height adjuster/directional				Erase Fault Code		Y		
207 CAN		Headlamp height adjuster/directional				Live Data		Y		
207 CAN		Headlamp height adjuster/directional				Actuation Test		Y		
207 CAN		Engine relay unit				Read ECU Information		Y		
207 CAN		Engine relay unit				Actuation Test		Y		
207 CAN		Trailer relay unit				Read ECU Information		Y		
207 CAN		Trailer relay unit				Read Fault Code		Y		
207 CAN		Trailer relay unit				Erase Fault Code		Y		
207 CAN		heating/ventilation				Read ECU Information		Y		
207 CAN		heating/ventilation				Read Fault Code		Y		
207 CAN		heating/ventilation				Erase Fault Code		Y		
207 CAN		heating/ventilation				Live Data		Y		
207 CAN		heating/ventilation				Actuation Test		Y		
207 CAN		Switch module under the steering wheel				Read ECU Information		Y		
207 CAN		Switch module under the steering wheel				Read Fault Code		Y		
207 CAN		Switch module under the steering wheel				Erase Fault Code		Y		
207 CAN		Switch module under the steering wheel				Live Data		Y		
207 CAN		Switch module under the steering wheel				Actuation Test		Y		
207 CAN		Instrument panel				Read ECU Information		Y		
207 CAN		Instrument panel				Read Fault Code		Y		

207 CAN		Instrument panel				Erase Fault Code		Y		
207 CAN		Instrument panel				Live Data		Y		
207 CAN		Instrument panel				Actuation Test		Y		
207 CAN		Multifunction display	Type 'A'(segments) with buttons			Read ECU Information		Y		
207 CAN		Multifunction display	Type 'A'(segments) with buttons			Read Fault Code		Y		
207 CAN		Multifunction display	Type 'A'(segments) with buttons			Erase Fault Code		Y		
207 CAN		Multifunction display	Type 'A'(segments) with buttons			Live Data		Y		
207 CAN		Multifunction display	Type 'A'(segments) with buttons			Actuation Test		Y		
207 CAN		Multifunction display	Type 'A'(segments) without buttons			Read ECU Information		Y		
207 CAN		Multifunction display	Type 'A'(segments) without buttons			Read Fault Code		Y		
207 CAN		Multifunction display	Type 'A'(segments) without buttons			Erase Fault Code		Y		
207 CAN		Multifunction display	Type 'A'(segments) without buttons			Live Data		Y		
207 CAN		Multifunction display	Type 'A'(segments) without buttons			Actuation Test		Y		
207 CAN		Multifunction display	Type 'C' (dot matrix)			Read ECU Information		Y		
207 CAN		Multifunction display	Type 'C' (dot matrix)			Read Fault Code		Y		
207 CAN		Multifunction display	Type 'C' (dot matrix)			Erase Fault Code		Y		
207 CAN		Multifunction display	Type 'C' (dot matrix)			Live Data		Y		
207 CAN		Multifunction display	Type 'C' (dot matrix)			Actuation Test		Y		
207 CAN		Multifunction display	Type 'C colour' (dot			Read ECU Information		Y		
207 CAN		Multifunction display	Type 'C colour' (dot			Read Fault Code		Y		
207 CAN		Multifunction display	Type 'C colour' (dot			Erase Fault Code		Y		
207 CAN		Multifunction display	Type 'C colour' (dot			Live Data		Y		
207 CAN		Multifunction display	Type 'C colour' (dot			Actuation Test		Y		
207 CAN		Parking aid				Read ECU Information		Y		
207 CAN		Parking aid				Read Fault Code		Y		
207 CAN		Parking aid				Erase Fault Code		Y		
207 CAN		Parking aid				Live Data		Y		
207 CAN		Radio or radiotelephone (radio part)	RD4			Read ECU Information		Y		
207 CAN		Radio or radiotelephone (radio part)	RD4			Read Fault Code		Y		
207 CAN		Radio or radiotelephone (radio part)	RD4			Erase Fault Code		Y		
207 CAN		Radio or radiotelephone (radio part)	RD4			Live Data		Y		
207 CAN		Radio or radiotelephone (radio part)	RD4			Actuation Test		Y		
207 CAN		Radio or radiotelephone (radio part)	RD45			Read ECU Information		Y		
207 CAN		Radio or radiotelephone (radio part)	RD45			Read Fault Code		Y		
207 CAN		Radio or radiotelephone (radio part)	RD45			Erase Fault Code		Y		
207 CAN		Radio or radiotelephone (radio part)	RD45			Live Data		Y		
207 CAN		Radio or radiotelephone (radio part)	RD45			Actuation Test		Y		
207 CAN		Telematics	RADIONAB RNEG			Read ECU Information		Y		
207 CAN		Telematics	RADIONAB RNEG			Read Fault Code		Y		
207 CAN		Telematics	RADIONAB RNEG			Erase Fault Code		Y		
207 CAN		Telematics	RADIONAB RNEG			Live Data		Y		
207 CAN		Telematics	RADIONAB RNEG			Actuation Test		Y		
207 CAN		Telematics	BOITIER TELEMATIQUE			Read ECU Information		Y		
207 CAN		Telematics	BOITIER TELEMATIQUE			Read Fault Code		Y		
207 CAN		Telematics	BOITIER TELEMATIQUE			Erase Fault Code		Y		
207 CAN		Telematics	BOITIER TELEMATIQUE			Live Data		Y		

207 CAN		Telematics	BOITIER TELEMATIQUE			Actuation Test		Y		
207 CAN		CD player				Read ECU Information		Y		
207 CAN		CD player				Read Fault Code		Y		
207 CAN		CD player				Erase Fault Code		Y		
207 CAN		CD player				Actuation Test		Y		
207 CAN		Hands-free kit (Telephone)	KML			Read ECU Information		Y		
207 CAN		Hands-free kit (Telephone)	KML			Read Fault Code		Y		
207 CAN		Hands-free kit (Telephone)	KML			Erase Fault Code		Y		
207 CAN		Hands-free kit (Telephone)	KML			Live Data		Y		
207 CAN		Hands-free kit (Telephone)	KML			Actuation Test		Y		
207 CAN		Hands-free kit (Telephone)	BOITIER NOMADE			Read ECU Information		Y		
207 CAN		Hands-free kit (Telephone)	BOITIER NOMADE			Read Fault Code		Y		
207 CAN		Hands-free kit (Telephone)	BOITIER NOMADE			Erase Fault Code		Y		
207 CAN		Hands-free kit (Telephone)	BOITIER NOMADE			Live Data		Y		
207 CAN		Hands-free kit (Telephone)	BOITIER NOMADE			Actuation Test		Y		
207 CAN		Anti-theft alarm	Alarm without anti-lift module			Read ECU Information		Y		
207 CAN		Anti-theft alarm	Alarm without anti-lift module			Read Fault Code		Y		
207 CAN		Anti-theft alarm	Alarm without anti-lift module			Erase Fault Code		Y		
207 CAN		Anti-theft alarm	Alarm without anti-lift module			Live Data		Y		
207 CAN		Anti-theft alarm	Alarm without anti-lift module			Actuation Test		Y		
207 CAN		Folding roof				Read ECU Information		Y		
207 CAN		Folding roof				Read Fault Code		Y		
207 CAN		Folding roof				Erase Fault Code		Y		
207 CAN		Folding roof				Live Data		Y		
207 CAN		Folding roof				Actuation Test		Y		
207 CAN		Driving school module				Read ECU Information		Y		
207 CAN		Driving school module				Actuation Test		Y		
207 CAN		High frequency receiver				Read ECU Information		Y		
207 CAN		High frequency receiver				Read Fault Code		Y		
207 CAN		High frequency receiver				Erase Fault Code		Y		
207 CAN		High frequency receiver				Live Data		Y		
207 CAN		Seat belts not fastened LED unit				Read ECU Information		Y		
207 CAN		Seat belts not fastened LED unit				Actuation Test		Y		
207 CAN		Service module				Read ECU Information		Y		
207 CAN		Service module				Read Fault Code		Y		
207 CAN		Service module				Erase Fault Code		Y		
207 CAN		Service module				Live Data		Y		
207 CAN		Service module				Actuation Test		Y		
207 CAN		Rain and brightness sensor				Read ECU Information		Y		
207 CAN		Rain and brightness sensor				Read Fault Code		Y		
207 CAN		Rain and brightness sensor				Erase Fault Code		Y		
207i		BSI(Built-in Systems				Read ECU Information		Y		
207i		BSI(Built-in Systems				Read Fault Code		Y		
207i		BSI(Built-in Systems				Erase Fault Code		Y		
207i		BSI(Built-in Systems				Live Data		Y		
207i		BSI(Built-in Systems				Actuation Test		Y		
207i		AL4 AT8 automatic gearbox				Read ECU Information		Y		
207i		AL4 AT8 automatic gearbox				Live Data		Y		
207i		AL4 AT8 automatic gearbox				Actuation Test		Y		
207i		AL4 AT8 automatic gearbox				Special Function	Configuration	Y		
207i		AL4 AT8 automatic gearbox				Special Function	Pack Repair	Y		
207i		ABS or ESP ECU	ABS MK70			Read ECU Information		Y		
207i		ABS or ESP ECU	ABS MK70			Read Fault Code		Y		
207i		ABS or ESP ECU	ABS MK70			Erase Fault Code		Y		
207i		ABS or ESP ECU	ABS MK70			Live Data		Y		
207i		ABS or ESP ECU	ABS MK70			Actuation Test		Y		
207i		ABS or ESP ECU	ABS MK70			Special Function	Replacement parts	Y		
207i		ABS or ESP ECU	ESP MK60			Read ECU Information		Y		
207i		ABS or ESP ECU	ESP MK60			Read Fault Code		Y		

207i		ABS or ESP ECU	ESP MK60			Erase Fault Code		Y		
207i		ABS or ESP ECU	ESP MK60			Live Data		Y		
207i		ABS or ESP ECU	ESP MK60			Actuation Test		Y		
207i		ABS or ESP ECU	ESP MK60			Special Function	Replacement parts	Y		
207i		Air-bag				Read ECU Information		Y		
207i		Air-bag				Read Fault Code		Y		
207i		Air-bag				Erase Fault Code		Y		
207i		Air-bag				Special Function	Replacement parts	Y		
207i		heating/ventilation				Read ECU Information		Y		
207i		heating/ventilation				Read Fault Code		Y		
207i		heating/ventilation				Erase Fault Code		Y		
207i		heating/ventilation				Live Data		Y		
207i		alarm				Read ECU Information		Y		
207i		alarm				Read Fault Code		Y		
207i		alarm				Erase Fault Code		Y		
207i		alarm				Actuation Test		Y		
207i		Rain/sunlight sensor				Read ECU Information		Y		
207i		Rain/sunlight sensor				Read Fault Code		Y		
207i		Rain/sunlight sensor				Erase Fault Code		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Live Data		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Actuation Test		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Read ECU Information		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Read Fault Code		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Live Data		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Actuation Test		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Live Data		Y		
207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Actuation Test		Y		

207 +		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CM	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Read ECU Information		Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Read Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Live Data		Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Actuation Test		Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Read ECU Information		Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Read Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Live Data		Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Actuation Test		Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read ECU Information		Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Live Data		Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Actuation Test		Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Read ECU Information		Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Read Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Live Data		Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Actuation Test		Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Read ECU Information		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Read Fault Code		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Live Data		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Actuation Test		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Pairing	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Read ECU Information		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Read Fault Code		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Live Data		Y		

207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Actuation Test		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Pairing	Y		
207 +		Engine ECU	ME745	ME745 N6B		Read ECU Information		Y		
207 +		Engine ECU	ME745	ME745 N6B		Read Fault Code		Y		
207 +		Engine ECU	ME745	ME745 N6B		Erase Fault Code		Y		
207 +		Engine ECU	ME745	ME745 N6B		Live Data		Y		
207 +		Engine ECU	ME745	ME745 N6B		Actuation Test		Y		
207 +		Engine ECU	ME745	ME745 N6B		Special Function	Pack Repair	Y		
207 +		Engine ECU	ME745	ME745 N6A		Read ECU Information		Y		
207 +		Engine ECU	ME745	ME745 N6A		Read Fault Code		Y		
207 +		Engine ECU	ME745	ME745 N6A		Erase Fault Code		Y		
207 +		Engine ECU	ME745	ME745 N6A		Live Data		Y		
207 +		Engine ECU	ME745	ME745 N6A		Actuation Test		Y		
207 +		Engine ECU	ME745	ME745 N6A		Special Function	Pack Repair	Y		
207 +		Engine ECU	ME745	ME745 NFU		Read ECU Information		Y		
207 +		Engine ECU	ME745	ME745 NFU		Read Fault Code		Y		
207 +		Engine ECU	ME745	ME745 NFU		Erase Fault Code		Y		
207 +		Engine ECU	ME745	ME745 NFU		Live Data		Y		
207 +		Engine ECU	ME745	ME745 NFU		Actuation Test		Y		
207 +		Engine ECU	ME745	ME745 NFU		Special Function	Pack Repair	Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Read ECU Information		Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Read Fault Code		Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Erase Fault Code		Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Live Data		Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Actuation Test		Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Special Function	Pack Repair	Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Read ECU Information		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Read Fault Code		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Erase Fault Code		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Live Data		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Actuation Test		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Special Function	Configuration	Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Special Function	Pack Repair	Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Read ECU Information		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Read Fault Code		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Erase Fault Code		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Live Data		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Actuation Test		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Special Function	Configuration	Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4 5FY		Special Function	Pack Repair	Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Read ECU Information		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Read Fault Code		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Erase Fault Code		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Live Data		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Actuation Test		Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Special Function	Configuration	Y		
207 +		Engine ECU	MED17 4 EURO4	MED17 4 EURO4+ 5FR		Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Read ECU Information		Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Read Fault Code		Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Erase Fault Code		Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Live Data		Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Actuation Test		Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Read ECU Information		Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Read Fault Code		Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Erase Fault Code		Y		

207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Live Data		Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Actuation Test		Y		
207 +		Engine ECU	MEV17 4 EURO4	MEV17 4 EURO4 8FS		Special Function	Pack Repair	Y		
207 +		Engine ECU	J34P	J34P KFW		Read ECU Information		Y		
207 +		Engine ECU	J34P	J34P KFW		Read Fault Code		Y		
207 +		Engine ECU	J34P	J34P KFW		Erase Fault Code		Y		
207 +		Engine ECU	J34P	J34P KFW		Live Data		Y		
207 +		Engine ECU	J34P	J34P KFW		Actuation Test		Y		
207 +		Engine ECU	J34P	J34P KFW		Special Function	Pack Repair	Y		
207 +		Engine ECU	J34P	J34P KFV		Read ECU Information		Y		
207 +		Engine ECU	J34P	J34P KFV		Read Fault Code		Y		
207 +		Engine ECU	J34P	J34P KFV		Erase Fault Code		Y		
207 +		Engine ECU	J34P	J34P KFV		Live Data		Y		
207 +		Engine ECU	J34P	J34P KFV		Actuation Test		Y		
207 +		Engine ECU	J34P	J34P KFV		Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Read ECU Information		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Read Fault Code		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Erase Fault Code		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Live Data		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Actuation Test		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Read ECU Information		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Read Fault Code		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Erase Fault Code		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Live Data		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Actuation Test		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FR		Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Read ECU Information		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Read Fault Code		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Erase Fault Code		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Live Data		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Actuation Test		Y		
207 +		Engine ECU	MEV17 4 EURO5	MEV17 4 EURO5 8FP		Special Function	Pack Repair	Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HR		Read ECU Information		Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HR		Read Fault Code		Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HR		Erase Fault Code		Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HR		Live Data		Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HR		Actuation Test		Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HR		Special Function	Configuration	Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HR		Special Function	Pack Repair	Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HL		Read ECU Information		Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HL		Read Fault Code		Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HL		Erase Fault Code		Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HL		Live Data		Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HL		Actuation Test		Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HL		Special Function	Configuration	Y		
207 +		Engine ECU	HDI SID807	HDI SID807 9HL		Special Function	Pack Repair	Y		
207 +		Engine ECU	V341			Read ECU Information		Y		
207 +		Engine ECU	V341			Read Fault Code		Y		
207 +		Engine ECU	V341			Erase Fault Code		Y		
207 +		Engine ECU	V341			Live Data		Y		
207 +		Engine ECU	V341			Actuation Test		Y		
207 +		Engine ECU	V341			Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Read ECU Information		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Read Fault Code		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Erase Fault Code		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Live Data		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Actuation Test		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Special Function	Configuration	Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Read ECU Information		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Read Fault Code		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Erase Fault Code		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Live Data		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Actuation Test		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Special Function	Configuration	Y		

207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Special Function	Pack Repair	Y		
207 +		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Read ECU Information		Y		
207 +		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Read Fault Code		Y		
207 +		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Erase Fault Code		Y		
207 +		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Live Data		Y		
207 +		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Actuation Test		Y		
207 +		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Special Function	Configuration	Y		
207 +		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Read ECU Information		Y		
207 +		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Read Fault Code		Y		
207 +		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Live Data		Y		
207 +		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Actuation Test		Y		
207 +		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
207 +		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
207 +		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Live Data		Y		
207 +		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
207 +		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
207 +		gearbox	BVA AL4			Read ECU Information		Y		
207 +		gearbox	BVA AL4			Read Fault Code		Y		
207 +		gearbox	BVA AL4			Erase Fault Code		Y		
207 +		gearbox	BVA AL4			Live Data		Y		
207 +		gearbox	BVA AL4			Actuation Test		Y		
207 +		gearbox	BVA AL4			Special Function	Configuration	Y		
207 +		gearbox	BVA AL4			Special Function	Pack Repair	Y		
207 +		gearbox	BVMP MA			Read ECU Information		Y		
207 +		gearbox	BVMP MA			Read Fault Code		Y		
207 +		gearbox	BVMP MA			Erase Fault Code		Y		
207 +		gearbox	BVMP MA			Live Data		Y		
207 +		gearbox	BVMP MA			Actuation Test		Y		
207 +		gearbox	BVMP MA			Special Function	Counters	Y		
207 +		gearbox	BVMP MA			Special Function	Pack Repair	Y		
207 +		ABS/traction control	ABS MK70 1			Read ECU Information		Y		
207 +		ABS/traction control	ABS MK70 1			Read Fault Code		Y		
207 +		ABS/traction control	ABS MK70 1			Erase Fault Code		Y		
207 +		ABS/traction control	ABS MK70 1			Live Data		Y		
207 +		ABS/traction control	ABS MK70 1			Actuation Test		Y		
207 +		ABS/traction control	ABS MK70 1			Special Function	Replacement parts	Y		
207 +		ABS/traction control	ESP MK60 0			Read ECU Information		Y		
207 +		ABS/traction control	ESP MK60 0			Read Fault Code		Y		
207 +		ABS/traction control	ESP MK60 0			Erase Fault Code		Y		
207 +		ABS/traction control	ESP MK60 0			Live Data		Y		
207 +		ABS/traction control	ESP MK60 0			Actuation Test		Y		
207 +		ABS/traction control	ESP MK60 0			Special Function	Pack Repair	Y		
207 +		Driver and passenger airbags				Read ECU Information		Y		
207 +		Driver and passenger airbags				Read Fault Code		Y		
207 +		Driver and passenger airbags				Erase Fault Code		Y		
207 +		Driver and passenger airbags				Live Data		Y		
207 +		Driver and passenger airbags				Special Function	Pack Repair	Y		
207 +		Electric power steering				Read ECU Information		Y		
207 +		Electric power steering				Read Fault Code		Y		
207 +		Electric power steering				Erase Fault Code		Y		
207 +		Electric power steering				Live Data		Y		
207 +		Diesel additive				Read ECU Information		Y		
207 +		Diesel additive				Read Fault Code		Y		
207 +		Diesel additive				Erase Fault Code		Y		
207 +		Diesel additive				Live Data		Y		
207 +		Diesel additive				Actuation Test		Y		
207 +		Under inflation detection				Read ECU Information		Y		
207 +		Under inflation detection				Read Fault Code		Y		
207 +		Under inflation detection				Erase Fault Code		Y		
207 +		Under inflation detection				Live Data		Y		

207 +		Battery charge status unit	BECB			Read ECU Information		Y		
207 +		Battery charge status unit	BECB			Live Data		Y		
207 +		Battery charge status unit	BECB GEN2			Read ECU Information		Y		
207 +		Battery charge status unit	BECB GEN2			Live Data		Y		
207 +		Headlamp height adjuster/directional				Read ECU Information		Y		
207 +		Headlamp height adjuster/directional				Read Fault Code		Y		
207 +		Headlamp height adjuster/directional				Erase Fault Code		Y		
207 +		Headlamp height adjuster/directional				Live Data		Y		
207 +		Headlamp height adjuster/directional				Actuation Test		Y		
207 +		Engine relay unit				Read ECU Information		Y		
207 +		Engine relay unit				Actuation Test		Y		
207 +		Trailer relay unit				Read ECU Information		Y		
207 +		Trailer relay unit				Read Fault Code		Y		
207 +		Trailer relay unit				Erase Fault Code		Y		
207 +		heating/ventilation				Read ECU Information		Y		
207 +		heating/ventilation				Read Fault Code		Y		
207 +		heating/ventilation				Erase Fault Code		Y		
207 +		heating/ventilation				Live Data		Y		
207 +		heating/ventilation				Actuation Test		Y		
207 +		Switch module under the steering wheel				Read ECU Information		Y		
207 +		Switch module under the steering wheel				Read Fault Code		Y		
207 +		Switch module under the steering wheel				Erase Fault Code		Y		
207 +		Switch module under the steering wheel				Live Data		Y		
207 +		Switch module under the steering wheel				Actuation Test		Y		
207 +		Instrument panel				Read ECU Information		Y		
207 +		Instrument panel				Read Fault Code		Y		
207 +		Instrument panel				Erase Fault Code		Y		
207 +		Instrument panel				Live Data		Y		
207 +		Instrument panel				Actuation Test		Y		
207 +		Multifunction display	Type 'A'(segments) with buttons			Read ECU Information		Y		
207 +		Multifunction display	Type 'A'(segments) with buttons			Read Fault Code		Y		
207 +		Multifunction display	Type 'A'(segments) with buttons			Erase Fault Code		Y		
207 +		Multifunction display	Type 'A'(segments) with buttons			Live Data		Y		
207 +		Multifunction display	Type 'A'(segments) with buttons			Actuation Test		Y		
207 +		Multifunction display	Type 'A'(segments) without buttons			Read ECU Information		Y		
207 +		Multifunction display	Type 'A'(segments) without buttons			Read Fault Code		Y		
207 +		Multifunction display	Type 'A'(segments) without buttons			Erase Fault Code		Y		
207 +		Multifunction display	Type 'A'(segments) without buttons			Live Data		Y		
207 +		Multifunction display	Type 'A'(segments) without buttons			Actuation Test		Y		
207 +		Multifunction display	Type 'C' (dot matrix)			Read ECU Information		Y		
207 +		Multifunction display	Type 'C' (dot matrix)			Read Fault Code		Y		
207 +		Multifunction display	Type 'C' (dot matrix)			Erase Fault Code		Y		
207 +		Multifunction display	Type 'C' (dot matrix)			Live Data		Y		
207 +		Multifunction display	Type 'C' (dot matrix)			Actuation Test		Y		
207 +		Multifunction display	Type 'C colour' (dot			Read ECU Information		Y		
207 +		Multifunction display	Type 'C colour' (dot			Read Fault Code		Y		

207 +		Multifunction display	Type 'C colour' (dot			Erase Fault Code		Y		
207 +		Multifunction display	Type 'C colour' (dot			Live Data		Y		
207 +		Multifunction display	Type 'C colour' (dot			Actuation Test		Y		
207 +		Parking aid				Read ECU Information		Y		
207 +		Parking aid				Read Fault Code		Y		
207 +		Parking aid				Erase Fault Code		Y		
207 +		Parking aid				Live Data		Y		
207 +		Radio or radiotelephone (radio part)	RD4			Read ECU Information		Y		
207 +		Radio or radiotelephone (radio part)	RD4			Read Fault Code		Y		
207 +		Radio or radiotelephone (radio part)	RD4			Erase Fault Code		Y		
207 +		Radio or radiotelephone (radio part)	RD4			Live Data		Y		
207 +		Radio or radiotelephone (radio part)	RD4			Actuation Test		Y		
207 +		Radio or radiotelephone (radio part)	RD45			Read ECU Information		Y		
207 +		Radio or radiotelephone (radio part)	RD45			Read Fault Code		Y		
207 +		Radio or radiotelephone (radio part)	RD45			Erase Fault Code		Y		
207 +		Radio or radiotelephone (radio part)	RD45			Live Data		Y		
207 +		Radio or radiotelephone (radio part)	RD45			Actuation Test		Y		
207 +		Telematics	RADIONAB RNEG			Read ECU Information		Y		
207 +		Telematics	RADIONAB RNEG			Read Fault Code		Y		
207 +		Telematics	RADIONAB RNEG			Erase Fault Code		Y		
207 +		Telematics	RADIONAB RNEG			Live Data		Y		
207 +		Telematics	RADIONAB RNEG			Actuation Test		Y		
207 +		Telematics	BOITIER TELEMATIQUE			Read ECU Information		Y		
207 +		Telematics	BOITIER TELEMATIQUE			Read Fault Code		Y		
207 +		Telematics	BOITIER TELEMATIQUE			Erase Fault Code		Y		
207 +		Telematics	BOITIER TELEMATIQUE			Live Data		Y		
207 +		Telematics	BOITIER TELEMATIQUE			Actuation Test		Y		
207 +		CD player				Read ECU Information		Y		
207 +		CD player				Read Fault Code		Y		
207 +		CD player				Erase Fault Code		Y		
207 +		CD player				Actuation Test		Y		
207 +		Hands-free kit (Telephone)	KML			Read ECU Information		Y		
207 +		Hands-free kit (Telephone)	KML			Read Fault Code		Y		
207 +		Hands-free kit (Telephone)	KML			Erase Fault Code		Y		
207 +		Hands-free kit (Telephone)	KML			Live Data		Y		
207 +		Hands-free kit (Telephone)	KML			Actuation Test		Y		
207 +		Hands-free kit (Telephone)	BOITIER NOMADE			Read ECU Information		Y		
207 +		Hands-free kit (Telephone)	BOITIER NOMADE			Read Fault Code		Y		
207 +		Hands-free kit (Telephone)	BOITIER NOMADE			Erase Fault Code		Y		
207 +		Hands-free kit (Telephone)	BOITIER NOMADE			Live Data		Y		
207 +		Hands-free kit (Telephone)	BOITIER NOMADE			Actuation Test		Y		
207 +		Anti-theft alarm	Alarm without anti-lift module			Read ECU Information		Y		
207 +		Anti-theft alarm	Alarm without anti-lift module			Read Fault Code		Y		
207 +		Anti-theft alarm	Alarm without anti-lift module			Erase Fault Code		Y		
207 +		Anti-theft alarm	Alarm without anti-lift module			Live Data		Y		
207 +		Anti-theft alarm	Alarm without anti-lift module			Actuation Test		Y		
207 +		Folding roof				Read ECU Information		Y		
207 +		Folding roof				Read Fault Code		Y		
207 +		Folding roof				Erase Fault Code		Y		
207 +		Folding roof				Live Data		Y		
207 +		Folding roof				Actuation Test		Y		

207 +		Driving school module				Read ECU Information		Y		
207 +		Driving school module				Actuation Test		Y		
207 +		High frequency receiver				Read ECU Information		Y		
207 +		High frequency receiver				Read Fault Code		Y		
207 +		High frequency receiver				Erase Fault Code		Y		
207 +		High frequency receiver				Live Data		Y		
207 +		Seat belts not fastened LED unit				Read ECU Information		Y		
207 +		Seat belts not fastened LED unit				Actuation Test		Y		
207 +		Service module				Read ECU Information		Y		
207 +		Service module				Read Fault Code		Y		
207 +		Service module				Erase Fault Code		Y		
207 +		Service module				Live Data		Y		
207 +		Service module				Actuation Test		Y		
207 +		Rain and brightness sensor				Read ECU Information		Y		
207 +		Rain and brightness sensor				Read Fault Code		Y		
207 +		Rain and brightness sensor				Erase Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Read ECU Information		Y		
208		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Read Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Erase Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Live Data		Y		
208		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Actuation Test		Y		
208		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Special Function	Configuration	Y		
208		Engine ECU	EDC17C10 BR2	9HP-DV6DTED-92 CV		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C10 BR2	9HJ-DV6DTEDM-90 CV		Read ECU Information		Y		
208		Engine ECU	EDC17C10 BR2	9HJ-DV6DTEDM-90 CV		Read Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	9HJ-DV6DTEDM-90 CV		Erase Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	9HJ-DV6DTEDM-90 CV		Live Data		Y		
208		Engine ECU	EDC17C10 BR2	9HJ-DV6DTEDM-90 CV		Actuation Test		Y		
208		Engine ECU	EDC17C10 BR2	9HJ-DV6DTEDM-90 CV		Special Function	Configuration	Y		
208		Engine ECU	EDC17C10 BR2	9HJ-DV6DTEDM-90 CV		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C10 BR2	9HK-DV6ETEDM-75 CV		Read ECU Information		Y		
208		Engine ECU	EDC17C10 BR2	9HK-DV6ETEDM-75 CV		Read Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	9HK-DV6ETEDM-75 CV		Erase Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	9HK-DV6ETEDM-75 CV		Live Data		Y		
208		Engine ECU	EDC17C10 BR2	9HK-DV6ETEDM-75 CV		Actuation Test		Y		
208		Engine ECU	EDC17C10 BR2	9HK-DV6ETEDM-75 CV		Special Function	Configuration	Y		
208		Engine ECU	EDC17C10 BR2	9HK-DV6ETEDM-75 CV		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
208		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Live Data		Y		
208		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
208		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
208		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C10 BR2	8HP-DV4CTED-70 CV		Read ECU Information		Y		
208		Engine ECU	EDC17C10 BR2	8HP-DV4CTED-70 CV		Read Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	8HP-DV4CTED-70 CV		Erase Fault Code		Y		
208		Engine ECU	EDC17C10 BR2	8HP-DV4CTED-70 CV		Live Data		Y		
208		Engine ECU	EDC17C10 BR2	8HP-DV4CTED-70 CV		Actuation Test		Y		
208		Engine ECU	EDC17C10 BR2	8HP-DV4CTED-70 CV		Special Function	Configuration	Y		
208		Engine ECU	EDC17C10 BR2	8HP-DV4CTED-70 CV		Special Function	Pack Repair	Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		

208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Live Data		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Actuation Test		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Read ECU Information		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Read Fault Code		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Erase Fault Code		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Live Data		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Actuation Test		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3C	8FR MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Read ECU Information		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Read Fault Code		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Erase Fault Code		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Live Data		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Actuation Test		Y		
208		Engine ECU	MEV17 4 2	MEV17 4 2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HD		Read ECU Information		Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HD		Read Fault Code		Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HD		Erase Fault Code		Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HD		Live Data		Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HD		Actuation Test		Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HD		Special Function	Configuration	Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HD		Special Function	Pack Repair	Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Read ECU Information		Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Read Fault Code		Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Erase Fault Code		Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Live Data		Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Actuation Test		Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Special Function	Configuration	Y		
208		Engine ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Special Function	Pack Repair	Y		
208		Engine ECU	V46	Yes		Read ECU Information		Y		
208		Engine ECU	V46	Yes		Read Fault Code		Y		
208		Engine ECU	V46	Yes		Erase Fault Code		Y		
208		Engine ECU	V46	Yes		Live Data		Y		
208		Engine ECU	V46	Yes		Actuation Test		Y		
208		Engine ECU	V46	Yes		Special Function	Pack Repair	Y		
208		Engine ECU	V46	No	ZMZ	Read ECU Information		Y		
208		Engine ECU	V46	No	ZMZ	Read Fault Code		Y		
208		Engine ECU	V46	No	ZMZ	Erase Fault Code		Y		
208		Engine ECU	V46	No	ZMZ	Live Data		Y		
208		Engine ECU	V46	No	ZMZ	Actuation Test		Y		
208		Engine ECU	V46	No	ZMZ	Special Function	Pack Repair	Y		
208		Engine ECU	V46	No	HMW	Read ECU Information		Y		
208		Engine ECU	V46	No	HMW	Read Fault Code		Y		
208		Engine ECU	V46	No	HMW	Erase Fault Code		Y		
208		Engine ECU	V46	No	HMW	Live Data		Y		

208		Engine ECU	V46	No	HMW	Actuation Test		Y		
208		Engine ECU	V46	No	HMW	Special Function	Pack Repair	Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Read ECU Information		Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Read Fault Code		Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Erase Fault Code		Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Live Data		Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Actuation Test		Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Special Function	Replacement parts	Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Special Function	Initialising the autoadaptives	Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Read ECU Information		Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Read Fault Code		Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Erase Fault Code		Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Live Data		Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Actuation Test		Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Special Function	Replacement parts	Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Special Function	Initialising the autoadaptives	Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Read ECU Information		Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Read Fault Code		Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Erase Fault Code		Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Live Data		Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Actuation Test		Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Special Function	Initialising the autoadaptives	Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Special Function	Replacement parts	Y		
208		Engine ECU	VD46	Engine type 42 : EB2DTS engine with 5-speed manual gearbox		Read ECU Information		Y		
208		Engine ECU	VD46	Engine type 42 : EB2DTS engine with 5-speed manual gearbox		Read Fault Code		Y		
208		Engine ECU	VD46	Engine type 42 : EB2DTS engine with 5-speed manual gearbox		Erase Fault Code		Y		
208		Engine ECU	VD46	Engine type 42 : EB2DTS engine with 5-speed manual gearbox		Live Data		Y		
208		Engine ECU	VD46	Engine type 42 : EB2DTS engine with 5-speed manual gearbox		Actuation Test		Y		
208		Engine ECU	VD46	Engine type 42 : EB2DTS engine with 5-speed manual gearbox		Special Function	Pack Repair	Y		
208		Engine ECU	VD46	Engine type 44 : EB2DTS engine with 6-speed manual gearbox		Read ECU Information		Y		
208		Engine ECU	VD46	Engine type 44 : EB2DTS engine with 6-speed manual gearbox		Read Fault Code		Y		
208		Engine ECU	VD46	Engine type 44 : EB2DTS engine with 6-speed manual gearbox		Erase Fault Code		Y		
208		Engine ECU	VD46	Engine type 44 : EB2DTS engine with 6-speed manual gearbox		Live Data		Y		
208		Engine ECU	VD46	Engine type 44 : EB2DTS engine with 6-speed manual gearbox		Actuation Test		Y		
208		Engine ECU	VD46	Engine type 44 : EB2DTS engine with 6-speed manual gearbox		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C60	Yes		Read ECU Information		Y		
208		Engine ECU	EDC17C60	Yes		Read Fault Code		Y		
208		Engine ECU	EDC17C60	Yes		Erase Fault Code		Y		
208		Engine ECU	EDC17C60	Yes		Live Data		Y		
208		Engine ECU	EDC17C60	Yes		Actuation Test		Y		
208		Engine ECU	EDC17C60	Yes		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Read ECU Information		Y		

208		Engine ECU	EDC17C60	No	BHZ/BHX	Read Fault Code		Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Erase Fault Code		Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Live Data		Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Actuation Test		Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C60	No	BHY	Read ECU Information		Y		
208		Engine ECU	EDC17C60	No	BHY	Read Fault Code		Y		
208		Engine ECU	EDC17C60	No	BHY	Erase Fault Code		Y		
208		Engine ECU	EDC17C60	No	BHY	Live Data		Y		
208		Engine ECU	EDC17C60	No	BHY	Actuation Test		Y		
208		Engine ECU	EDC17C60	No	BHY	Special Function	Pack Repair	Y		
208		Engine ECU	MEVD17 4 4			Read ECU Information		Y		
208		Engine ECU	MEVD17 4 4			Read Fault Code		Y		
208		Engine ECU	MEVD17 4 4			Erase Fault Code		Y		
208		Engine ECU	MEVD17 4 4			Live Data		Y		
208		Engine ECU	MEVD17 4 4			Actuation Test		Y		
208		Engine ECU	MEVD17 4 4			Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
208		Engine ECU	MEVD17 4 4			Special Function	Work on the ancillaries battery	Y		
208		Engine ECU	MEVD17 4 4			Special Function	Initialisation of the autoadaptive values	Y		
208		Engine ECU	MEVD17 4 4			Special Function	Replacement parts	Y		
208		gearbox	CFC300P			Read ECU Information		Y		
208		gearbox	CFC300P			Read Fault Code		Y		
208		gearbox	CFC300P			Erase Fault Code		Y		
208		gearbox	CFC300P			Live Data		Y		
208		gearbox	CFC300P			Actuation Test		Y		
208		gearbox	CFC300P			Special Function	Replacement parts	Y		
208		gearbox	BVMP			Read ECU Information		Y		
208		gearbox	BVMP			Read Fault Code		Y		
208		gearbox	BVMP			Erase Fault Code		Y		
208		gearbox	BVMP			Live Data		Y		
208		gearbox	BVMP			Actuation Test		Y		
208		gearbox	BVA AL4			Read ECU Information		Y		
208		gearbox	BVA AL4			Read Fault Code		Y		
208		gearbox	BVA AL4			Erase Fault Code		Y		
208		gearbox	BVA AL4			Live Data		Y		
208		gearbox	BVA AL4			Actuation Test		Y		
208		gearbox	BVA AL4			Special Function	Configuration	Y		
208		gearbox	BVA AL4			Special Function	Pack Repair	Y		
208		gearbox	MAPS UDS			Read ECU Information		Y		
208		gearbox	MAPS UDS			Read Fault Code		Y		
208		gearbox	MAPS UDS			Erase Fault Code		Y		
208		gearbox	MAPS UDS			Live Data		Y		
208		gearbox	MAPS UDS			Actuation Test		Y		
208		gearbox	MAPS UDS			Special Function	Setting of the actuator	Y		
208		gearbox	MAPS UDS			Special Function	Programming	Y		
208		gearbox	MAPS UDS			Special Function	Replacement parts	Y		
208		ABS or ESP ECU	ABSMK100			Read ECU Information		Y		
208		ABS or ESP ECU	ABSMK100			Read Fault Code		Y		
208		ABS or ESP ECU	ABSMK100			Erase Fault Code		Y		
208		ABS or ESP ECU	ABSMK100			Live Data		Y		
208		ABS or ESP ECU	ABSMK100			Actuation Test		Y		
208		ABS or ESP ECU	ESPMK100			Read ECU Information		Y		
208		ABS or ESP ECU	ESPMK100			Read Fault Code		Y		
208		ABS or ESP ECU	ESPMK100			Erase Fault Code		Y		
208		ABS or ESP ECU	ESPMK100			Live Data		Y		
208		ABS or ESP ECU	ESPMK100			Actuation Test		Y		
208		Air bag				Read ECU Information		Y		
208		Air bag				Read Fault Code		Y		
208		Air bag				Erase Fault Code		Y		
208		Air bag				Live Data		Y		
208		Air bag				Special Function	Pack Repair	Y		
208		Electric power steering				Read ECU Information		Y		
208		Electric power steering				Read Fault Code		Y		

208		Electric power steering				Erase Fault Code		Y		
208		Electric power steering				Live Data		Y		
208		Trailer relay unit				Read ECU Information		Y		
208		Trailer relay unit				Read Fault Code		Y		
208		Trailer relay unit				Erase Fault Code		Y		
208		Trailer relay unit				Live Data		Y		
208		Trailer relay unit				Actuation Test		Y		
208		Parking aid	4 parking assistance			Read ECU Information		Y		
208		Parking aid	4 parking assistance			Read Fault Code		Y		
208		Parking aid	4 parking assistance			Erase Fault Code		Y		
208		Parking aid	4 parking assistance			Live Data		Y		
208		Parking aid	8 parking assistance			Read ECU Information		Y		
208		Parking aid	8 parking assistance			Read Fault Code		Y		
208		Parking aid	8 parking assistance			Erase Fault Code		Y		
208		Parking aid	8 parking assistance			Live Data		Y		
208		Parking aid	10 parking assistance			Read ECU Information		Y		
208		Parking aid	10 parking assistance			Read Fault Code		Y		
208		Parking aid	10 parking assistance			Erase Fault Code		Y		
208		Parking aid	10 parking assistance			Live Data		Y		
208		Air conditioning				Read ECU Information		Y		
208		Air conditioning				Read Fault Code		Y		
208		Air conditioning				Erase Fault Code		Y		
208		Air conditioning				Live Data		Y		
208		Air conditioning				Actuation Test		Y		
208		Radio				Read ECU Information		Y		
208		Radio				Read Fault Code		Y		
208		Radio				Erase Fault Code		Y		
208		Radio				Live Data		Y		
208		Radio				Actuation Test		Y		
208		Rain and brightness sensor				Read ECU Information		Y		
208		Rain and brightness sensor				Read Fault Code		Y		
208		Rain and brightness sensor				Erase Fault Code		Y		
208		Rain and brightness sensor				Live Data		Y		
208		Independent telematic unit	BTA			Read ECU Information		Y		
208		Independent telematic unit	BTA			Read Fault Code		Y		
208		Independent telematic unit	BTA			Erase Fault Code		Y		
208		Independent telematic unit	BTA			Live Data		Y		
208		Independent telematic unit	BTA			Actuation Test		Y		
208		Instrument panel				Read ECU Information		Y		
208		Instrument panel				Read Fault Code		Y		
208		Instrument panel				Erase Fault Code		Y		
208		Instrument panel				Live Data		Y		
208		Instrument panel				Actuation Test		Y		
208		audio amplifier				Read ECU Information		Y		
208		audio amplifier				Read Fault Code		Y		
208		audio amplifier				Erase Fault Code		Y		
208		audio amplifier				Actuation Test		Y		
208		Matrix screen integral to the instrument panel	Yes	Colour matrix screen		Read ECU Information		Y		
208		Matrix screen integral to the instrument panel	Yes	Colour matrix screen		Read Fault Code		Y		
208		Matrix screen integral to the instrument panel	Yes	Colour matrix screen		Erase Fault Code		Y		
208		Matrix screen integral to the instrument panel	Yes	Colour matrix screen		Actuation Test		Y		
208		Matrix screen integral to the instrument panel	No	Monochrome matrix screen		Read ECU Information		Y		
208		Matrix screen integral to the instrument panel	No	Monochrome matrix screen		Read Fault Code		Y		
208		Matrix screen integral to the instrument panel	No	Monochrome matrix screen		Erase Fault Code		Y		
208		Matrix screen integral to the instrument panel	No	Monochrome matrix screen		Actuation Test		Y		
208		External CD player				Read ECU Information		Y		
208		External CD player				Read Fault Code		Y		
208		External CD player				Erase Fault Code		Y		

208		External CD player				Live Data		Y		
208		External CD player				Actuation Test		Y		
208		Steering wheel with integral controls (VCI)				Read ECU Information		Y		
208		Steering wheel with integral controls (VCI)				Read Fault Code		Y		
208		Steering wheel with integral controls (VCI)				Erase Fault Code		Y		
208		Steering wheel with integral controls (VCI)				Live Data		Y		
208		Steering wheel with integral controls (VCI)				Actuation Test		Y		
208		Central voltage retention device	DMTC			Read ECU Information		Y		
208		Central voltage retention device	DMTR			Read ECU Information		Y		
208		Central voltage retention device	DMTR			Read Fault Code		Y		
208		Central voltage retention device	DMTR			Erase Fault Code		Y		
208		Battery charge status unit				Read ECU Information		Y		
208		Battery charge status unit				Live Data		Y		
208		Telematics	SMEG			Read ECU Information		Y		
208		Telematics	SMEG			Read Fault Code		Y		
208		Telematics	SMEG			Erase Fault Code		Y		
208		Telematics	SMEG			Live Data		Y		
208		Telematics	SMEG			Actuation Test		Y		
208		Telematics	SMEG PLUS			Read ECU Information		Y		
208		Telematics	SMEG PLUS			Read Fault Code		Y		
208		Telematics	SMEG PLUS			Erase Fault Code		Y		
208		Telematics	SMEG PLUS			Live Data		Y		
208		Telematics	SMEG PLUS			Actuation Test		Y		
208		Siren				Read ECU Information		Y		
208		Siren				Read Fault Code		Y		
208		Siren				Erase Fault Code		Y		
208		Siren				Live Data		Y		
208		Siren				Actuation Test		Y		
208		Anti-theft alarm				Read ECU Information		Y		
208		Anti-theft alarm				Read Fault Code		Y		
208		Anti-theft alarm				Erase Fault Code		Y		
208		Anti-theft alarm				Live Data		Y		
208		Anti-theft alarm				Actuation Test		Y		
208		Multiplexed additive pump				Read ECU Information		Y		
208		Multiplexed additive pump				Read Fault Code		Y		
208		Multiplexed additive pump				Erase Fault Code		Y		
208		Multiplexed additive pump				Live Data		Y		
208		Multiplexed additive pump				Actuation Test		Y		
208		Switch module under the steering wheel(Top of				Read ECU Information		Y		
208		Switch module under the steering wheel(Top of				Read Fault Code		Y		
208		Switch module under the steering wheel(Top of				Erase Fault Code		Y		
208		Switch module under the steering wheel(Top of				Live Data		Y		
208		Switch module under the steering wheel(Top of				Actuation Test		Y		
208		Driving school module				Read ECU Information		Y		
208		Driving school module				Actuation Test		Y		
208		Lighting relay unit				Read ECU Information		Y		
208		Lighting relay unit				Read Fault Code		Y		
208		Lighting relay unit				Erase Fault Code		Y		
208		Lighting relay unit				Live Data		Y		
208		Lighting relay unit				Actuation Test		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5_NFP		Read ECU Information		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5_NFP		Read Fault Code		Y		

208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFP		Erase Fault Code		Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFP		Live Data		Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFP		Actuation Test		Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFP		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFP		Special Function	Replacement parts	Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFN		Read ECU Information		Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFN		Read Fault Code		Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFN		Erase Fault Code		Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFN		Live Data		Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFN		Actuation Test		Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFN		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	ME749 EC5	ME749 EC5 NFN		Special Function	Replacement parts	Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Read ECU Information		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Read Fault Code		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Erase Fault Code		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Live Data		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Actuation Test		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Special Function	Replacement parts	Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Read ECU Information		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Read Fault Code		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Erase Fault Code		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Live Data		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Actuation Test		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Special Function	Replacement parts	Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Read ECU Information		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Read Fault Code		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Erase Fault Code		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Live Data		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Actuation Test		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Special Function	Replacement parts	Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Read ECU Information		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Read Fault Code		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Erase Fault Code		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Live Data		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Actuation Test		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Special Function	Replacement parts	Y		
208(Ai91)		gearbox				Read ECU Information		Y		
208(Ai91)		gearbox				Read Fault Code		Y		
208(Ai91)		gearbox				Erase Fault Code		Y		
208(Ai91)		gearbox				Live Data		Y		
208(Ai91)		gearbox				Actuation Test		Y		
208(Ai91)		gearbox				Special Function	Configuration	Y		
208(Ai91)		gearbox				Special Function	Pack Repair	Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Read ECU Information		Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Read Fault Code		Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Erase Fault Code		Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Live Data		Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Actuation Test		Y		
208(Ai91)		ABS or ESP ECU	ESPMK100			Read ECU Information		Y		
208(Ai91)		ABS or ESP ECU	ESPMK100			Read Fault Code		Y		
208(Ai91)		ABS or ESP ECU	ESPMK100			Erase Fault Code		Y		
208(Ai91)		ABS or ESP ECU	ESPMK100			Live Data		Y		
208(Ai91)		ABS or ESP ECU	ESPMK100			Actuation Test		Y		
208(Ai91)		Air bag				Read ECU Information		Y		
208(Ai91)		Air bag				Read Fault Code		Y		
208(Ai91)		Air bag				Erase Fault Code		Y		
208(Ai91)		Air bag				Live Data		Y		
208(Ai91)		Air bag				Special Function	Pack Repair	Y		
208(Ai91)		Parking aid	parking assistance			Read ECU Information		Y		
208(Ai91)		Parking aid	parking assistance			Read Fault Code		Y		
208(Ai91)		Parking aid	parking assistance			Erase Fault Code		Y		
208(Ai91)		Parking aid	parking assistance			Live Data		Y		

208(Ai91)		External CD player				Read ECU Information		Y		
208(Ai91)		External CD player				Read Fault Code		Y		
208(Ai91)		External CD player				Erase Fault Code		Y		
208(Ai91)		External CD player				Live Data		Y		
208(Ai91)		External CD player				Actuation Test		Y		
208(Ai91)		Telematics	SMEG			Read ECU Information		Y		
208(Ai91)		Telematics	SMEG			Read Fault Code		Y		
208(Ai91)		Telematics	SMEG			Erase Fault Code		Y		
208(Ai91)		Telematics	SMEG			Live Data		Y		
208(Ai91)		Telematics	SMEG			Actuation Test		Y		
208(Ai91)		Telematics	SMEG PLUS			Read ECU Information		Y		
208(Ai91)		Telematics	SMEG PLUS			Read Fault Code		Y		
208(Ai91)		Telematics	SMEG PLUS			Erase Fault Code		Y		
208(Ai91)		Telematics	SMEG PLUS			Live Data		Y		
208(Ai91)		Telematics	SMEG PLUS			Actuation Test		Y		
208(Ai91)		Switch module under the steering wheel(Top of				Read ECU Information		Y		
208(Ai91)		Switch module under the steering wheel(Top of				Read Fault Code		Y		
208(Ai91)		Switch module under the steering wheel(Top of				Erase Fault Code		Y		
208(Ai91)		Switch module under the steering wheel(Top of				Live Data		Y		
208(Ai91)		Switch module under the steering wheel(Top of				Actuation Test		Y		
208(Ai91)		Air conditioning				Read ECU Information		Y		
208(Ai91)		Air conditioning				Read Fault Code		Y		
208(Ai91)		Air conditioning				Erase Fault Code		Y		
208(Ai91)		Air conditioning				Live Data		Y		
208(Ai91)		Air conditioning				Actuation Test		Y		
208(Ai91)		Radio				Read ECU Information		Y		
208(Ai91)		Radio				Read Fault Code		Y		
208(Ai91)		Radio				Erase Fault Code		Y		
208(Ai91)		Radio				Live Data		Y		
208(Ai91)		Radio				Actuation Test		Y		
208(Ai91)		Rain and brightness sensor				Read ECU Information		Y		
208(Ai91)		Rain and brightness sensor				Read Fault Code		Y		
208(Ai91)		Rain and brightness sensor				Erase Fault Code		Y		
208(Ai91)		Rain and brightness sensor				Live Data		Y		
208(Ai91)		Electric power steering				Read ECU Information		Y		
208(Ai91)		Electric power steering				Read Fault Code		Y		
208(Ai91)		Electric power steering				Erase Fault Code		Y		
208(Ai91)		Electric power steering				Live Data		Y		
208(Ai91)		Steering wheel with integral controls (VCI)				Read ECU Information		Y		
208(Ai91)		Steering wheel with integral controls (VCI)				Read Fault Code		Y		
208(Ai91)		Steering wheel with integral controls (VCI)				Erase Fault Code		Y		
208(Ai91)		Steering wheel with integral controls (VCI)				Live Data		Y		
208(Ai91)		Steering wheel with integral controls (VCI)				Actuation Test		Y		
208(Ai91)		Instrument panel				Read ECU Information		Y		
208(Ai91)		Instrument panel				Read Fault Code		Y		
208(Ai91)		Instrument panel				Erase Fault Code		Y		
208(Ai91)		Instrument panel				Live Data		Y		
208(Ai91)		Instrument panel				Actuation Test		Y		
208(Ai91)		Siren				Read ECU Information		Y		
208(Ai91)		Siren				Read Fault Code		Y		
208(Ai91)		Siren				Erase Fault Code		Y		
208(Ai91)		Siren				Live Data		Y		
208(Ai91)		Siren				Actuation Test		Y		
208(Ai91)		Anti-theft alarm				Read ECU Information		Y		
208(Ai91)		Anti-theft alarm				Read Fault Code		Y		
208(Ai91)		Anti-theft alarm				Erase Fault Code		Y		

208(Ai91)		Anti-theft alarm				Live Data		Y		
208(Ai91)		Anti-theft alarm				Actuation Test		Y		
208(Ai91)		Stolen vehicle location control unit				Read ECU Information		Y		
208(Ai91)		Stolen vehicle location control unit				Read Fault Code		Y		
208(Ai91)		Stolen vehicle location control unit				Erase Fault Code		Y		
208(Ai91)		Stolen vehicle location control unit				Live Data		Y		
208(Ai91)		Stolen vehicle location control unit				Actuation Test		Y		
301		BSI(Built-in Systems				Read ECU Information		Y		
301		Engine management ECU	EDC17C10 BR2	9HP - DV6DTED -90 CV		Read ECU Information		Y		
301		Engine management ECU	EDC17C10 BR2	9HP - DV6DTED -90 CV		Read Fault Code		Y		
301		Engine management ECU	EDC17C10 BR2	9HP - DV6DTED -90 CV		Erase Fault Code		Y		
301		Engine management ECU	EDC17C10 BR2	9HP - DV6DTED -90 CV		Live Data		Y		
301		Engine management ECU	EDC17C10 BR2	9HP - DV6DTED -90 CV		Actuation Test		Y		
301		Engine management ECU	EDC17C10 BR2	9HP - DV6DTED -90 CV		Special Function	Configuration	Y		
301		Engine management ECU	EDC17C10 BR2	9HP - DV6DTED -90 CV		Special Function	Pack Repair	Y		
301		Engine management ECU	EDC17C10 BR2	9HF - DV6DTED -89 CV		Read ECU Information		Y		
301		Engine management ECU	EDC17C10 BR2	9HF - DV6DTED -89 CV		Read Fault Code		Y		
301		Engine management ECU	EDC17C10 BR2	9HF - DV6DTED -89 CV		Erase Fault Code		Y		
301		Engine management ECU	EDC17C10 BR2	9HF - DV6DTED -89 CV		Live Data		Y		
301		Engine management ECU	EDC17C10 BR2	9HF - DV6DTED -89 CV		Actuation Test		Y		
301		Engine management ECU	EDC17C10 BR2	9HF - DV6DTED -89 CV		Special Function	Configuration	Y		
301		Engine management ECU	EDC17C10 BR2	9HF - DV6DTED -89 CV		Special Function	Pack Repair	Y		
301		Engine management ECU	EDC17C10 BR2	9HJ - DV6DTEM -90 CV		Read ECU Information		Y		
301		Engine management ECU	EDC17C10 BR2	9HJ - DV6DTEM -90 CV		Read Fault Code		Y		
301		Engine management ECU	EDC17C10 BR2	9HJ - DV6DTEM -90 CV		Erase Fault Code		Y		
301		Engine management ECU	EDC17C10 BR2	9HJ - DV6DTEM -90 CV		Live Data		Y		
301		Engine management ECU	EDC17C10 BR2	9HJ - DV6DTEM -90 CV		Actuation Test		Y		
301		Engine management ECU	EDC17C10 BR2	9HJ - DV6DTEM -90 CV		Special Function	Configuration	Y		
301		Engine management ECU	EDC17C10 BR2	9HJ - DV6DTEM -90 CV		Special Function	Pack Repair	Y		
301		Engine management ECU	ME745 EC5			Read ECU Information		Y		
301		Engine management ECU	ME745 EC5			Read Fault Code		Y		
301		Engine management ECU	ME745 EC5			Erase Fault Code		Y		
301		Engine management ECU	ME745 EC5			Live Data		Y		
301		Engine management ECU	ME745 EC5			Actuation Test		Y		
301		Engine management ECU	ME745 EC5			Special Function	Configuration	Y		
301		Engine management ECU	ME745 EC5			Special Function	Pack Repair	Y		
301		Engine management ECU	V46 21	V46 21 NFP		Read ECU Information		Y		
301		Engine management ECU	V46 21	V46 21 NFP		Read Fault Code		Y		
301		Engine management ECU	V46 21	V46 21 NFP		Erase Fault Code		Y		
301		Engine management ECU	V46 21	V46 21 NFP		Live Data		Y		
301		Engine management ECU	V46 21	V46 21 NFP		Actuation Test		Y		
301		Engine management ECU	V46 21	V46 21 NFP		Special Function	Initialisation of the autoadaptive values	Y		
301		Engine management ECU	V46 21	V46 21 NFP		Special Function	Replacement parts	Y		
301		Engine management ECU	V46			Read ECU Information		Y		
301		Engine management ECU	V46			Read Fault Code		Y		
301		Engine management ECU	V46			Erase Fault Code		Y		
301		Engine management ECU	V46			Live Data		Y		
301		Engine management ECU	V46			Actuation Test		Y		
301		Engine management ECU	V46			Special Function	Pack Repair	Y		
301		Automatic gearbox or controlled manual gearbox	BVA AT8			Read ECU Information		Y		
301		Automatic gearbox or controlled manual gearbox	BVA AT8			Read Fault Code		Y		
301		Automatic gearbox or controlled manual gearbox	BVA AT8			Erase Fault Code		Y		
301		Automatic gearbox or controlled manual gearbox	BVA AT8			Live Data		Y		
301		Automatic gearbox or controlled manual gearbox	BVA AT8			Actuation Test		Y		

301		Automatic gearbox or controlled manual gearbox	BVA AT8			Special Function	Configuration	Y		
301		Automatic gearbox or controlled manual gearbox	BVA AT8			Special Function	Pack Repair	Y		
301		Automatic gearbox or controlled manual gearbox	MAPS UDS			Read ECU Information		Y		
301		Automatic gearbox or controlled manual gearbox	MAPS UDS			Read Fault Code		Y		
301		Automatic gearbox or controlled manual gearbox	MAPS UDS			Erase Fault Code		Y		
301		Automatic gearbox or controlled manual gearbox	MAPS UDS			Actuation Test		Y		
301		Automatic gearbox or controlled manual gearbox	MAPS UDS			Special Function	Setting of the actuator	Y		
301		Automatic gearbox or controlled manual gearbox	MAPS UDS			Special Function	Programming	Y		
301		Automatic gearbox or controlled manual gearbox	MAPS UDS			Special Function	Replacement parts	Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Read ECU Information		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Read Fault Code		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Erase Fault Code		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Live Data		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Actuation Test		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Special Function	Configuration	Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Special Function	Pack Repair	Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK100			Read ECU Information		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK100			Read Fault Code		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK100			Erase Fault Code		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK100			Live Data		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK100			Actuation Test		Y		
301		Air bags and pre-tensioners control unit				Read ECU Information		Y		
301		Air bags and pre-tensioners control unit				Read Fault Code		Y		
301		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
301		Air bags and pre-tensioners control unit				Live Data		Y		
301		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
301		Multifunction screen	EMF A UDS			Read ECU Information		Y		
301		Multifunction screen	EMF A UDS			Read Fault Code		Y		

301		Multifunction screen	EMF A UDS			Erase Fault Code		Y		
301		Multifunction screen	EMF A UDS			Actuation Test		Y		
301		Multifunction screen	EMF C UDS			Read ECU Information		Y		
301		Multifunction screen	EMF C UDS			Read Fault Code		Y		
301		Multifunction screen	EMF C UDS			Erase Fault Code		Y		
301		Multifunction screen	EMF C UDS			Actuation Test		Y		
301		Controls under the steering wheel				Read ECU Information		Y		
301		Controls under the steering wheel				Read Fault Code		Y		
301		Controls under the steering wheel				Erase Fault Code		Y		
301		Controls under the steering wheel				Live Data		Y		
301		Controls under the steering wheel				Actuation Test		Y		
301		Instrument panel				Read ECU Information		Y		
301		Instrument panel				Read Fault Code		Y		
301		Instrument panel				Erase Fault Code		Y		
301		Instrument panel				Live Data		Y		
301		Instrument panel				Actuation Test		Y		
301		Parking assistance				Read ECU Information		Y		
301		Parking assistance				Read Fault Code		Y		
301		Parking assistance				Erase Fault Code		Y		
301		Parking assistance				Live Data		Y		
301		Radio	RDE			Read ECU Information		Y		
301		Radio	RDE			Read Fault Code		Y		
301		Radio	RDE			Erase Fault Code		Y		
301		Radio	RDE			Live Data		Y		
301		Radio	RDE			Actuation Test		Y		
301		Radio	RD45			Read ECU Information		Y		
301		Radio	RD45			Read Fault Code		Y		
301		Radio	RD45			Erase Fault Code		Y		
301		Radio	RD45			Live Data		Y		
301		Radio	RD45			Actuation Test		Y		
301		Power steering				Read ECU Information		Y		
301		Power steering				Read Fault Code		Y		
301		Power steering				Erase Fault Code		Y		
301		Power steering				Live Data		Y		
301		Trailer relay unit				Read ECU Information		Y		
301		Trailer relay unit				Read Fault Code		Y		
301		Trailer relay unit				Erase Fault Code		Y		
301		Trailer relay unit				Live Data		Y		
301		Trailer relay unit				Actuation Test		Y		
301		Siren				Read ECU Information		Y		
301		Siren				Read Fault Code		Y		
301		Siren				Erase Fault Code		Y		
301		Siren				Live Data		Y		
301		Siren				Actuation Test		Y		
301		Diesel additive function				Read ECU Information		Y		
301		Diesel additive function				Read Fault Code		Y		
301		Diesel additive function				Erase Fault Code		Y		
301		Diesel additive function				Live Data		Y		
301		Diesel additive function				Actuation Test		Y		
306		Air bag and seat belt				Read ECU Information		Y		
306		Air bag and seat belt				Read Fault Code		Y		
306		Air bag and seat belt				Erase Fault Code		Y		
306		Active safety	Anti-lock brakes BOSCH			Read ECU Information		Y		
306		Active safety	Anti-lock brakes BOSCH			Read Fault Code		Y		
306		Active safety	Anti-lock brakes BOSCH			Erase Fault Code		Y		
306		Active safety	Anti-lock brakes BOSCH			Live Data		Y		
306		Active safety	Anti-lock brakes BOSCH			Actuation Test		Y		
306		Engine/ automatic gearbox	All models	HDY BOSCH MA3.1		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDY BOSCH MA3.1		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDY BOSCH MA3.1		Actuation Test		Y		
306		Engine/ automatic gearbox	All models	HDY BOSCH MA3.1		Special Function	Injection ECU initialisation	Y		

306		Engine/ automatic gearbox	All models	HDY MAGNETI MARELLI MA3.1		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDY MAGNETI MARELLI MA3.1		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDY MAGNETI MARELLI MA3.1		Special Function	Injection ECU initialisation	Y		
306		Engine/ automatic gearbox	All models	HDZ BOSCH MA3.1		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDZ BOSCH MA3.1		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDZ BOSCH MA3.1		Actuation Test		Y		
306		Engine/ automatic gearbox	All models	HDZ BOSCH MA3.1		Special Function	Injection ECU initialisation	Y		
306		Engine/ automatic gearbox	All models	HDZ MAGNETI MARELLI MA3.1		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDZ MAGNETI MARELLI MA3.1		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDZ MAGNETI MARELLI MA3.1		Special Function	Injection ECU initialisation	Y		
306		Engine/ automatic gearbox	All models	KFX MM1AP		Read ECU Information		Y		
306		Engine/ automatic gearbox	All models	KFX MM1AP		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	KFX MM1AP		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	KFX MM1AP		Live Data		Y		
306		Engine/ automatic gearbox	All models	KFX MM1AP		Special Function	Injection ECU initialisation	Y		
306		Engine/ automatic gearbox	All models	NFZ BOSCH MP5.2		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	NFZ BOSCH MP5.2		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	NFZ BOSCH MP5.2		Live Data		Y		
306		Engine/ automatic gearbox	All models	NFZ BOSCH MP5.2		Special Function	Injection ECU initialisation	Y		
306		Engine/ automatic gearbox	All models	NFL BOSCH MP5.2		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	NFL BOSCH MP5.2		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	NFL BOSCH MP5.2		Live Data		Y		
306		Engine/ automatic gearbox	All models	NFL BOSCH MP5.2		Special Function	Injection ECU initialisation	Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Read ECU Information		Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Live Data		Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Actuation Test		Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Special Function	Injection ECU initialisation	Y		
306R		engines	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
306R		engines	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
306R		engines	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
306R		engines	Petrol	KFW SAGEM S2000		Live Data		Y		
306R		engines	Petrol	KFW SAGEM S2000		Actuation Test		Y		
306R		engines	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
306R		engines	Petrol	K6D SAGEM S2000		Read ECU Information		Y		
306R		engines	Petrol	K6D SAGEM S2000		Read Fault Code		Y		
306R		engines	Petrol	K6D SAGEM S2000		Erase Fault Code		Y		
306R		engines	Petrol	K6D SAGEM S2000		Live Data		Y		
306R		engines	Petrol	K6D SAGEM S2000		Actuation Test		Y		
306R		engines	Petrol	K6D SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
306R		engines	Petrol	KFX BOSCH MP7.3		Read ECU Information		Y		
306R		engines	Petrol	KFX BOSCH MP7.3		Read Fault Code		Y		
306R		engines	Petrol	KFX BOSCH MP7.3		Erase Fault Code		Y		
306R		engines	Petrol	KFX BOSCH MP7.3		Live Data		Y		
306R		engines	Petrol	KFX BOSCH MP7.3		Actuation Test		Y		
306R		engines	Petrol	KFX BOSCH MP7.3		Special Function	Injection ECU initialisation	Y		
306R		engines	Petrol	KFX MM1AP		Read ECU Information		Y		
306R		engines	Petrol	KFX MM1AP		Read Fault Code		Y		
306R		engines	Petrol	KFX MM1AP		Erase Fault Code		Y		
306R		engines	Petrol	KFX MM1AP		Live Data		Y		
306R		engines	Petrol	KFX MM1AP		Actuation Test		Y		
306R		engines	Petrol	KFX MM1AP		Special Function	Ignition advance setting	Y		
306R		engines	Petrol	KFX MM1AP		Special Function	Injection ECU initialisation	Y		
306R		engines	Petrol	KFX SAGEM SL 96		Read ECU Information		Y		
306R		engines	Petrol	KFX SAGEM SL 96		Read Fault Code		Y		
306R		engines	Petrol	KFX SAGEM SL 96		Erase Fault Code		Y		
306R		engines	Petrol	KFX SAGEM SL 96		Live Data		Y		
306R		engines	Petrol	KFX SAGEM SL 96		Actuation Test		Y		
306R		engines	Petrol	LFY BOSCH MP7.3		Read ECU Information		Y		
306R		engines	Petrol	LFY BOSCH MP7.3		Read Fault Code		Y		
306R		engines	Petrol	LFY BOSCH MP7.3		Erase Fault Code		Y		
306R		engines	Petrol	LFY BOSCH MP7.3		Live Data		Y		
306R		engines	Petrol	LFY BOSCH MP7.3		Actuation Test		Y		
306R		engines	Petrol	LFY BOSCH MP7.3		Special Function	Injection ECU initialisation	Y		
306R		engines	Petrol	LFY SAGEM SL 96		Read ECU Information		Y		

306R		engines	Petrol	LFY SAGEM SL 96		Read Fault Code		Y		
306R		engines	Petrol	LFY SAGEM SL 96		Erase Fault Code		Y		
306R		engines	Petrol	LFY SAGEM SL 96		Live Data		Y		
306R		engines	Petrol	LFY SAGEM SL 96		Actuation Test		Y		
306R		engines	Petrol	NFT BOSCH M7.4.4		Read ECU Information		Y		
306R		engines	Petrol	NFT BOSCH M7.4.4		Read Fault Code		Y		
306R		engines	Petrol	NFT BOSCH M7.4.4		Erase Fault Code		Y		
306R		engines	Petrol	NFT BOSCH M7.4.4		Live Data		Y		
306R		engines	Petrol	NFT BOSCH M7.4.4		Special Function	Initialising the autoadaptives	Y		
306R		engines	Petrol	NFV BOSCH M7.4.4		Read ECU Information		Y		
306R		engines	Petrol	NFV BOSCH M7.4.4		Read Fault Code		Y		
306R		engines	Petrol	NFV BOSCH M7.4.4		Erase Fault Code		Y		
306R		engines	Petrol	NFV BOSCH M7.4.4		Live Data		Y		
306R		engines	Petrol	NFV BOSCH M7.4.4		Special Function	Initialising the autoadaptives	Y		
306R		engines	Petrol	NFZ BOSCH MP5.2		Read Fault Code		Y		
306R		engines	Petrol	NFZ BOSCH MP5.2		Erase Fault Code		Y		
306R		engines	Petrol	NFZ BOSCH MP5.2		Live Data		Y		
306R		engines	Petrol	NFZ BOSCH MP7.2		Read ECU Information		Y		
306R		engines	Petrol	NFZ BOSCH MP7.2		Read Fault Code		Y		
306R		engines	Petrol	NFZ BOSCH MP7.2		Erase Fault Code		Y		
306R		engines	Petrol	NFZ BOSCH MP7.2		Live Data		Y		
306R		engines	Petrol	NFZ BOSCH MP7.2		Actuation Test		Y		
306R		engines	Petrol	NFZ BOSCH MP7.2		Special Function	Injection ECU initialisation	Y		
306R		engines	Petrol	R6E BOSCH MP5.2		Read Fault Code		Y		
306R		engines	Petrol	R6E BOSCH MP5.2		Erase Fault Code		Y		
306R		engines	Petrol	R6E BOSCH MP5.2		Live Data		Y		
306R		engines	Petrol	RFS MM1AP		Read ECU Information		Y		
306R		engines	Petrol	RFS MM1AP		Read Fault Code		Y		
306R		engines	Petrol	RFS MM1AP		Erase Fault Code		Y		
306R		engines	Petrol	RFS MM1AP		Live Data		Y		
306R		engines	Petrol	RFS MM1AP		Actuation Test		Y		
306R		engines	Petrol	RFS MM1AP		Special Function	Ignition advance setting	Y		
306R		engines	Petrol	RFS MM1AP		Special Function	Injection ECU initialisation	Y		
306R		engines	Petrol	RFV BOSCH MP5.2		Read Fault Code		Y		
306R		engines	Petrol	RFV BOSCH MP5.2		Erase Fault Code		Y		
306R		engines	Petrol	RFV BOSCH MP5.2		Live Data		Y		
306R		engines	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
306R		engines	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
306R		engines	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
306R		engines	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
306R		engines	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
306R		engines	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
306R		engines	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		
306R		engines	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
306R		engines	Diesel	WJY LUCAS DCN2		Live Data		Y		
306R		engines	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
306R		engines	Diesel	WJZ LUCAS DCN2		Read ECU Information		Y		
306R		engines	Diesel	WJZ LUCAS DCN2		Read Fault Code		Y		
306R		engines	Diesel	WJZ LUCAS DCN2		Erase Fault Code		Y		
306R		engines	Diesel	WJZ LUCAS DCN2		Live Data		Y		
306R		engines	Diesel	WJZ LUCAS DCN2		Actuation Test		Y		
306R		Airbags	Air bag and seat belt			Read ECU Information		Y		
306R		Airbags	Air bag and seat belt			Read Fault Code		Y		
306R		Airbags	Air bag and seat belt			Erase Fault Code		Y		
306R		Airbags	Side airbag(right side)			Read ECU Information		Y		
306R		Airbags	Side airbag(right side)			Read Fault Code		Y		
306R		Airbags	Side airbag(right side)			Erase Fault Code		Y		
306R		Airbags	Side airbag(right side)			Actuation Test		Y		
306R		Airbags	Side airbag(left side)			Read ECU Information		Y		
306R		Airbags	Side airbag(left side)			Read Fault Code		Y		
306R		Airbags	Side airbag(left side)			Erase Fault Code		Y		
306R		Airbags	Side airbag(left side)			Actuation Test		Y		
306R		Active safety	ABS BOSCH 53			Read ECU Information		Y		
306R		Active safety	ABS BOSCH 53			Read Fault Code		Y		
306R		Active safety	ABS BOSCH 53			Erase Fault Code		Y		
306R		Active safety	ABS BOSCH 53			Live Data		Y		

306R		Active safety	ABS BOSCH 53			Actuation Test		Y		
306R		Active safety	ABS BOSCH 53			Special Function	Bleeding	Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Read ECU Information		Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Read Fault Code		Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Live Data		Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Actuation Test		Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Special Function	Changing the modeElectrical	Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Special Function	Learning	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Live Data		Y		

308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 8FS	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 8FS	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 8FS	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 8FS	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 8FS	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Read ECU Information		Y		

308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Live Data		Y		

308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6A	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6A	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6A	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6A	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6A	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6A	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 NFU	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 NFU	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 NFU	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 NFU	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 NFU	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 NFU	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6B	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6B	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6B	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6B	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6B	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749	ME749 N6B	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Read ECU Information		Y		

308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Erase Fault Code		Y		

308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 4		Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 4		Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 4		Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 4		Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 4		Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Live Data		Y		

308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Read Fault Code		Y		

308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Special Function	Pack Repair	Y		

308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Actuation Test		Y		

308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read ECU Information		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read Fault Code		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Live Data		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Actuation Test		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read ECU Information		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Live Data		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Actuation Test		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Read ECU Information		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Read Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Live Data		Y		

308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Actuation Test		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Read ECU Information		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Read Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Live Data		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Actuation Test		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC AUTOLIV			Read ECU Information		Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC AUTOLIV			Read Fault Code		Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC AUTOLIV			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC AUTOLIV			Live Data		Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC AUTOLIV			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Power steering				Read ECU Information		Y		
308(2010.01 - 2014.09)		Power steering				Read Fault Code		Y		
308(2010.01 - 2014.09)		Power steering				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Power steering				Live Data		Y		
308(2010.01 - 2014.09)		Power steering				Actuation Test		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX MGI			Read ECU Information		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX MGI			Read Fault Code		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX MGI			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX MGI			Live Data		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX MGI			Actuation Test		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX TI			Read ECU Information		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX TI			Read Fault Code		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX TI			Erase Fault Code		Y		

308(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX TI			Live Data		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX TI			Actuation Test		Y		
308(2010.01 - 2014.09)		Under inflation detection				Read ECU Information		Y		
308(2010.01 - 2014.09)		Under inflation detection				Read Fault Code		Y		
308(2010.01 - 2014.09)		Under inflation detection				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Under inflation detection				Live Data		Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Read ECU Information		Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Read Fault Code		Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Live Data		Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Actuation Test		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB			Read ECU Information		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB			Live Data		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB GEN2			Read ECU Information		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB GEN2			Live Data		Y		
308(2010.01 - 2014.09)		Lane departure warning system				Read ECU Information		Y		
308(2010.01 - 2014.09)		Lane departure warning system				Read Fault Code		Y		
308(2010.01 - 2014.09)		Lane departure warning system				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Lane departure warning system				Live Data		Y		
308(2010.01 - 2014.09)		Lane departure warning system				Actuation Test		Y		
308(2010.01 - 2014.09)		Engine relay unit				Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine relay unit				Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine relay unit				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine relay unit				Actuation Test		Y		
308(2010.01 - 2014.09)		Trailer relay unit				Read ECU Information		Y		
308(2010.01 - 2014.09)		Trailer relay unit				Read Fault Code		Y		
308(2010.01 - 2014.09)		Trailer relay unit				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)With buttons			Read ECU Information		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)With buttons			Read Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)With buttons			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)With buttons			Live Data		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)With buttons			Actuation Test		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)Without button			Read ECU Information		Y		

308(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)Without button			Read Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)Without button			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)Without button			Live Data		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)Without button			Actuation Test		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'C' (dot matrix)			Read ECU Information		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'C' (dot matrix)			Read Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'C' (dot matrix)			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'C' (dot matrix)			Live Data		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'C' (dot matrix)			Actuation Test		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'C colour' (dot matrix)			Read ECU Information		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'C colour' (dot matrix)			Read Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'C colour' (dot matrix)			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'C colour' (dot matrix)			Live Data		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type 'C colour' (dot matrix)			Actuation Test		Y		
308(2010.01 - 2014.09)		Windscreen wiper				Read ECU Information		Y		
308(2010.01 - 2014.09)		Windscreen wiper				Actuation Test		Y		
308(2010.01 - 2014.09)		Parking assistance	Parking aid			Read ECU Information		Y		
308(2010.01 - 2014.09)		Parking assistance	Parking aid			Read Fault Code		Y		
308(2010.01 - 2014.09)		Parking assistance	Parking aid			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Parking assistance	Parking aid			Live Data		Y		
308(2010.01 - 2014.09)		Air conditioning				Read ECU Information		Y		
308(2010.01 - 2014.09)		Air conditioning				Read Fault Code		Y		
308(2010.01 - 2014.09)		Air conditioning				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Air conditioning				Live Data		Y		
308(2010.01 - 2014.09)		Air conditioning				Actuation Test		Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Read ECU Information		Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Read Fault Code		Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Live Data		Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Actuation Test		Y		
308(2010.01 - 2014.09)		Instrument panel				Read ECU Information		Y		
308(2010.01 - 2014.09)		Instrument panel				Read Fault Code		Y		
308(2010.01 - 2014.09)		Instrument panel				Erase Fault Code		Y		

308(2010.01 - 2014.09)		Instrument panel				Live Data		Y		
308(2010.01 - 2014.09)		Instrument panel				Actuation Test		Y		
308(2010.01 - 2014.09)		CD changer / external CD player				Read ECU Information		Y		
308(2010.01 - 2014.09)		CD changer / external CD player				Read Fault Code		Y		
308(2010.01 - 2014.09)		CD changer / external CD player				Erase Fault Code		Y		
308(2010.01 - 2014.09)		CD changer / external CD player				Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		

308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
308(2010.01 - 2014.09)		Radio amplifier				Read ECU Information		Y		
308(2010.01 - 2014.09)		Radio amplifier				Read Fault Code		Y		
308(2010.01 - 2014.09)		Radio amplifier				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Radio amplifier				Actuation Test		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Read ECU Information		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Read Fault Code		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Live Data		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Actuation Test		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER NOMADE			Read ECU Information		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER NOMADE			Read Fault Code		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER NOMADE			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER NOMADE			Live Data		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER NOMADE			Actuation Test		Y		
308(2010.01 - 2014.09)		Radio	RD4			Read ECU Information		Y		
308(2010.01 - 2014.09)		Radio	RD4			Read Fault Code		Y		
308(2010.01 - 2014.09)		Radio	RD4			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Radio	RD4			Live Data		Y		
308(2010.01 - 2014.09)		Radio	RD4			Actuation Test		Y		
308(2010.01 - 2014.09)		Radio	RD45			Read ECU Information		Y		
308(2010.01 - 2014.09)		Radio	RD45			Read Fault Code		Y		
308(2010.01 - 2014.09)		Radio	RD45			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Radio	RD45			Live Data		Y		
308(2010.01 - 2014.09)		Radio	RD45			Actuation Test		Y		
308(2010.01 - 2014.09)		Seat driver position memory module.				Read ECU Information		Y		
308(2010.01 - 2014.09)		Seat driver position memory module.				Read Fault Code		Y		
308(2010.01 - 2014.09)		Seat driver position memory module.				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Seat driver position memory module.				Live Data		Y		
308(2010.01 - 2014.09)		Seat driver position memory module.				Actuation Test		Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Read ECU Information		Y		

308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Read Fault Code		Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Live Data		Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Actuation Test		Y		
308(2010.01 - 2014.09)		Anti-theft alarm				Read ECU Information		Y		
308(2010.01 - 2014.09)		Anti-theft alarm				Read Fault Code		Y		
308(2010.01 - 2014.09)		Anti-theft alarm				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Anti-theft alarm				Live Data		Y		
308(2010.01 - 2014.09)		Seat passenger position memory module.				Read ECU Information		Y		
308(2010.01 - 2014.09)		Seat passenger position memory module.				Read Fault Code		Y		
308(2010.01 - 2014.09)		Seat passenger position memory module.				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Seat passenger position memory module.				Live Data		Y		
308(2010.01 - 2014.09)		Seat passenger position memory module.				Actuation Test		Y		
308(2010.01 - 2014.09)		Driver's door module	Driver's door module			Read ECU Information		Y		
308(2010.01 - 2014.09)		Driver's door module	Driver's door module			Read Fault Code		Y		
308(2010.01 - 2014.09)		Driver's door module	Driver's door module			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Driver's door module	Driver's door module			Live Data		Y		
308(2010.01 - 2014.09)		Driver's door module	Driver's door module			Actuation Test		Y		
308(2010.01 - 2014.09)		Sun roof				Read ECU Information		Y		
308(2010.01 - 2014.09)		Sun roof				Read Fault Code		Y		
308(2010.01 - 2014.09)		Sun roof				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Sun roof				Live Data		Y		
308(2010.01 - 2014.09)		Sun roof				Actuation Test		Y		
308(2010.01 - 2014.09)		Moving panel deflector				Read ECU Information		Y		
308(2010.01 - 2014.09)		Moving panel deflector				Read Fault Code		Y		
308(2010.01 - 2014.09)		Moving panel deflector				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Moving panel deflector				Live Data		Y		
308(2010.01 - 2014.09)		Moving panel deflector				Actuation Test		Y		
308(2010.01 - 2014.09)		Folding roof				Read ECU Information		Y		
308(2010.01 - 2014.09)		Folding roof				Read Fault Code		Y		
308(2010.01 - 2014.09)		Folding roof				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Folding roof				Live Data		Y		
308(2010.01 - 2014.09)		Folding roof				Actuation Test		Y		

308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD SERV			Read ECU Information		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD SERV			Read Fault Code		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD SERV			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD SERV			Live Data		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD SERV			Actuation Test		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Live Data		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Actuation Test		Y		
308(2010.01 - 2014.09)		Driving school module				Read ECU Information		Y		
308(2010.01 - 2014.09)		Driving school module				Actuation Test		Y		
308(2010.01 - 2014.09)		Rain and light sensor				Read ECU Information		Y		
308(2010.01 - 2014.09)		Rain and light sensor				Read Fault Code		Y		
308(2010.01 - 2014.09)		Rain and light sensor				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Seat belt not fastened warning lights unit				Read ECU Information		Y		
308(2010.01 - 2014.09)		Seat belt not fastened warning lights unit				Actuation Test		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Read ECU Information		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Read Fault Code		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Live Data		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Actuation Test		Y		
308(2010.01 - 2014.09)		High frequency receiver				Read ECU Information		Y		
308(2010.01 - 2014.09)		High frequency receiver				Read Fault Code		Y		
308(2010.01 - 2014.09)		High frequency receiver				Erase Fault Code		Y		
308(2010.01 - 2014.09)		High frequency receiver				Live Data		Y		
308(2010.01 - 2014.09)		Voltage retaining device	DMTC			Read ECU Information		Y		
308(2010.01 - 2014.09)		Voltage retaining device	DMTR			Read ECU Information		Y		
308(2010.01 - 2014.09)		Voltage retaining device	DMTR			Read Fault Code		Y		
308(2010.01 - 2014.09)		Voltage retaining device	DMTR			Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FV MED 17.4.2 EURO 5	Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FV MED 17.4.2 EURO 5	Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FV MED 17.4.2 EURO 5	Erase Fault Code		Y		

308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FV MED 17.4.2 EURO 5	Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FV MED 17.4.2 EURO 5	Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FV MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FN MED 17.4.2 EURO 5	Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FN MED 17.4.2 EURO 5	Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FN MED 17.4.2 EURO 5	Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FN MED 17.4.2 EURO 5	Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FN MED 17.4.2 EURO 5	Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FN MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FA MED 17.4.2 EURO 5	Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FA MED 17.4.2 EURO 5	Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FA MED 17.4.2 EURO 5	Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FA MED 17.4.2 EURO 5	Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FA MED 17.4.2 EURO 5	Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 2	5FA MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	V46		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	V46		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	V46		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	V46		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	V46		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	V46		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	VD46		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	VD46		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	VD46		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	VD46		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	VD46		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 4		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 4		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 4		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 4		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 4		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MED17 4 4		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MEVD17 4 4		Read ECU Information		Y		

308(T9)(after 2014.09)		Engine management ECU	petrol	MEVD17 4 4		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MEVD17 4 4		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MEVD17 4 4		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MEVD17 4 4		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MEVD17 4 4		Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MEVD17 4 4		Special Function	Work on the ancillaries battery	Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MEVD17 4 4		Special Function	Initialisation of the autoadaptive values	Y		
308(T9)(after 2014.09)		Engine management ECU	petrol	MEVD17 4 4		Special Function	Replacement parts	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2		Special Function	Configuration	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Special Function	Configuration	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Live Data		Y		

308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read ECU Information		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read Fault Code		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Erase Fault Code		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Live Data		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Actuation Test		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Read ECU Information		Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Read Fault Code		Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Erase Fault Code		Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Live Data		Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Actuation Test		Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Air bags and pre-tensioners control unit				Live Data		Y		
308(T9)(after 2014.09)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Trailer relay unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Trailer relay unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Trailer relay unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Trailer relay unit				Live Data		Y		
308(T9)(after 2014.09)		Trailer relay unit				Actuation Test		Y		
308(T9)(after 2014.09)		Engine relay unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Engine relay unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Engine relay unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with PIXELS(C-)			Read ECU Information		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with PIXELS(C-)			Read Fault Code		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with PIXELS(C-)			Erase Fault Code		Y		

308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with PIXELS(C-)			Actuation Test		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with SEGMENTS(A+)			Read ECU Information		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with SEGMENTS(A+)			Read Fault Code		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with SEGMENTS(A+)			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with SEGMENTS(A+)			Actuation Test		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	YES			Read ECU Information		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	YES			Read Fault Code		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	YES			Erase Fault Code		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	YES			Live Data		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	YES			Actuation Test		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	NO			Read ECU Information		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	NO			Read Fault Code		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	NO			Erase Fault Code		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	NO			Live Data		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	NO			Actuation Test		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Read ECU Information		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Read Fault Code		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Live Data		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Actuation Test		Y		
308(T9)(after 2014.09)		External CD player				Read ECU Information		Y		
308(T9)(after 2014.09)		External CD player				Read Fault Code		Y		
308(T9)(after 2014.09)		External CD player				Erase Fault Code		Y		
308(T9)(after 2014.09)		External CD player				Live Data		Y		
308(T9)(after 2014.09)		External CD player				Actuation Test		Y		
308(T9)(after 2014.09)		Supply protection and management unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Supply protection and management unit				Live Data		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Read ECU Information		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Read Fault Code		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Erase Fault Code		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Live Data		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Actuation Test		Y		
308(T9)(after 2014.09)		Driver's door module				Read ECU Information		Y		

308(T9)(after 2014.09)		Driver's door module				Read Fault Code		Y		
308(T9)(after 2014.09)		Driver's door module				Erase Fault Code		Y		
308(T9)(after 2014.09)		Driver's door module				Live Data		Y		
308(T9)(after 2014.09)		Driver's door module				Actuation Test		Y		
308(T9)(after 2014.09)		Power steering				Read ECU Information		Y		
308(T9)(after 2014.09)		Power steering				Read Fault Code		Y		
308(T9)(after 2014.09)		Power steering				Erase Fault Code		Y		
308(T9)(after 2014.09)		Power steering				Live Data		Y		
308(T9)(after 2014.09)		Electronic key reader				Read ECU Information		Y		
308(T9)(after 2014.09)		Electronic key reader				Read Fault Code		Y		
308(T9)(after 2014.09)		Electronic key reader				Erase Fault Code		Y		
308(T9)(after 2014.09)		Electronic key reader				Live Data		Y		
308(T9)(after 2014.09)		Diesel additive function	PADDGO INERGY	PADDGO INERGY DV6CTED	9HC PADDGO INERGY	Read ECU Information		Y		
308(T9)(after 2014.09)		Diesel additive function	PADDGO INERGY	PADDGO INERGY DV6CTED	9HC PADDGO INERGY	Read Fault Code		Y		
308(T9)(after 2014.09)		Diesel additive function	PADDGO INERGY	PADDGO INERGY DV6CTED	9HC PADDGO INERGY	Erase Fault Code		Y		
308(T9)(after 2014.09)		Diesel additive function	PADDGO INERGY	PADDGO INERGY DV6CTED	9HC PADDGO INERGY	Live Data		Y		
308(T9)(after 2014.09)		Diesel additive function	PADDGO INERGY	PADDGO INERGY DV6CTED	9HC PADDGO INERGY	Actuation Test		Y		
308(T9)(after 2014.09)		Diesel additive function	PADDGO INERGY	PADDGO INERGY DV6DTED	9HP PADDGO INERGY	Read ECU Information		Y		
308(T9)(after 2014.09)		Diesel additive function	PADDGO INERGY	PADDGO INERGY DV6DTED	9HP PADDGO INERGY	Read Fault Code		Y		
308(T9)(after 2014.09)		Diesel additive function	PADDGO INERGY	PADDGO INERGY DV6DTED	9HP PADDGO INERGY	Erase Fault Code		Y		
308(T9)(after 2014.09)		Diesel additive function	PADDGO INERGY	PADDGO INERGY DV6DTED	9HP PADDGO INERGY	Live Data		Y		
308(T9)(after 2014.09)		Diesel additive function	PADDGO INERGY	PADDGO INERGY DV6DTED	9HP PADDGO INERGY	Actuation Test		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Read ECU Information		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Read Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Erase Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Live Data		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Actuation Test		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Read ECU Information		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Read Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Erase Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Live Data		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Actuation Test		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Read ECU Information		Y		

308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Read Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Erase Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Live Data		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Actuation Test		Y		
308(T9)(after 2014.09)		Vehicle Distance Assistance				Read ECU Information		Y		
308(T9)(after 2014.09)		Vehicle Distance Assistance				Read Fault Code		Y		
308(T9)(after 2014.09)		Vehicle Distance Assistance				Erase Fault Code		Y		
308(T9)(after 2014.09)		Vehicle Distance Assistance				Live Data		Y		
308(T9)(after 2014.09)		Vehicle Distance Assistance				Actuation Test		Y		
308(T9)(after 2014.09)		Air conditioning				Read ECU Information		Y		
308(T9)(after 2014.09)		Air conditioning				Read Fault Code		Y		
308(T9)(after 2014.09)		Air conditioning				Erase Fault Code		Y		
308(T9)(after 2014.09)		Air conditioning				Live Data		Y		
308(T9)(after 2014.09)		Air conditioning				Actuation Test		Y		
308(T9)(after 2014.09)		Control on the steering wheel / integral controls steering wheel	Control on the steering wheel / integral controls steering wheel			Read ECU Information		Y		
308(T9)(after 2014.09)		Control on the steering wheel / integral controls steering wheel	Control on the steering wheel / integral controls steering wheel			Read Fault Code		Y		
308(T9)(after 2014.09)		Control on the steering wheel / integral controls steering wheel	Control on the steering wheel / integral controls steering wheel			Erase Fault Code		Y		
308(T9)(after 2014.09)		Control on the steering wheel / integral controls steering wheel	Control on the steering wheel / integral controls steering wheel			Live Data		Y		
308(T9)(after 2014.09)		Control on the steering wheel / integral controls steering wheel	Control on the steering wheel / integral controls steering wheel			Actuation Test		Y		
308(T9)(after 2014.09)		Touch screen				Read ECU Information		Y		
308(T9)(after 2014.09)		Touch screen				Read Fault Code		Y		
308(T9)(after 2014.09)		Touch screen				Erase Fault Code		Y		
308(T9)(after 2014.09)		Touch screen				Live Data		Y		
308(T9)(after 2014.09)		Touch screen				Actuation Test		Y		
308(T9)(after 2014.09)		Rain and brightness sensor				Read ECU Information		Y		
308(T9)(after 2014.09)		Rain and brightness sensor				Read Fault Code		Y		
308(T9)(after 2014.09)		Rain and brightness sensor				Erase Fault Code		Y		
308(T9)(after 2014.09)		Rain and brightness sensor				Live Data		Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Read ECU Information		Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Read Fault Code		Y		

308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Erase Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Live Data		Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Actuation Test		Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Read ECU Information		Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Read Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Erase Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Live Data		Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Actuation Test		Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Read ECU Information		Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Read Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Erase Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Live Data		Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Actuation Test		Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Read ECU Information		Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Read Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Erase Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Live Data		Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Actuation Test		Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Live Data		Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Actuation Test		Y		
308(T9)(after 2014.09)		Battery charge status unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Battery charge status unit				Live Data		Y		
308(T9)(after 2014.09)		Radio amplifier				Read ECU Information		Y		
308(T9)(after 2014.09)		Radio amplifier				Read Fault Code		Y		
308(T9)(after 2014.09)		Radio amplifier				Erase Fault Code		Y		
308(T9)(after 2014.09)		Radio amplifier				Actuation Test		Y		
308(T9)(after 2014.09)		Hands-free control unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Hands-free control unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Hands-free control unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Hands-free control unit				Live Data		Y		

308(T9)(after 2014.09)		Hands-free control unit				Actuation Test		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Live Data		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Actuation Test		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA 2			Read ECU Information		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA 2			Read Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA 2			Erase Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA 2			Live Data		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA 2			Actuation Test		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA 3S			Read ECU Information		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA 3S			Read Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA 3S			Erase Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA 3S			Live Data		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA 3S			Actuation Test		Y		
308(T9)(after 2014.09)		Multiplexed control panel	Accessory audio system and manual air			Read ECU Information		Y		
308(T9)(after 2014.09)		Multiplexed control panel	Accessory audio system and manual air			Read Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	Accessory audio system and manual air			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	Accessory audio system and manual air			Live Data		Y		
308(T9)(after 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read ECU Information		Y		
308(T9)(after 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Live Data		Y		
308(T9)(after 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Actuation Test		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG audio-navigation+			Read ECU Information		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG audio-navigation+			Read Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG audio-navigation+			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG audio-navigation+			Live Data		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG audio-navigation+			Actuation Test		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG+ audio-navigation with CD player			Read ECU Information		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG+ audio-navigation with CD player			Read Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG+ audio-navigation with CD player			Erase Fault Code		Y		

308(T9)(after 2014.09)		Multiplexed control panel	SMEG+ audio-navigation with CD player			Live Data		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG+ audio-navigation with CD player			Actuation Test		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Read ECU Information		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Read Fault Code		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Erase Fault Code		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Live Data		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Actuation Test		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Live Data		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Actuation Test		Y		
308(T9)(after 2014.09)		Radio	RD45			Read ECU Information		Y		
308(T9)(after 2014.09)		Radio	RD45			Read Fault Code		Y		
308(T9)(after 2014.09)		Radio	RD45			Erase Fault Code		Y		
308(T9)(after 2014.09)		Radio	RD45			Live Data		Y		
308(T9)(after 2014.09)		Radio	RD45			Actuation Test		Y		
308(T9)(after 2014.09)		Radio	RD6			Read ECU Information		Y		
308(T9)(after 2014.09)		Radio	RD6			Read Fault Code		Y		
308(T9)(after 2014.09)		Radio	RD6			Erase Fault Code		Y		
308(T9)(after 2014.09)		Radio	RD6			Live Data		Y		
308(T9)(after 2014.09)		Radio	RD6			Actuation Test		Y		
308(T9)(after 2014.09)		Matrix screen integral to the instrument panel	No			Read ECU Information		Y		
308(T9)(after 2014.09)		Matrix screen integral to the instrument panel	No			Read Fault Code		Y		
308(T9)(after 2014.09)		Matrix screen integral to the instrument panel	No			Erase Fault Code		Y		
308(T9)(after 2014.09)		Matrix screen integral to the instrument panel	No			Actuation Test		Y		
308(T9)(after 2014.09)		Matrix screen integral to the instrument panel	Yes			Read ECU Information		Y		
308(T9)(after 2014.09)		Matrix screen integral to the instrument panel	Yes			Read Fault Code		Y		
308(T9)(after 2014.09)		Matrix screen integral to the instrument panel	Yes			Erase Fault Code		Y		
308(T9)(after 2014.09)		Matrix screen integral to the instrument panel	Yes			Actuation Test		Y		
308(T9)(after 2014.09)		Seat belts not fastened LED unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Seat belts not fastened LED unit				Actuation Test		Y		
308(T9)(after 2014.09)		Additional heating				Read ECU Information		Y		

308(T9)(after 2014.09)		Additional heating				Read Fault Code		Y		
308(T9)(after 2014.09)		Additional heating				Erase Fault Code		Y		
308(T9)(after 2014.09)		Additional heating				Live Data		Y		
308(T9)(after 2014.09)		Additional heating				Actuation Test		Y		
308(T9)(after 2014.09)		Voltage retaining device	DMTC			Read ECU Information		Y		
308(T9)(after 2014.09)		Voltage retaining device	DMTR			Read ECU Information		Y		
308(T9)(after 2014.09)		Voltage retaining device	DMTR			Read Fault Code		Y		
308(T9)(after 2014.09)		Voltage retaining device	DMTR			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multifunction video camera(CMF)				Read ECU Information		Y		
308(T9)(after 2014.09)		Multifunction video camera(CMF)				Read Fault Code		Y		
308(T9)(after 2014.09)		Multifunction video camera(CMF)				Erase Fault Code		Y		
308(T9)(after 2014.09)		Multifunction video camera(CMF)				Live Data		Y		
308(T9)(after 2014.09)		Multifunction video camera(CMF)				Actuation Test		Y		
308S(T9)		Engine management ECU	V46 52			Read ECU Information		Y		
308S(T9)		Engine management ECU	V46 52			Read Fault Code		Y		
308S(T9)		Engine management ECU	V46 52			Erase Fault Code		Y		
308S(T9)		Engine management ECU	V46 52			Live Data		Y		
308S(T9)		Engine management ECU	V46 52			Actuation Test		Y		
308S(T9)		Engine management ECU	V46 52			Special Function	Initialisation of the autoadaptive values	Y		
308S(T9)		Engine management ECU	V46 52			Special Function	Replacement parts	Y		
308S(T9)		Engine management ECU	VD46			Read ECU Information		Y		
308S(T9)		Engine management ECU	VD46			Read Fault Code		Y		
308S(T9)		Engine management ECU	VD46			Erase Fault Code		Y		
308S(T9)		Engine management ECU	VD46			Live Data		Y		
308S(T9)		Engine management ECU	VD46			Actuation Test		Y		
308S(T9)		Engine management ECU	VD46			Special Function	Pack Repair	Y		
308S(T9)		Engine management ECU	MED17 4 4			Read ECU Information		Y		
308S(T9)		Engine management ECU	MED17 4 4			Read Fault Code		Y		
308S(T9)		Engine management ECU	MED17 4 4			Erase Fault Code		Y		
308S(T9)		Engine management ECU	MED17 4 4			Live Data		Y		
308S(T9)		Engine management ECU	MED17 4 4			Actuation Test		Y		
308S(T9)		Engine management ECU	MED17 4 4			Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
308S(T9)		Engine management ECU	MED17 4 4			Special Function	Work on the ancillaries battery	Y		
308S(T9)		Engine management ECU	MED17 4 4			Special Function	Initialisation of the autoadaptive values	Y		
308S(T9)		Engine management ECU	MED17 4 4			Special Function	Replacement parts	Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read ECU Information		Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read Fault Code		Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Erase Fault Code		Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Live Data		Y		

308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Actuation Test		Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Special Function	Pack Repair	Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Read ECU Information		Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Read Fault Code		Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Erase Fault Code		Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Live Data		Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Actuation Test		Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Special Function	Pack Repair	Y		
308S(T9)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
308S(T9)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
308S(T9)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
308S(T9)		Air bags and pre-tensioners control unit				Live Data		Y		
308S(T9)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
308S(T9)		Engine relay unit				Read ECU Information		Y		
308S(T9)		Engine relay unit				Read Fault Code		Y		
308S(T9)		Engine relay unit				Erase Fault Code		Y		
308S(T9)		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
308S(T9)		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
308S(T9)		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
308S(T9)		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
308S(T9)		Dynamic headlamp height adjuster				Read ECU Information		Y		
308S(T9)		Dynamic headlamp height adjuster				Read Fault Code		Y		
308S(T9)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
308S(T9)		Dynamic headlamp height adjuster				Live Data		Y		
308S(T9)		Dynamic headlamp height adjuster				Actuation Test		Y		
308S(T9)		Supply protection and management unit				Read ECU Information		Y		
308S(T9)		Supply protection and management unit				Live Data		Y		
308S(T9)		Power steering				Read ECU Information		Y		
308S(T9)		Power steering				Read Fault Code		Y		
308S(T9)		Power steering				Erase Fault Code		Y		
308S(T9)		Power steering				Live Data		Y		
308S(T9)		Electronic key reader				Read ECU Information		Y		
308S(T9)		Electronic key reader				Read Fault Code		Y		
308S(T9)		Electronic key reader				Erase Fault Code		Y		
308S(T9)		Electronic key reader				Live Data		Y		
308S(T9)		Air conditioning				Read ECU Information		Y		
308S(T9)		Air conditioning				Read Fault Code		Y		
308S(T9)		Air conditioning				Erase Fault Code		Y		
308S(T9)		Air conditioning				Live Data		Y		
308S(T9)		Air conditioning				Actuation Test		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	YES			Read ECU Information		Y		

308S(T9)		Control on the steering wheel / integral controls steering wheel	YES			Read Fault Code		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	YES			Erase Fault Code		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	YES			Live Data		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	YES			Actuation Test		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	NO			Read ECU Information		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	NO			Read Fault Code		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	NO			Erase Fault Code		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	NO			Live Data		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	NO			Actuation Test		Y		
308S(T9)		Rain and brightness sensor				Read ECU Information		Y		
308S(T9)		Rain and brightness sensor				Read Fault Code		Y		
308S(T9)		Rain and brightness sensor				Erase Fault Code		Y		
308S(T9)		Rain and brightness sensor				Live Data		Y		
308S(T9)		Parking assistance	4 parking assistance			Read ECU Information		Y		
308S(T9)		Parking assistance	4 parking assistance			Read Fault Code		Y		
308S(T9)		Parking assistance	4 parking assistance			Erase Fault Code		Y		
308S(T9)		Parking assistance	4 parking assistance			Live Data		Y		
308S(T9)		Parking assistance	4 parking assistance			Actuation Test		Y		
308S(T9)		Parking assistance	8 parking assistance			Read ECU Information		Y		
308S(T9)		Parking assistance	8 parking assistance			Read Fault Code		Y		
308S(T9)		Parking assistance	8 parking assistance			Erase Fault Code		Y		
308S(T9)		Parking assistance	8 parking assistance			Live Data		Y		
308S(T9)		Parking assistance	8 parking assistance			Actuation Test		Y		
308S(T9)		Parking assistance	10 parking assistance			Read ECU Information		Y		
308S(T9)		Parking assistance	10 parking assistance			Read Fault Code		Y		
308S(T9)		Parking assistance	10 parking assistance			Erase Fault Code		Y		
308S(T9)		Parking assistance	10 parking assistance			Live Data		Y		
308S(T9)		Parking assistance	10 parking assistance			Actuation Test		Y		
308S(T9)		Parking assistance	12 parking assistance			Read ECU Information		Y		
308S(T9)		Parking assistance	12 parking assistance			Read Fault Code		Y		
308S(T9)		Parking assistance	12 parking assistance			Erase Fault Code		Y		
308S(T9)		Parking assistance	12 parking assistance			Live Data		Y		
308S(T9)		Parking assistance	12 parking assistance			Actuation Test		Y		
308S(T9)		Driver's seat memorizing				Read ECU Information		Y		
308S(T9)		Driver's seat memorizing				Read Fault Code		Y		
308S(T9)		Driver's seat memorizing				Erase Fault Code		Y		
308S(T9)		Driver's seat memorizing				Live Data		Y		
308S(T9)		Driver's seat memorizing				Actuation Test		Y		
308S(T9)		Battery charge status unit				Read ECU Information		Y		
308S(T9)		Battery charge status unit				Live Data		Y		
308S(T9)		Hands-free starting access electronic module				Read ECU Information		Y		
308S(T9)		Hands-free starting access electronic module				Read Fault Code		Y		
308S(T9)		Hands-free starting access electronic module				Erase Fault Code		Y		
308S(T9)		Hands-free starting access electronic module				Live Data		Y		

308S(T9)		Hands-free starting access electronic module				Actuation Test		Y		
308S(T9)		Service module / Independent telematic unit	BTA CN			Read ECU Information		Y		
308S(T9)		Service module / Independent telematic unit	BTA CN			Read Fault Code		Y		
308S(T9)		Service module / Independent telematic unit	BTA CN			Erase Fault Code		Y		
308S(T9)		Service module / Independent telematic unit	BTA CN			Live Data		Y		
308S(T9)		Service module / Independent telematic unit	BTA CN			Actuation Test		Y		
308S(T9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read ECU Information		Y		
308S(T9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read Fault Code		Y		
308S(T9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Erase Fault Code		Y		
308S(T9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Live Data		Y		
308S(T9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Actuation Test		Y		
308S(T9)		Multiplexed control panel	MRN audio-navigation			Read ECU Information		Y		
308S(T9)		Multiplexed control panel	MRN audio-navigation			Read Fault Code		Y		
308S(T9)		Multiplexed control panel	MRN audio-navigation			Erase Fault Code		Y		
308S(T9)		Multiplexed control panel	MRN audio-navigation			Live Data		Y		
308S(T9)		Multiplexed control panel	MRN audio-navigation			Actuation Test		Y		
308S(T9)		Control of the telematic				Read ECU Information		Y		
308S(T9)		Control of the telematic				Read Fault Code		Y		
308S(T9)		Control of the telematic				Erase Fault Code		Y		
308S(T9)		Control of the telematic				Live Data		Y		
308S(T9)		Control of the telematic				Actuation Test		Y		
308S(T9)		Control panel dot matrix display	No			Read ECU Information		Y		
308S(T9)		Control panel dot matrix display	No			Read Fault Code		Y		
308S(T9)		Control panel dot matrix display	No			Erase Fault Code		Y		
308S(T9)		Control panel dot matrix display	No			Actuation Test		Y		
308S(T9)		Control panel dot matrix display	Yes			Read ECU Information		Y		
308S(T9)		Control panel dot matrix display	Yes			Read Fault Code		Y		
308S(T9)		Control panel dot matrix display	Yes			Erase Fault Code		Y		
308S(T9)		Control panel dot matrix display	Yes			Actuation Test		Y		
308S(T9)		Voltage retaining device	DMTR DTC3B			Read ECU Information		Y		
308S(T9)		Voltage retaining device	DMTR DTC3B			Read Fault Code		Y		
308S(T9)		Voltage retaining device	DMTR DTC3B			Erase Fault Code		Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Read ECU Information		Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Read Fault Code		Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Erase Fault Code		Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Live Data		Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Actuation Test		Y		
308S(T9)		Radio				Read ECU Information		Y		
308S(T9)		Radio				Read Fault Code		Y		
308S(T9)		Radio				Erase Fault Code		Y		
308S(T9)		Radio				Live Data		Y		
308S(T9)		Radio				Actuation Test		Y		

308S(T9)		Controls under the steering wheel	YES			Read ECU Information		Y		
308S(T9)		Controls under the steering wheel	YES			Read Fault Code		Y		
308S(T9)		Controls under the steering wheel	YES			Erase Fault Code		Y		
308S(T9)		Controls under the steering wheel	YES			Live Data		Y		
308S(T9)		Controls under the steering wheel	YES			Actuation Test		Y		
308S(T9)		Controls under the steering wheel	NO			Read ECU Information		Y		
308S(T9)		Controls under the steering wheel	NO			Read Fault Code		Y		
308S(T9)		Controls under the steering wheel	NO			Erase Fault Code		Y		
308S(T9)		Controls under the steering wheel	NO			Live Data		Y		
308S(T9)		Controls under the steering wheel	NO			Actuation Test		Y		
308S(T9)		Touch screen				Read ECU Information		Y		
308S(T9)		Touch screen				Read Fault Code		Y		
308S(T9)		Touch screen				Erase Fault Code		Y		
308S(T9)		Touch screen				Live Data		Y		
308S(T9)		Touch screen				Actuation Test		Y		
308S(T9)		Anti-theft alarm				Read ECU Information		Y		
308S(T9)		Anti-theft alarm				Read Fault Code		Y		
308S(T9)		Anti-theft alarm				Erase Fault Code		Y		
308S(T9)		Anti-theft alarm				Live Data		Y		
308S(T9)		Anti-theft alarm				Actuation Test		Y		
308 4 portes		Built-in Systems Interface (BSI)				Read ECU Information		Y		
308 4 portes		Built-in Systems Interface (BSI)				Read Fault Code		Y		
308 4 portes		Built-in Systems Interface (BSI)				Erase Fault Code		Y		
308 4 portes		Built-in Systems Interface (BSI)				Live Data		Y		
308 4 portes		Built-in Systems Interface (BSI)				Actuation Test		Y		
308 4 portes		Built-in Systems Interface (BSI)				Special Function	Maintenance - BSI operating mode	Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO4		Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO4		Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO4		Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO4		Live Data		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO4		Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO4		Special Function	Configuration	Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO4		Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO4		Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO4		Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO4		Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO4		Live Data		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO4		Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Special Function	Pack Repair	Y		

308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6B	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6B	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6B	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6B	Live Data		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6B	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6B	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6A	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6A	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6A	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6A	Live Data		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6A	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 N6A	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 NFU	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 NFU	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 NFU	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 NFU	Live Data		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 NFU	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	ME745	ME745 NFU	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6A	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6A	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6A	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6A	Live Data		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6A	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6A	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 NFU	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 NFU	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 NFU	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 NFU	Live Data		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 NFU	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 NFU	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6B	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6B	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6B	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6B	Live Data		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6B	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	ME749	ME749 N6B	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Live Data		Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFP	Special Function	Pack Repair	Y		

308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Live Data		Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	ME749 EC5	ME749 EC5 NFN	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	ME745 EC5		Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	ME745 EC5		Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME745 EC5		Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	ME745 EC5		Live Data		Y		
308 4 portes		Engine management ECU	petrol	ME745 EC5		Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	ME745 EC5		Special Function	Configuration	Y		
308 4 portes		Engine management ECU	petrol	ME745 EC5		Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Actuation Test		Y		

308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Live Data		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Actuation Test		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	petrol	MED17 4 4		Read ECU Information		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 4		Read Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 4		Erase Fault Code		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 4		Live Data		Y		
308 4 portes		Engine management ECU	petrol	MED17 4 4		Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Special Function	Pack Repair	Y		

308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Erase Fault Code		Y		

308 4 portes		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Special Function	Configuration	Y		

308 4 portes		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Special Function	Pack Repair	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read ECU Information		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Erase Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Live Data		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Actuation Test		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Special Function	Pack Repair	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AT8			Read ECU Information		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AT8			Read Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AT8			Erase Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AT8			Live Data		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AT8			Actuation Test		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AT8			Special Function	Configuration	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AT8			Special Function	Pack Repair	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6			Read ECU Information		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6			Read Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6			Erase Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6			Live Data		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6			Actuation Test		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA AM6			Special Function	Pack Repair	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read ECU Information		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read Fault Code		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Erase Fault Code		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Live Data		Y		

308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Actuation Test		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Configuration	Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Pack Repair	Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC AUTOLIV			Read ECU Information		Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC AUTOLIV			Read Fault Code		Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC AUTOLIV			Erase Fault Code		Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC AUTOLIV			Live Data		Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC AUTOLIV			Special Function	Pack Repair	Y		
308 4 portes		Power steering				Read ECU Information		Y		
308 4 portes		Power steering				Read Fault Code		Y		
308 4 portes		Power steering				Erase Fault Code		Y		
308 4 portes		Power steering				Live Data		Y		
308 4 portes		Power steering				Actuation Test		Y		
308 4 portes		Diesel additive pump	POMPE MUX MGI			Read ECU Information		Y		
308 4 portes		Diesel additive pump	POMPE MUX MGI			Read Fault Code		Y		
308 4 portes		Diesel additive pump	POMPE MUX MGI			Erase Fault Code		Y		
308 4 portes		Diesel additive pump	POMPE MUX MGI			Live Data		Y		
308 4 portes		Diesel additive pump	POMPE MUX MGI			Actuation Test		Y		
308 4 portes		Diesel additive pump	POMPE MUX TI			Read ECU Information		Y		
308 4 portes		Diesel additive pump	POMPE MUX TI			Read Fault Code		Y		
308 4 portes		Diesel additive pump	POMPE MUX TI			Erase Fault Code		Y		
308 4 portes		Diesel additive pump	POMPE MUX TI			Live Data		Y		
308 4 portes		Diesel additive pump	POMPE MUX TI			Actuation Test		Y		
308 4 portes		Under inflation detection				Read ECU Information		Y		
308 4 portes		Under inflation detection				Read Fault Code		Y		
308 4 portes		Under inflation detection				Erase Fault Code		Y		
308 4 portes		Under inflation detection				Live Data		Y		
308 4 portes		Dynamic headlamp height adjuster				Read ECU Information		Y		
308 4 portes		Dynamic headlamp height adjuster				Read Fault Code		Y		
308 4 portes		Dynamic headlamp height adjuster				Erase Fault Code		Y		

308 4 portes		Dynamic headlamp height adjuster				Live Data		Y		
308 4 portes		Dynamic headlamp height adjuster				Actuation Test		Y		
308 4 portes		Battery charge status unit	BECB			Read ECU Information		Y		
308 4 portes		Battery charge status unit	BECB			Live Data		Y		
308 4 portes		Battery charge status unit	BECB GEN2			Read ECU Information		Y		
308 4 portes		Battery charge status unit	BECB GEN2			Live Data		Y		
308 4 portes		Lane departure warning				Read ECU Information		Y		
308 4 portes		Lane departure warning				Read Fault Code		Y		
308 4 portes		Lane departure warning				Erase Fault Code		Y		
308 4 portes		Lane departure warning				Live Data		Y		
308 4 portes		Lane departure warning				Actuation Test		Y		
308 4 portes		Engine relay unit				Read ECU Information		Y		
308 4 portes		Engine relay unit				Read Fault Code		Y		
308 4 portes		Engine relay unit				Erase Fault Code		Y		
308 4 portes		Engine relay unit				Actuation Test		Y		
308 4 portes		Multifunction screen	Type 'A' (segments)With buttons			Read ECU Information		Y		
308 4 portes		Multifunction screen	Type 'A' (segments)With buttons			Read Fault Code		Y		
308 4 portes		Multifunction screen	Type 'A' (segments)With buttons			Erase Fault Code		Y		
308 4 portes		Multifunction screen	Type 'A' (segments)With buttons			Live Data		Y		
308 4 portes		Multifunction screen	Type 'A' (segments)With buttons			Actuation Test		Y		
308 4 portes		Multifunction screen	Type 'A' (segments)Without button			Read ECU Information		Y		
308 4 portes		Multifunction screen	Type 'A' (segments)Without button			Read Fault Code		Y		
308 4 portes		Multifunction screen	Type 'A' (segments)Without button			Erase Fault Code		Y		
308 4 portes		Multifunction screen	Type 'A' (segments)Without button			Live Data		Y		
308 4 portes		Multifunction screen	Type 'A' (segments)Without button			Actuation Test		Y		
308 4 portes		Multifunction screen	Type 'C' (dot matrix)			Read ECU Information		Y		
308 4 portes		Multifunction screen	Type 'C' (dot matrix)			Read Fault Code		Y		
308 4 portes		Multifunction screen	Type 'C' (dot matrix)			Erase Fault Code		Y		
308 4 portes		Multifunction screen	Type 'C' (dot matrix)			Live Data		Y		
308 4 portes		Multifunction screen	Type 'C' (dot matrix)			Actuation Test		Y		
308 4 portes		Multifunction screen	Type 'C colour' (dot			Read ECU Information		Y		
308 4 portes		Multifunction screen	Type 'C colour' (dot			Read Fault Code		Y		
308 4 portes		Multifunction screen	Type 'C colour' (dot			Erase Fault Code		Y		
308 4 portes		Multifunction screen	Type 'C colour' (dot			Live Data		Y		
308 4 portes		Multifunction screen	Type 'C colour' (dot			Actuation Test		Y		
308 4 portes		Windscreen wiper				Read ECU Information		Y		
308 4 portes		Windscreen wiper				Actuation Test		Y		
308 4 portes		Parking assistance	Parking aid			Read ECU Information		Y		
308 4 portes		Parking assistance	Parking aid			Read Fault Code		Y		
308 4 portes		Parking assistance	Parking aid			Erase Fault Code		Y		
308 4 portes		Parking assistance	Parking aid			Live Data		Y		
308 4 portes		Air conditioning				Read ECU Information		Y		
308 4 portes		Air conditioning				Read Fault Code		Y		
308 4 portes		Air conditioning				Erase Fault Code		Y		
308 4 portes		Air conditioning				Live Data		Y		
308 4 portes		Air conditioning				Actuation Test		Y		
308 4 portes		Controls under the steering wheel				Read ECU Information		Y		
308 4 portes		Controls under the steering wheel				Read Fault Code		Y		
308 4 portes		Controls under the steering wheel				Erase Fault Code		Y		
308 4 portes		Controls under the steering wheel				Live Data		Y		

308 4 portes		Controls under the steering wheel				Actuation Test		Y		
308 4 portes		Instrument panel				Read ECU Information		Y		
308 4 portes		Instrument panel				Read Fault Code		Y		
308 4 portes		Instrument panel				Erase Fault Code		Y		
308 4 portes		Instrument panel				Live Data		Y		
308 4 portes		Instrument panel				Actuation Test		Y		
308 4 portes		CD changer / external CD				Read ECU Information		Y		
308 4 portes		CD changer / external CD				Read Fault Code		Y		
308 4 portes		CD changer / external CD				Erase Fault Code		Y		
308 4 portes		CD changer / external CD				Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		

308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
308 4 portes		Radio amplifier				Read ECU Information		Y		
308 4 portes		Radio amplifier				Read Fault Code		Y		
308 4 portes		Radio amplifier				Erase Fault Code		Y		
308 4 portes		Radio amplifier				Actuation Test		Y		
308 4 portes		Hands-free Kit / Portable	KML			Read ECU Information		Y		
308 4 portes		Hands-free Kit / Portable	KML			Read Fault Code		Y		
308 4 portes		Hands-free Kit / Portable	KML			Erase Fault Code		Y		
308 4 portes		Hands-free Kit / Portable	KML			Live Data		Y		
308 4 portes		Hands-free Kit / Portable	KML			Actuation Test		Y		
308 4 portes		Hands-free Kit / Portable	BOITIER NOMADE			Read ECU Information		Y		
308 4 portes		Hands-free Kit / Portable	BOITIER NOMADE			Read Fault Code		Y		
308 4 portes		Hands-free Kit / Portable	BOITIER NOMADE			Erase Fault Code		Y		
308 4 portes		Hands-free Kit / Portable	BOITIER NOMADE			Live Data		Y		
308 4 portes		Hands-free Kit / Portable	BOITIER NOMADE			Actuation Test		Y		
308 4 portes		Seat driver position memory module.				Read ECU Information		Y		
308 4 portes		Seat driver position memory module.				Read Fault Code		Y		
308 4 portes		Seat driver position memory module.				Erase Fault Code		Y		
308 4 portes		Seat driver position memory module.				Live Data		Y		
308 4 portes		Seat driver position memory module.				Actuation Test		Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift			Read ECU Information		Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift			Read Fault Code		Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift			Erase Fault Code		Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift			Live Data		Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift			Actuation Test		Y		
308 4 portes		Anti-theft alarm				Read ECU Information		Y		
308 4 portes		Anti-theft alarm				Read Fault Code		Y		
308 4 portes		Anti-theft alarm				Erase Fault Code		Y		
308 4 portes		Anti-theft alarm				Live Data		Y		
308 4 portes		Seat passenger position memory module.				Read ECU Information		Y		
308 4 portes		Seat passenger position memory module.				Read Fault Code		Y		
308 4 portes		Seat passenger position memory module.				Erase Fault Code		Y		
308 4 portes		Seat passenger position memory module.				Live Data		Y		
308 4 portes		Seat passenger position memory module.				Actuation Test		Y		
308 4 portes		Driver's door module	Driver's door module			Read ECU Information		Y		
308 4 portes		Driver's door module	Driver's door module			Read Fault Code		Y		
308 4 portes		Driver's door module	Driver's door module			Erase Fault Code		Y		
308 4 portes		Driver's door module	Driver's door module			Live Data		Y		
308 4 portes		Driver's door module	Driver's door module			Actuation Test		Y		
308 4 portes		Sun roof				Read ECU Information		Y		
308 4 portes		Sun roof				Read Fault Code		Y		
308 4 portes		Sun roof				Erase Fault Code		Y		
308 4 portes		Sun roof				Live Data		Y		
308 4 portes		Sun roof				Actuation Test		Y		
308 4 portes		Moving panel deflector				Read ECU Information		Y		
308 4 portes		Moving panel deflector				Read Fault Code		Y		
308 4 portes		Moving panel deflector				Erase Fault Code		Y		
308 4 portes		Moving panel deflector				Live Data		Y		
308 4 portes		Moving panel deflector				Actuation Test		Y		
308 4 portes		Folding roof				Read ECU Information		Y		
308 4 portes		Folding roof				Read Fault Code		Y		

308 4 portes		Folding roof				Erase Fault Code		Y		
308 4 portes		Folding roof				Live Data		Y		
308 4 portes		Folding roof				Actuation Test		Y		
308 4 portes		Service module / Independent telematic unit	MD SERV			Read ECU Information		Y		
308 4 portes		Service module / Independent telematic unit	MD SERV			Read Fault Code		Y		
308 4 portes		Service module / Independent telematic unit	MD SERV			Erase Fault Code		Y		
308 4 portes		Service module / Independent telematic unit	MD SERV			Live Data		Y		
308 4 portes		Service module / Independent telematic unit	MD SERV			Actuation Test		Y		
308 4 portes		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
308 4 portes		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
308 4 portes		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
308 4 portes		Service module / Independent telematic unit	BTA			Live Data		Y		
308 4 portes		Service module / Independent telematic unit	BTA			Actuation Test		Y		
308 4 portes		Driving school module				Read ECU Information		Y		
308 4 portes		Driving school module				Actuation Test		Y		
308 4 portes		Rain and light sensor				Read ECU Information		Y		
308 4 portes		Rain and light sensor				Read Fault Code		Y		
308 4 portes		Rain and light sensor				Erase Fault Code		Y		
308 4 portes		Seat belt not fastened warning lights unit				Read ECU Information		Y		
308 4 portes		Seat belt not fastened warning lights unit				Actuation Test		Y		
308 4 portes		Control panel dot matrix display				Read ECU Information		Y		
308 4 portes		Control panel dot matrix display				Read Fault Code		Y		
308 4 portes		Control panel dot matrix display				Erase Fault Code		Y		
308 4 portes		Control panel dot matrix display				Live Data		Y		
308 4 portes		Control panel dot matrix display				Actuation Test		Y		
308(TX9)		Engine management ECU	VD46			Read ECU Information		Y		
308(TX9)		Engine management ECU	VD46			Read Fault Code		Y		
308(TX9)		Engine management ECU	VD46			Erase Fault Code		Y		
308(TX9)		Engine management ECU	VD46			Live Data		Y		
308(TX9)		Engine management ECU	VD46			Actuation Test		Y		
308(TX9)		Engine management ECU	VD46			Special Function	Pack Repair	Y		
308(TX9)		Engine management ECU	V46 52			Read ECU Information		Y		
308(TX9)		Engine management ECU	V46 52			Read Fault Code		Y		
308(TX9)		Engine management ECU	V46 52			Erase Fault Code		Y		
308(TX9)		Engine management ECU	V46 52			Live Data		Y		
308(TX9)		Engine management ECU	V46 52			Actuation Test		Y		
308(TX9)		Engine management ECU	V46 52			Special Function	Pack Repair	Y		
308(TX9)		Engine management ECU	MED17 4 4			Read ECU Information		Y		
308(TX9)		Engine management ECU	MED17 4 4			Read Fault Code		Y		
308(TX9)		Engine management ECU	MED17 4 4			Erase Fault Code		Y		
308(TX9)		Engine management ECU	MED17 4 4			Live Data		Y		
308(TX9)		Engine management ECU	MED17 4 4			Actuation Test		Y		
308(TX9)		Engine management ECU	MED17 4 4			Special Function	Pack Repair	Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read ECU Information		Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read Fault Code		Y		

308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Erase Fault Code		Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Live Data		Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Actuation Test		Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Special Function	Pack Repair	Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Read ECU Information		Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Read Fault Code		Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Erase Fault Code		Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Live Data		Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Actuation Test		Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Special Function	Pack Repair	Y		
308(TX9)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
308(TX9)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
308(TX9)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
308(TX9)		Air bags and pre-tensioners control unit				Live Data		Y		
308(TX9)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
308(TX9)		Electric steering lock				Read ECU Information		Y		
308(TX9)		Electric steering lock				Read Fault Code		Y		
308(TX9)		Electric steering lock				Erase Fault Code		Y		
308(TX9)		Electric steering lock				Live Data		Y		
308(TX9)		Rain and brightness sensor				Read ECU Information		Y		
308(TX9)		Rain and brightness sensor				Read Fault Code		Y		
308(TX9)		Rain and brightness sensor				Erase Fault Code		Y		
308(TX9)		Rain and brightness sensor				Live Data		Y		
308(TX9)		Audio-navigation/telematic unit/connected audio system				Read ECU Information		Y		
308(TX9)		Audio-navigation/telematic unit/connected audio system				Read Fault Code		Y		
308(TX9)		Audio-navigation/telematic unit/connected audio system				Erase Fault Code		Y		
308(TX9)		Audio-navigation/telematic unit/connected audio system				Live Data		Y		
308(TX9)		Audio-navigation/telematic unit/connected audio system				Actuation Test		Y		
308(TX9)		Service module / Independent telematic unit				Read ECU Information		Y		
308(TX9)		Service module / Independent telematic unit				Read Fault Code		Y		
308(TX9)		Service module / Independent telematic unit				Erase Fault Code		Y		
308(TX9)		Service module / Independent telematic unit				Live Data		Y		
308(TX9)		Service module / Independent telematic unit				Actuation Test		Y		
308(TX9)		Power steering				Read ECU Information		Y		
308(TX9)		Power steering				Read Fault Code		Y		
308(TX9)		Power steering				Erase Fault Code		Y		
308(TX9)		Power steering				Live Data		Y		

308(TX9)		Multiplexed control panel	RD4450 audio system and manual air conditioning			Read ECU Information		Y		
308(TX9)		Multiplexed control panel	RD4450 audio system and manual air conditioning			Read Fault Code		Y		
308(TX9)		Multiplexed control panel	RD4450 audio system and manual air conditioning			Erase Fault Code		Y		
308(TX9)		Multiplexed control panel	RD4450 audio system and manual air conditioning			Live Data		Y		
308(TX9)		Multiplexed control panel	RD4450 audio system and manual air conditioning			Actuation Test		Y		
308(TX9)		Multiplexed control panel	Audio/Navigation NAC			Read ECU Information		Y		
308(TX9)		Multiplexed control panel	Audio/Navigation NAC			Read Fault Code		Y		
308(TX9)		Multiplexed control panel	Audio/Navigation NAC			Erase Fault Code		Y		
308(TX9)		Multiplexed control panel	Audio/Navigation NAC			Actuation Test		Y		
308(TX9)		Controls under the steering wheel				Read ECU Information		Y		
308(TX9)		Controls under the steering wheel				Read Fault Code		Y		
308(TX9)		Controls under the steering wheel				Erase Fault Code		Y		
308(TX9)		Controls under the steering wheel				Live Data		Y		
308(TX9)		Controls under the steering wheel				Actuation Test		Y		
308(TX9)		Control panel dot matrix display	Colour matrix screen			Read ECU Information		Y		
308(TX9)		Control panel dot matrix display	Colour matrix screen			Read Fault Code		Y		
308(TX9)		Control panel dot matrix display	Colour matrix screen			Erase Fault Code		Y		
308(TX9)		Control panel dot matrix display	Colour matrix screen			Actuation Test		Y		
308(TX9)		Multifunction screen	EMF C UDS			Read ECU Information		Y		
308(TX9)		Multifunction screen	EMF C UDS			Read Fault Code		Y		
308(TX9)		Multifunction screen	EMF C UDS			Erase Fault Code		Y		
308(TX9)		Multifunction screen	EMF C UDS			Actuation Test		Y		
308(TX9)		Air conditioning				Read ECU Information		Y		
308(TX9)		Air conditioning				Read Fault Code		Y		
308(TX9)		Air conditioning				Erase Fault Code		Y		
308(TX9)		Air conditioning				Live Data		Y		
308(TX9)		Air conditioning				Actuation Test		Y		
308(TX9)		Battery charge status unit				Read ECU Information		Y		
308(TX9)		Battery charge status unit				Read Fault Code		Y		
308(TX9)		Battery charge status unit				Erase Fault Code		Y		
308(TX9)		Battery charge status unit				Live Data		Y		
308(TX9)		Parking assistance	4 parking assistance			Read ECU Information		Y		
308(TX9)		Parking assistance	4 parking assistance			Read Fault Code		Y		
308(TX9)		Parking assistance	4 parking assistance			Erase Fault Code		Y		
308(TX9)		Parking assistance	4 parking assistance			Live Data		Y		
308(TX9)		Parking assistance	4 parking assistance			Actuation Test		Y		
308(TX9)		Parking assistance	10 parking assistance			Read ECU Information		Y		
308(TX9)		Parking assistance	10 parking assistance			Read Fault Code		Y		
308(TX9)		Parking assistance	10 parking assistance			Erase Fault Code		Y		
308(TX9)		Parking assistance	10 parking assistance			Live Data		Y		
308(TX9)		Parking assistance	10 parking assistance			Actuation Test		Y		
308(TX9)		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
308(TX9)		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
308(TX9)		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		

308(TX9)		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
308(TX9)		Radio				Read ECU Information		Y		
308(TX9)		Radio				Read Fault Code		Y		
308(TX9)		Radio				Erase Fault Code		Y		
308(TX9)		Radio				Live Data		Y		
308(TX9)		Radio				Actuation Test		Y		
308(TX9)		Voltage retaining device	DMTR DTC3B			Read ECU Information		Y		
308(TX9)		Voltage retaining device	DMTR DTC3B			Read Fault Code		Y		
308(TX9)		Voltage retaining device	DMTR DTC3B			Erase Fault Code		Y		
308(TX9)		Touch screen				Read ECU Information		Y		
308(TX9)		Touch screen				Read Fault Code		Y		
308(TX9)		Touch screen				Erase Fault Code		Y		
308(TX9)		Touch screen				Live Data		Y		
308(TX9)		Touch screen				Actuation Test		Y		
406		engines	Petrol	LFX MM1AP		Read ECU Information		Y		
406		engines	Petrol	LFX MM1AP		Read Fault Code		Y		
406		engines	Petrol	LFX MM1AP		Erase Fault Code		Y		
406		engines	Petrol	LFX MM1AP		Live Data		Y		
406		engines	Petrol	LFX MM1AP		Actuation Test		Y		
406		engines	Petrol	LFX BOSCH MP7.3		Read ECU Information		Y		
406		engines	Petrol	LFX BOSCH MP7.3		Read Fault Code		Y		
406		engines	Petrol	LFX BOSCH MP7.3		Erase Fault Code		Y		
406		engines	Petrol	LFX BOSCH MP7.3		Live Data		Y		
406		engines	Petrol	LFX BOSCH MP7.3		Actuation Test		Y		
406		engines	Petrol	LFY SAGEM SL 96		Read ECU Information		Y		
406		engines	Petrol	LFY SAGEM SL 96		Read Fault Code		Y		
406		engines	Petrol	LFY SAGEM SL 96		Erase Fault Code		Y		
406		engines	Petrol	LFY SAGEM SL 96		Live Data		Y		
406		engines	Petrol	LFY SAGEM SL 96		Actuation Test		Y		
406		engines	Petrol	XFZ BOSCH MP7.0		Read ECU Information		Y		
406		engines	Petrol	XFZ BOSCH MP7.0		Read Fault Code		Y		
406		engines	Petrol	XFZ BOSCH MP7.0		Erase Fault Code		Y		
406		engines	Petrol	XFZ BOSCH MP7.0		Live Data		Y		
406		engines	Petrol	XFZ BOSCH MP7.0		Actuation Test		Y		
406		engines	Diesel	P8C LUCAS EPIC		Read ECU Information		Y		
406		engines	Diesel	P8C LUCAS EPIC		Live Data		Y		
406		engines	Diesel	RHZ BOSCH EDC15C2		Read ECU Information		Y		
406		engines	Diesel	RHZ BOSCH EDC15C2		Read Fault Code		Y		
406		engines	Diesel	RHZ BOSCH EDC15C2		Erase Fault Code		Y		
406		engines	Diesel	RHZ BOSCH EDC15C2		Live Data		Y		
406		engines	Diesel	RHZ BOSCH EDC15C2		Actuation Test		Y		
406		automatic gearbox	4HP20 automatic gearbox			Read ECU Information		Y		
406		automatic gearbox	4HP20 automatic gearbox			Read Fault Code		Y		
406		automatic gearbox	4HP20 automatic gearbox			Erase Fault Code		Y		
406		automatic gearbox	4HP20 automatic gearbox			Live Data		Y		
406		automatic gearbox	4HP20 automatic gearbox			Actuation Test		Y		
406		automatic gearbox	BVA AL4 AT8			Read ECU Information		Y		
406		automatic gearbox	BVA AL4 AT8			Read Fault Code		Y		
406		automatic gearbox	BVA AL4 AT8			Erase Fault Code		Y		
406		automatic gearbox	BVA AL4 AT8			Live Data		Y		
406		automatic gearbox	BVA AL4 AT8			Actuation Test		Y		
406		Active safety	ABS5 BOSCH			Read ECU Information		Y		
406		Active safety	ABS5 BOSCH			Read Fault Code		Y		
406		Active safety	ABS5 BOSCH			Erase Fault Code		Y		
406		Active safety	ABS5 BOSCH			Live Data		Y		
406		Active safety	ABS5 BOSCH			Actuation Test		Y		
406		Active safety	ABS5 BOSCH 5.3			Read ECU Information		Y		
406		Active safety	ABS5 BOSCH 5.3			Read Fault Code		Y		
406		Active safety	ABS5 BOSCH 5.3			Erase Fault Code		Y		
406		Active safety	ABS5 BOSCH 5.3			Live Data		Y		
406		Active safety	ABS5 BOSCH 5.3			Actuation Test		Y		
406		Active safety	ABS5 BOSCH 5.3			Special Function	Bleeding	Y		
406		Airbags	Side airbag (right side)			Read ECU Information		Y		
406		Airbags	Side airbag (right side)			Read Fault Code		Y		

406		Airbags	Side airbag (right side)			Erase Fault Code		Y		
406		Airbags	Side airbag (right side)			Actuation Test		Y		
406		Airbags	Side airbag (left side)			Read ECU Information		Y		
406		Airbags	Side airbag (left side)			Read Fault Code		Y		
406		Airbags	Side airbag (left side)			Erase Fault Code		Y		
406		Airbags	Side airbag (left side)			Actuation Test		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type BFZ		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type BFZ		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type BFZ		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type BFZ		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHV		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHV		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHV		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHV		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHW		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHW		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHW		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHW		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHX		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHX		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHX		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type DHX		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type L6A		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type L6A		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type L6A		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type L6A		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFX		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFX		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFX		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFX		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.BOSCH MP5.2 system		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.BOSCH MP5.2 system		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.BOSCH MP5.2 system		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.BOSCH MP5.2 system		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.BOSCH MP7.3 system		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.BOSCH MP7.3 system		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.BOSCH MP7.3 system		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.BOSCH MP7.3 system		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.SAGEM SL96 system		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.SAGEM SL96 system		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.SAGEM SL96 system		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type LFY.SAGEM SL96 system		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type P8C		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type P8C		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type P8C		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type P8C		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type R6E		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type R6E		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type R6E		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type R6E		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RFV		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RFV		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RFV		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RFV		Live Data		Y		

406		Protect the vehicle	Transponder PEUGEOT	Engine type RGX		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RGX		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RGX		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RGX		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RHZ		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RHZ		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RHZ		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type RHZ		Live Data		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type XFZ		Read ECU Information		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type XFZ		Read Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type XFZ		Erase Fault Code		Y		
406		Protect the vehicle	Transponder PEUGEOT	Engine type XFZ		Live Data		Y		
406		Electronically managed suspension				Read ECU Information		Y		
406		Electronically managed suspension				Read Fault Code		Y		
406		Electronically managed suspension				Erase Fault Code		Y		
406		Electronically managed suspension				Live Data		Y		
406		Variable power steeringZF				Read ECU Information		Y		
406		Variable power steeringZF				Read Fault Code		Y		
406		Variable power steeringZF				Erase Fault Code		Y		
406		Seat and mirrors with memory				Read ECU Information		Y		
406		Seat and mirrors with memory				Read Fault Code		Y		
406		Seat and mirrors with memory				Erase Fault Code		Y		
406		Seat and mirrors with memory				Live Data		Y		
406 COUPE		engines	Petrol	XFZ BOSCH MP7.0		Read ECU Information		Y		
406 COUPE		engines	Petrol	XFZ BOSCH MP7.0		Read Fault Code		Y		
406 COUPE		engines	Petrol	XFZ BOSCH MP7.0		Erase Fault Code		Y		
406 COUPE		engines	Petrol	XFZ BOSCH MP7.0		Live Data		Y		
406 COUPE		engines	Petrol	XFZ BOSCH MP7.0		Actuation Test		Y		
406 COUPE		Airbags	Side airbag (right side)			Read ECU Information		Y		
406 COUPE		Airbags	Side airbag (right side)			Read Fault Code		Y		
406 COUPE		Airbags	Side airbag (right side)			Erase Fault Code		Y		
406 COUPE		Airbags	Side airbag (right side)			Actuation Test		Y		
406 COUPE		Airbags	Side airbag (left side)			Read ECU Information		Y		
406 COUPE		Airbags	Side airbag (left side)			Read Fault Code		Y		
406 COUPE		Airbags	Side airbag (left side)			Erase Fault Code		Y		
406 COUPE		Airbags	Side airbag (left side)			Actuation Test		Y		
406 COUPE		Transponder PEUGEOT	Engine type R6E			Read ECU Information		Y		
406 COUPE		Transponder PEUGEOT	Engine type R6E			Read Fault Code		Y		
406 COUPE		Transponder PEUGEOT	Engine type R6E			Erase Fault Code		Y		
406 COUPE		Transponder PEUGEOT	Engine type R6E			Live Data		Y		
406 COUPE		Transponder PEUGEOT	Engine type RFV			Read ECU Information		Y		
406 COUPE		Transponder PEUGEOT	Engine type RFV			Read Fault Code		Y		
406 COUPE		Transponder PEUGEOT	Engine type RFV			Erase Fault Code		Y		
406 COUPE		Transponder PEUGEOT	Engine type RFV			Live Data		Y		
406 COUPE		Transponder PEUGEOT	Engine type XFZ			Read ECU Information		Y		
406 COUPE		Transponder PEUGEOT	Engine type XFZ			Read Fault Code		Y		
406 COUPE		Transponder PEUGEOT	Engine type XFZ			Erase Fault Code		Y		
406 COUPE		Transponder PEUGEOT	Engine type XFZ			Live Data		Y		
406 COUPE		Variable power steeringZF				Read ECU Information		Y		
406 COUPE		Variable power steeringZF				Read Fault Code		Y		
406 COUPE		Variable power steeringZF				Erase Fault Code		Y		
406 COUPE		Seat and mirrors with memory				Read ECU Information		Y		
406 COUPE		Seat and mirrors with memory				Read Fault Code		Y		
406 COUPE		Seat and mirrors with memory				Erase Fault Code		Y		
406 COUPE		Seat and mirrors with memory				Live Data		Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		

406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Live Data		Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
406R	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 1		Read ECU Information		Y		
406R	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 1		Read Fault Code		Y		
406R	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 1		Erase Fault Code		Y		
406R	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 1		Live Data		Y		
406R	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Read ECU Information		Y		
406R	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Read Fault Code		Y		
406R	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Erase Fault Code		Y		
406R	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Live Data		Y		
406R	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Actuation Test		Y		
406R	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Special Function	Initialising the autoadaptives	Y		
406R	Production date before 30 June 2001	automatic gearbox	BVA AL4 AT8			Read ECU Information		Y		
406R	Production date before 30 June 2001	automatic gearbox	BVA AL4 AT8			Read Fault Code		Y		
406R	Production date before 30 June 2001	automatic gearbox	BVA AL4 AT8			Erase Fault Code		Y		
406R	Production date before 30 June 2001	automatic gearbox	BVA AL4 AT8			Live Data		Y		
406R	Production date before 30 June 2001	automatic gearbox	BVA AL4 AT8			Actuation Test		Y		
406R	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Read ECU Information		Y		
406R	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Read Fault Code		Y		
406R	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Erase Fault Code		Y		
406R	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Live Data		Y		
406R	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Actuation Test		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Read ECU Information		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Read Fault Code		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Erase Fault Code		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Live Data		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Actuation Test		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Calibration of the steering wheel angle sensor	Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	De-calibration of the steering wheel angle sensor	Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Bleeding	Y		
406R	Production date before 30 June 2001	Airbags	Air bag and seat belt			Read ECU Information		Y		
406R	Production date before 30 June 2001	Airbags	Air bag and seat belt			Read Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Air bag and seat belt			Erase Fault Code		Y		

406R	Production date before 30 June 2001	Airbags	Side airbag (right side)			Read ECU Information		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (right side)			Read Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (right side)			Erase Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (right side)			Actuation Test		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (left side)			Read ECU Information		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (left side)			Read Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (left side)			Erase Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (left side)			Actuation Test		Y		
406R	Production date before 30 June 2001	Multifunction display				Read ECU Information		Y		
406R	Production date before 30 June 2001	Multifunction display				Read Fault Code		Y		
406R	Production date before 30 June 2001	Multifunction display				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Multifunction display				Live Data		Y		
406R	Production date before 30 June 2001	Multifunction display				Actuation Test		Y		
406R	Production date before 30 June 2001	Radio				Read ECU Information		Y		
406R	Production date before 30 June 2001	Radio				Read Fault Code		Y		
406R	Production date before 30 June 2001	Radio				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Radio				Live Data		Y		
406R	Production date before 30 June 2001	Radio				Actuation Test		Y		
406R	Production date before 30 June 2001	CD player				Read ECU Information		Y		
406R	Production date before 30 June 2001	CD player				Read Fault Code		Y		
406R	Production date before 30 June 2001	CD player				Erase Fault Code		Y		
406R	Production date before 30 June 2001	CD player				Live Data		Y		
406R	Production date before 30 June 2001	CD player				Actuation Test		Y		
406R	Production date before 30 June 2001	Instrument panel				Read ECU Information		Y		
406R	Production date before 30 June 2001	Instrument panel				Read Fault Code		Y		
406R	Production date before 30 June 2001	Instrument panel				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Instrument panel				Live Data		Y		
406R	Production date before 30 June 2001	On-board navigation system				Read ECU Information		Y		
406R	Production date before 30 June 2001	On-board navigation system				Read Fault Code		Y		
406R	Production date before 30 June 2001	On-board navigation system				Erase Fault Code		Y		
406R	Production date before 30 June 2001	On-board navigation system				Live Data		Y		
406R	Production date before 30 June 2001	heating/ventilation				Read ECU Information		Y		
406R	Production date before 30 June 2001	heating/ventilation				Read Fault Code		Y		

406R	Production date before 30 June 2001	heating/ventilation				Erase Fault Code		Y		
406R	Production date before 30 June 2001	heating/ventilation				Live Data		Y		
406R	Production date before 30 June 2001	heating/ventilation				Actuation Test		Y		
406R	Production date before 30 June 2001	Electronically managed suspension				Read ECU Information		Y		
406R	Production date before 30 June 2001	Electronically managed suspension				Read Fault Code		Y		
406R	Production date before 30 June 2001	Electronically managed suspension				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Electronically managed suspension				Live Data		Y		
406R	Production date before 30 June 2001	Variable power steering				Read ECU Information		Y		
406R	Production date before 30 June 2001	Variable power steering				Read Fault Code		Y		
406R	Production date before 30 June 2001	Variable power steering				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Seat position memory ECU				Read ECU Information		Y		
406R	Production date before 30 June 2001	Seat position memory ECU				Read Fault Code		Y		
406R	Production date before 30 June 2001	Seat position memory ECU				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Seat position memory ECU				Live Data		Y		
406R	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
406R	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
406R	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
406R	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Live Data		Y		
406R	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Read ECU Information		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Read Fault Code		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Erase Fault Code		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Live Data		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Actuation Test		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Special Function	Bleeding	Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Read ECU Information		Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Read Fault Code		Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Erase Fault Code		Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Live Data		Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Actuation Test		Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Calibration of the steering wheel angle sensor	Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	De-calibration of the steering wheel angle sensor	Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Bleeding	Y		

406R	Production date after 30 June 2001	Airbags				Read ECU Information		Y		
406R	Production date after 30 June 2001	Airbags				Read Fault Code		Y		
406R	Production date after 30 June 2001	Airbags				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Programming of the built-in systems interface (Engine immobiliser code and keys)				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
406R	Production date after 30 June 2001	alarm				Read ECU Information		Y		
406R	Production date after 30 June 2001	alarm				Read Fault Code		Y		
406R	Production date after 30 June 2001	alarm				Erase Fault Code		Y		
406R	Production date after 30 June 2001	alarm				Live Data		Y		
406R	Production date after 30 June 2001	alarm				Actuation Test		Y		
406R	Production date after 30 June 2001	Multifunction display				Read ECU Information		Y		
406R	Production date after 30 June 2001	Multifunction display				Read Fault Code		Y		
406R	Production date after 30 June 2001	Multifunction display				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Multifunction display				Live Data		Y		
406R	Production date after 30 June 2001	Multifunction display				Actuation Test		Y		
406R	Production date after 30 June 2001	Instrument panel				Read ECU Information		Y		
406R	Production date after 30 June 2001	Instrument panel				Read Fault Code		Y		
406R	Production date after 30 June 2001	Instrument panel				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Instrument panel				Live Data		Y		
406R	Production date after 30 June 2001	Instrument panel				Actuation Test		Y		
406R	Production date after 30 June 2001	Radio				Read ECU Information		Y		
406R	Production date after 30 June 2001	Radio				Read Fault Code		Y		
406R	Production date after 30 June 2001	Radio				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Radio				Live Data		Y		
406R	Production date after 30 June 2001	Radio				Actuation Test		Y		
406R	Production date after 30 June 2001	CD player				Read ECU Information		Y		
406R	Production date after 30 June 2001	CD player				Read Fault Code		Y		
406R	Production date after 30 June 2001	CD player				Erase Fault Code		Y		
406R	Production date after 30 June 2001	CD player				Live Data		Y		
406R	Production date after 30 June 2001	CD player				Actuation Test		Y		
406R	Production date after 30 June 2001	On-board navigation system				Read ECU Information		Y		
406R	Production date after 30 June 2001	On-board navigation system				Read Fault Code		Y		
406R	Production date after 30 June 2001	On-board navigation system				Erase Fault Code		Y		

406R	Production date after 30 June 2001	On-board navigation system				Live Data		Y		
406R	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Read ECU Information		Y		
406R	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Read Fault Code		Y		
406R	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Live Data		Y		
406R	Production date after 30 June 2001	Rain/sunlight sensor				Read ECU Information		Y		
406R	Production date after 30 June 2001	Rain/sunlight sensor				Read Fault Code		Y		
406R	Production date after 30 June 2001	Rain/sunlight sensor				Erase Fault Code		Y		
406R	Production date after 30 June 2001	heating/ventilation				Read ECU Information		Y		
406R	Production date after 30 June 2001	heating/ventilation				Read Fault Code		Y		
406R	Production date after 30 June 2001	heating/ventilation				Erase Fault Code		Y		
406R	Production date after 30 June 2001	heating/ventilation				Live Data		Y		
406R	Production date after 30 June 2001	heating/ventilation				Actuation Test		Y		
406R	Production date after 30 June 2001	Diesel fuel additive control unit				Read ECU Information		Y		
406R	Production date after 30 June 2001	Diesel fuel additive control unit				Read Fault Code		Y		
406R	Production date after 30 June 2001	Diesel fuel additive control unit				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Diesel fuel additive control unit				Live Data		Y		
406R	Production date after 30 June 2001	Diesel fuel additive control unit				Actuation Test		Y		
406R	Production date after 30 June 2001	Variable power steering				Read ECU Information		Y		
406R	Production date after 30 June 2001	Variable power steering				Read Fault Code		Y		
406R	Production date after 30 June 2001	Variable power steering				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Seat position memory ECU				Read ECU Information		Y		
406R	Production date after 30 June 2001	Seat position memory ECU				Read Fault Code		Y		
406R	Production date after 30 June 2001	Seat position memory ECU				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Seat position memory ECU				Live Data		Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Live Data		Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 1		Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 1		Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 1		Erase Fault Code		Y		

406R COUPE	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 1		Live Data		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Live Data		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	4HP20 automatic gearbox	4HP20 2		Special Function	Initialising the autoadaptives	Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	BVA AL4 AT8			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	BVA AL4 AT8			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	BVA AL4 AT8			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	BVA AL4 AT8			Live Data		Y		
406R COUPE	Production date before 30 June 2001	automatic gearbox	BVA AL4 AT8			Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Live Data		Y		
406R COUPE	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Live Data		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Calibration of the steering wheel angle sensor	Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	De-calibration of the steering wheel angle sensor	Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Bleeding	Y		
406R COUPE	Production date before 30 June 2001	Airbags	Air bag and seat belt			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Air bag and seat belt			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Air bag and seat belt			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (right side)			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (right side)			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (right side)			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (right side)			Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (left side)			Read ECU Information		Y		

406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (left side)			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (left side)			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (left side)			Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Multifunction display				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Multifunction display				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Multifunction display				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Multifunction display				Live Data		Y		
406R COUPE	Production date before 30 June 2001	Multifunction display				Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Radio				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Radio				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Radio				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Radio				Live Data		Y		
406R COUPE	Production date before 30 June 2001	Radio				Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	CD player				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	CD player				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	CD player				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	CD player				Live Data		Y		
406R COUPE	Production date before 30 June 2001	CD player				Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Instrument panel				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Instrument panel				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Instrument panel				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Instrument panel				Live Data		Y		
406R COUPE	Production date before 30 June 2001	On-board navigation system				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	On-board navigation system				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	On-board navigation system				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	On-board navigation system				Live Data		Y		
406R COUPE	Production date before 30 June 2001	heating/ventilation				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	heating/ventilation				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	heating/ventilation				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	heating/ventilation				Live Data		Y		
406R COUPE	Production date before 30 June 2001	heating/ventilation				Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Electronically managed suspension				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Electronically managed suspension				Read Fault Code		Y		

406R COUPE	Production date before 30 June 2001	Electronically managed suspension				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Electronically managed suspension				Live Data		Y		
406R COUPE	Production date before 30 June 2001	Variable power steering				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Variable power steering				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Variable power steering				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Seat position memory ECU				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Seat position memory ECU				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Seat position memory ECU				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Seat position memory ECU				Live Data		Y		
406R COUPE	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Live Data		Y		
406R COUPE	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Live Data		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Special Function	Bleeding	Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Live Data		Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Calibration of the steering wheel angle sensor	Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	De-calibration of the steering wheel angle sensor	Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Bleeding	Y		
406R COUPE	Production date after 30 June 2001	Airbags				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Airbags				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Airbags				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Programming of the built-in systems interface (Engine immobiliser code and keys)				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		

406R COUPE	Production date after 30 June 2001	alarm				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	alarm				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	alarm				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	alarm				Live Data		Y		
406R COUPE	Production date after 30 June 2001	alarm				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Multifunction display				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Multifunction display				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Multifunction display				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Multifunction display				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Multifunction display				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Instrument panel				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Instrument panel				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Instrument panel				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Instrument panel				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Instrument panel				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Radio				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Radio				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Radio				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Radio				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Radio				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	CD player				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	CD player				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	CD player				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	CD player				Live Data		Y		
406R COUPE	Production date after 30 June 2001	CD player				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	On-board navigation system				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	On-board navigation system				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	On-board navigation system				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	On-board navigation system				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Live Data		Y		

406R COUPE	Production date after 30 June 2001	Rain/sunlight sensor				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Rain/sunlight sensor				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Rain/sunlight sensor				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	heating/ventilation				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	heating/ventilation				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	heating/ventilation				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	heating/ventilation				Live Data		Y		
406R COUPE	Production date after 30 June 2001	heating/ventilation				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Diesel fuel additive control unit				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Diesel fuel additive control unit				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Diesel fuel additive control unit				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Diesel fuel additive control unit				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Diesel fuel additive control unit				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Variable power steering				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Variable power steering				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Variable power steering				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Seat position memory ECU				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Seat position memory ECU				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Seat position memory ECU				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Seat position memory ECU				Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Special Function	Changing the modeElectrical	Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Special Function	Learning	Y		
407		407 saloon or estate fitted with an old generation BSI	Airbag ECU			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Airbag ECU			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Airbag ECU			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Airbag ECU			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Parking aid			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Parking aid			Read Fault Code		Y		

407		407 saloon or estate fitted with an old generation BSI	Parking aid			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Parking aid			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Parking aid			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Drivers seat memory unit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Drivers seat memory unit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Drivers seat memory unit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Drivers seat memory unit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Drivers seat memory unit			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger seat memorisation module			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger seat memorisation module			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger seat memorisation module			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger seat memorisation module			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger seat memorisation module			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Additional heating			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Additional heating			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Additional heating			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Additional heating			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Additional heating			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Under inflation detection			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Under inflation detection			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Under inflation detection			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Under inflation detection			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Under inflation detection			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Power steering			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Power steering			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Power steering			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Power steering			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Power steering			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Piloted suspension			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Piloted suspension			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Piloted suspension			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Piloted suspension			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Battery charge status unit			Read ECU Information		Y		

407		407 saloon or estate fitted with an old generation BSI	Battery charge status unit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Battery charge status unit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Battery charge status unit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Stop and Start battery charge status unit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Stop and Start battery charge status unit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Stop and Start battery charge status unit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Stop and Start battery charge status unit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Multifunction display			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Multifunction display			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Multifunction display			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Multifunction display			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Multifunction display			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Radio			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Radio			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Radio			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Radio			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Radio			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	CD player			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	CD player			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	CD player			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	CD player			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Special Function	Maintenance	Y		
407		407 saloon or estate fitted with an old generation BSI	Hands Free Kit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Hands Free Kit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Hands Free Kit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Hands Free Kit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Hands Free Kit			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Switch module at the steering wheel			Read ECU Information		Y		

407		407 saloon or estate fitted with an old generation BSI	Switch module at the steering wheel			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Switch module at the steering wheel			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Switch module at the steering wheel			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Switch module at the steering wheel			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	High frequency receiver			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	High frequency receiver			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	High frequency receiver			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	High frequency receiver			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Portable unit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Portable unit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Portable unit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Portable unit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Portable unit			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Diesel fuel additive control unit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Diesel fuel additive control unit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Diesel fuel additive control unit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Diesel fuel additive control unit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Diesel fuel additive control unit			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	alarm			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	alarm			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	alarm			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	alarm			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	alarm			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Driver's door module			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Driver's door module			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Driver's door module			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Driver's door module			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Driver's door module			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger door module			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger door module			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger door module			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger door module			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger door module			Actuation Test		Y		

407		407 saloon or estate fitted with an old generation BSI	Sun roof			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Sun roof			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Sun roof			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Sun roof			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Sun roof			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Control unit windscreen wipers			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Control unit windscreen wipers			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Control unit windscreen wipers			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Control unit windscreen wipers			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Control unit windscreen wipers			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Rain/sunlight sensor			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Rain/sunlight sensor			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Rain/sunlight sensor			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Special Function	Calibration	Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Special Function	Calibration	Y		
407		407 hatchback or estate fitted with a cross range	BSI(Built-in Systems Interface)			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	BSI(Built-in Systems Interface)			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	BSI(Built-in Systems Interface)			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	BSI(Built-in Systems Interface)			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	BSI(Built-in Systems Interface)			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	BSI(Built-in Systems Interface)			Special Function	Changing the modeElectrical	Y		
407		407 hatchback or estate fitted with a cross range	BSI(Built-in Systems Interface)			Special Function	Learning	Y		
407		407 hatchback or estate fitted with a cross range	Airbag ECU			Read ECU Information		Y		

407		407 hatchback or estate fitted with a cross range	Airbag ECU			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Airbag ECU			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Airbag ECU			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Parking aid			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Parking aid			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Parking aid			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Parking aid			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Parking aid			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Drivers seat memory unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Drivers seat memory unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Drivers seat memory unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Drivers seat memory unit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Drivers seat memory unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Passenger seat memorisation module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Passenger seat memorisation module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Passenger seat memorisation module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Passenger seat memorisation module			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Passenger seat memorisation module			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Additional heating			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Additional heating			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Additional heating			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Additional heating			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Additional heating			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Under inflation detection			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Under inflation detection			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Under inflation detection			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Under inflation detection			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Under inflation detection			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Power steering			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Power steering			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Power steering			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Power steering			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Power steering			Actuation Test		Y		

407		407 hatchback or estate fitted with a cross range	Piloted suspension			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Piloted suspension			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Piloted suspension			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Piloted suspension			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Battery charge status unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Battery charge status unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Battery charge status unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Battery charge status unit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Stop and Start battery charge status unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Stop and Start battery charge status unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Stop and Start battery charge status unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Stop and Start battery charge status unit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Multifunction display			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Multifunction display			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Multifunction display			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Multifunction display			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Multifunction display			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Radio			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Radio			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Radio			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Radio			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Radio			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	CD player			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	CD player			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	CD player			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	CD player			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Instrument panel			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Instrument panel			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Instrument panel			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Instrument panel			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Instrument panel			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Instrument panel			Special Function	Maintenance	Y		
407		407 hatchback or estate fitted with a cross range	Hands Free Kit			Read ECU Information		Y		

407		407 hatchback or estate fitted with a cross range	Hands Free Kit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Hands Free Kit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Hands Free Kit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Hands Free Kit			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Switch module at the steering wheel			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Switch module at the steering wheel			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Switch module at the steering wheel			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Switch module at the steering wheel			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Switch module at the steering wheel			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	High frequency receiver			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	High frequency receiver			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	High frequency receiver			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	High frequency receiver			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Portable unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Portable unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Portable unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Portable unit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Portable unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Diesel fuel additive control unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Diesel fuel additive control unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Diesel fuel additive control unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Diesel fuel additive control unit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Diesel fuel additive control unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	alarm			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	alarm			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	alarm			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	alarm			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	alarm			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Driver's door module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Driver's door module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Driver's door module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Driver's door module			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Driver's door module			Actuation Test		Y		

407		407 hatchback or estate fitted with a cross range	Passenger door module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Passenger door module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Passenger door module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Passenger door module			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Passenger door module			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Sun roof			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Sun roof			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Sun roof			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Sun roof			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Sun roof			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Control unit windscreen wipers			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Control unit windscreen wipers			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Control unit windscreen wipers			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Control unit windscreen wipers			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Control unit windscreen wipers			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Rain/sunlight sensor			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Rain/sunlight sensor			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Rain/sunlight sensor			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Master discharge bulb			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Master discharge bulb			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Master discharge bulb			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Master discharge bulb			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Master discharge bulb			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Master discharge bulb			Special Function	Calibration	Y		
407		407 hatchback or estate fitted with a cross range	Slave discharge bulb			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range	Slave discharge bulb			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Slave discharge bulb			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range	Slave discharge bulb			Live Data		Y		
407		407 hatchback or estate fitted with a cross range	Slave discharge bulb			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range	Slave discharge bulb			Special Function	Calibration	Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Erase Fault Code		Y		

407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Live Data		Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Special Function	Changing the modeElectrical	Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Special Function	Learning	Y		
407		407 coupé fitted with a cross range BSI	Airbag ECU			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Airbag ECU			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Airbag ECU			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Airbag ECU			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Parking aid			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Parking aid			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Parking aid			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Parking aid			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Parking aid			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Drivers seat memory unit			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Drivers seat memory unit			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Drivers seat memory unit			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Drivers seat memory unit			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Drivers seat memory unit			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Passenger seat memorisation module			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Passenger seat memorisation module			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Passenger seat memorisation module			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Passenger seat memorisation module			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Passenger seat memorisation module			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Additional heating			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Additional heating			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Additional heating			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Additional heating			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Additional heating			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Under inflation detection			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Under inflation detection			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Under inflation detection			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Under inflation detection			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Under inflation detection			Actuation Test		Y		

407		407 coupé fitted with a cross range BSI	Power steering			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Power steering			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Power steering			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Power steering			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Power steering			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Piloted suspension			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Piloted suspension			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Piloted suspension			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Piloted suspension			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Battery charge status unit			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Battery charge status unit			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Battery charge status unit			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Battery charge status unit			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Multifunction display			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Multifunction display			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Multifunction display			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Multifunction display			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Multifunction display			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Radio			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Radio			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Radio			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Radio			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Radio			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	CD player			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	CD player			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	CD player			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	CD player			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Special Function	Maintenance	Y		

407		407 coupé fitted with a cross range BSI	Switch module at the steering wheel			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Switch module at the steering wheel			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Switch module at the steering wheel			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Switch module at the steering wheel			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Switch module at the steering wheel			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Hands Free Kit			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Hands Free Kit			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Hands Free Kit			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Hands Free Kit			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Hands Free Kit			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	High frequency receiver			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	High frequency receiver			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	High frequency receiver			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	High frequency receiver			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Portable unit			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Portable unit			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Portable unit			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Portable unit			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Portable unit			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Diesel fuel additive control unit			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Diesel fuel additive control unit			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Diesel fuel additive control unit			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Diesel fuel additive control unit			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Diesel fuel additive control unit			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	alarm			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	alarm			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	alarm			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	alarm			Live Data		Y		
407		407 coupé fitted with a cross range BSI	alarm			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Driver's door module			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Driver's door module			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Driver's door module			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Driver's door module			Live Data		Y		

407		407 coupé fitted with a cross range BSI	Driver's door module			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Passenger door module			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Passenger door module			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Passenger door module			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Passenger door module			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Passenger door module			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Control unit windscreen wipers			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Control unit windscreen wipers			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Control unit windscreen wipers			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Control unit windscreen wipers			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Control unit windscreen wipers			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Rain/sunlight sensor			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Rain/sunlight sensor			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Rain/sunlight sensor			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Special Function	Changing the modeElectrical	Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Special Function	Learning	Y		
407		407 hatchback or estate fitted with a modified BSI	Airbag ECU			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Airbag ECU			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Airbag ECU			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Airbag ECU			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Parking aid			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Parking aid			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Parking aid			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Parking aid			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Parking aid			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Drivers seat memory unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Drivers seat memory unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Drivers seat memory unit			Erase Fault Code		Y		

407		407 hatchback or estate fitted with a modified BSI	Drivers seat memory unit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Drivers seat memory unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger seat memorisation module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger seat memorisation module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger seat memorisation module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger seat memorisation module			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger seat memorisation module			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Additional heating			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Additional heating			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Additional heating			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Additional heating			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Additional heating			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Under inflation detection			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Under inflation detection			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Under inflation detection			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Under inflation detection			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Under inflation detection			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Power steering			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Power steering			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Power steering			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Power steering			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Power steering			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Piloted suspension			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Piloted suspension			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Piloted suspension			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Piloted suspension			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Battery charge status unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Battery charge status unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Battery charge status unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Battery charge status unit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Stop and Start battery charge status unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Stop and Start battery charge status unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Stop and Start battery charge status unit			Erase Fault Code		Y		

407		407 hatchback or estate fitted with a modified BSI	Stop and Start battery charge status unit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Multifunction display			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Multifunction display			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Multifunction display			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Multifunction display			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Multifunction display			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Radio			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Radio			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Radio			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Radio			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Radio			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	CD player			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	CD player			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	CD player			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	CD player			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Special Function	Maintenance	Y		
407		407 hatchback or estate fitted with a modified BSI	Hands Free Kit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Hands Free Kit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Hands Free Kit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Hands Free Kit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Hands Free Kit			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Switch module at the steering wheel			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Switch module at the steering wheel			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Switch module at the steering wheel			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Switch module at the steering wheel			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Switch module at the steering wheel			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	High frequency receiver			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	High frequency receiver			Read Fault Code		Y		

407		407 hatchback or estate fitted with a modified BSI	High frequency receiver			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	High frequency receiver			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Portable unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Portable unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Portable unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Portable unit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Portable unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Diesel fuel additive control unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Diesel fuel additive control unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Diesel fuel additive control unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Diesel fuel additive control unit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Diesel fuel additive control unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	alarm			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	alarm			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	alarm			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	alarm			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	alarm			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Driver's door module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Driver's door module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Driver's door module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Driver's door module			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Driver's door module			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger door module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger door module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger door module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger door module			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger door module			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Sun roof			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Sun roof			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Sun roof			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Sun roof			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Sun roof			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Control unit windscreen wipers			Read ECU Information		Y		

407		407 hatchback or estate fitted with a modified BSI	Control unit windscreen wipers			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Control unit windscreen wipers			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Control unit windscreen wipers			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Control unit windscreen wipers			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Rain/sunlight sensor			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Rain/sunlight sensor			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Rain/sunlight sensor			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Special Function	Calibration	Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Special Function	Calibration	Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Live Data		Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Special Function	Changing the modeElectrical	Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Special Function	Learning	Y		
407		407 coupé fitted with a modified BSI	Airbag ECU			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Airbag ECU			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Airbag ECU			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Airbag ECU			Live Data		Y		
407		407 coupé fitted with a modified BSI	Parking aid			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Parking aid			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Parking aid			Erase Fault Code		Y		

407		407 coupé fitted with a modified BSI	Parking aid			Live Data		Y		
407		407 coupé fitted with a modified BSI	Parking aid			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Drivers seat memory unit			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Drivers seat memory unit			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Drivers seat memory unit			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Drivers seat memory unit			Live Data		Y		
407		407 coupé fitted with a modified BSI	Drivers seat memory unit			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Passenger seat memorisation module			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Passenger seat memorisation module			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Passenger seat memorisation module			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Passenger seat memorisation module			Live Data		Y		
407		407 coupé fitted with a modified BSI	Passenger seat memorisation module			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Additional heating			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Additional heating			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Additional heating			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Additional heating			Live Data		Y		
407		407 coupé fitted with a modified BSI	Additional heating			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Under inflation detection			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Under inflation detection			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Under inflation detection			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Under inflation detection			Live Data		Y		
407		407 coupé fitted with a modified BSI	Under inflation detection			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Power steering			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Power steering			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Power steering			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Power steering			Live Data		Y		
407		407 coupé fitted with a modified BSI	Power steering			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Piloted suspension			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Piloted suspension			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Piloted suspension			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Piloted suspension			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Battery charge status unit			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Battery charge status unit			Read Fault Code		Y		

407		407 coupé fitted with a modified BSI	Battery charge status unit			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Battery charge status unit			Live Data		Y		
407		407 coupé fitted with a modified BSI	Multifunction display			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Multifunction display			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Multifunction display			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Multifunction display			Live Data		Y		
407		407 coupé fitted with a modified BSI	Multifunction display			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Radio			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Radio			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Radio			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Radio			Live Data		Y		
407		407 coupé fitted with a modified BSI	Radio			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	CD player			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	CD player			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	CD player			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	CD player			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Live Data		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Special Function	Maintenance	Y		
407		407 coupé fitted with a modified BSI	Switch module at the steering wheel			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Switch module at the steering wheel			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Switch module at the steering wheel			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Switch module at the steering wheel			Live Data		Y		
407		407 coupé fitted with a modified BSI	Switch module at the steering wheel			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Hands Free Kit			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Hands Free Kit			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Hands Free Kit			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Hands Free Kit			Live Data		Y		
407		407 coupé fitted with a modified BSI	Hands Free Kit			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	High frequency receiver			Read ECU Information		Y		

407		407 coupé fitted with a modified BSI	High frequency receiver			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	High frequency receiver			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	High frequency receiver			Live Data		Y		
407		407 coupé fitted with a modified BSI	Portable unit			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Portable unit			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Portable unit			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Portable unit			Live Data		Y		
407		407 coupé fitted with a modified BSI	Portable unit			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Diesel fuel additive control unit			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Diesel fuel additive control unit			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Diesel fuel additive control unit			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Diesel fuel additive control unit			Live Data		Y		
407		407 coupé fitted with a modified BSI	Diesel fuel additive control unit			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	alarm			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	alarm			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	alarm			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	alarm			Live Data		Y		
407		407 coupé fitted with a modified BSI	alarm			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Driver's door module			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Driver's door module			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Driver's door module			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Driver's door module			Live Data		Y		
407		407 coupé fitted with a modified BSI	Driver's door module			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Passenger door module			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Passenger door module			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Passenger door module			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Passenger door module			Live Data		Y		
407		407 coupé fitted with a modified BSI	Passenger door module			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Control unit windscreen wipers			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Control unit windscreen wipers			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Control unit windscreen wipers			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Control unit windscreen wipers			Live Data		Y		
407		407 coupé fitted with a modified BSI	Control unit windscreen wipers			Actuation Test		Y		

407		407 coupé fitted with a modified BSI	Rain/sunlight sensor			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Rain/sunlight sensor			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Rain/sunlight sensor			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Special Function	Changing the modeElectrical	Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Special Function	Learning	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FY	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FT	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Read Fault Code		Y		

408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 5FN	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO4	MED17_4_EURO4 8FP	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 8FS	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 8FS	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 8FS	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 8FS	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO4	MEV17_4_EURO4 8FS	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6B	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Actuation Test		Y		

408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 N6A	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745	ME745 NFU	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FR	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 EURO5	MEV17_4_EURO5 8FP	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Read Fault Code		Y		

408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEVD17 4 2	5FU MEVD17.4.2 EURO 5	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6C	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP6CM	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Erase Fault Code		Y		

408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	MEV17 4 2	MEV17 4 2 EP3C	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	petrol	ME745 EC5		Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read Fault Code		Y		

408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Pack Repair	Y		

408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HP-DV6DTED-92 CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10 BR2	9HJ-DV6DTED-90 CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Actuation Test		Y		

408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AT8			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA AM6			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		

408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC AUTOLIV			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC AUTOLIV			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC AUTOLIV			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC AUTOLIV			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC AUTOLIV			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Power steering				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Power steering				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Power steering				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Power steering				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Power steering				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Read ECU Information		Y		

408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX MGI			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX MGI			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX MGI			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX MGI			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX TI			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX TI			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX TI			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX TI			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE MUX TI			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Under inflation detection				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Under inflation detection				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Under inflation detection				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Under inflation detection				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB GEN2			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB GEN2			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine relay unit				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine relay unit				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine relay unit				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine relay unit				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Trailer relay unit				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Trailer relay unit				Read Fault Code		Y		

408(T73)(2010.01 - 2014.09)		Trailer relay unit				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)With buttons			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)With buttons			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)With buttons			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)With buttons			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)With buttons			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)Without button			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)Without button			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)Without button			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)Without button			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'A' (segments)Without button			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'C' (dot matrix)			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'C' (dot matrix)			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'C' (dot matrix)			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'C' (dot matrix)			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'C' (dot matrix)			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'C colour' (dot matrix)			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'C colour' (dot matrix)			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'C colour' (dot matrix)			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'C colour' (dot matrix)			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type 'C colour' (dot matrix)			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Windscreen wiper				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Windscreen wiper				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Parking assistance	Parking aid			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Parking assistance	Parking aid			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Parking assistance	Parking aid			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Parking assistance	Parking aid			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Read ECU Information		Y		

408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		CD changer / external CD player				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		CD changer / external CD player				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		CD changer / external CD player				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		CD changer / external CD player				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Actuation Test		Y		

408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Radio amplifier				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Radio amplifier				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio amplifier				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio amplifier				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER NOMADE			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER NOMADE			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER NOMADE			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER NOMADE			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER NOMADE			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Live Data		Y		

408(T73)(2010.01 - 2014.09)		Radio	RD45			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module.				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module.				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module.				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module.				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module.				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module.				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module.				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module.				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module.				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module.				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Driver's door module	Driver's door module			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Driver's door module	Driver's door module			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Driver's door module	Driver's door module			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Driver's door module	Driver's door module			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Driver's door module	Driver's door module			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Sun roof				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Sun roof				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Sun roof				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Sun roof				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Sun roof				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Moving panel deflector				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Moving panel deflector				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Moving panel deflector				Erase Fault Code		Y		

408(T73)(2010.01 - 2014.09)		Moving panel deflector				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Moving panel deflector				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Rain and light sensor				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Rain and light sensor				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Rain and light sensor				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Seat belt not fastened warning lights unit				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Seat belt not fastened warning lights unit				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		High frequency receiver				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		High frequency receiver				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		High frequency receiver				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		High frequency receiver				Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	Yes		Read ECU Information		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	Yes		Read Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	Yes		Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	Yes		Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	Yes		Actuation Test		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	Yes		Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		

408(T93)(After 2014.09)		Engine management ECU	V46 32	Yes		Special Function	Initialisation of the autoadaptive values	Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	Yes		Special Function	Replacement parts	Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	NO		Read ECU Information		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	NO		Read Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	NO		Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	NO		Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	NO		Actuation Test		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	NO		Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	NO		Special Function	Initialisation of the autoadaptive values	Y		
408(T93)(After 2014.09)		Engine management ECU	V46 32	NO		Special Function	Replacement parts	Y		
408(T93)(After 2014.09)		Engine management ECU	V46 52			Read ECU Information		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 52			Read Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 52			Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 52			Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 52			Actuation Test		Y		
408(T93)(After 2014.09)		Engine management ECU	V46 52			Special Function	Initialisation of the autoadaptive values	Y		
408(T93)(After 2014.09)		Engine management ECU	V46 52			Special Function	Replacement parts	Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Read ECU Information		Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Read Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Actuation Test		Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Engine management ECU	MED17 4 4			Read ECU Information		Y		
408(T93)(After 2014.09)		Engine management ECU	MED17 4 4			Read Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	MED17 4 4			Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	MED17 4 4			Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	MED17 4 4			Actuation Test		Y		
408(T93)(After 2014.09)		Engine management ECU	MED17 4 4			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Read ECU Information		Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Read Fault Code		Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Erase Fault Code		Y		

408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Live Data		Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Actuation Test		Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read ECU Information		Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read Fault Code		Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Erase Fault Code		Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Live Data		Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Actuation Test		Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
408(T93)(After 2014.09)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
408(T93)(After 2014.09)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
408(T93)(After 2014.09)		Air bags and pre-tensioners control unit				Live Data		Y		
408(T93)(After 2014.09)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Engine relay unit				Read ECU Information		Y		
408(T93)(After 2014.09)		Engine relay unit				Read Fault Code		Y		
408(T93)(After 2014.09)		Engine relay unit				Erase Fault Code		Y		
408(T93)(After 2014.09)		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
408(T93)(After 2014.09)		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
408(T93)(After 2014.09)		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
408(T93)(After 2014.09)		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Read ECU Information		Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Read Fault Code		Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Live Data		Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Actuation Test		Y		
408(T93)(After 2014.09)		Supply protection and management unit				Read ECU Information		Y		
408(T93)(After 2014.09)		Supply protection and management unit				Live Data		Y		
408(T93)(After 2014.09)		Power steering				Read ECU Information		Y		
408(T93)(After 2014.09)		Power steering				Read Fault Code		Y		

408(T93)(After 2014.09)		Power steering				Erase Fault Code		Y		
408(T93)(After 2014.09)		Power steering				Live Data		Y		
408(T93)(After 2014.09)		Electronic key reader				Read ECU Information		Y		
408(T93)(After 2014.09)		Electronic key reader				Read Fault Code		Y		
408(T93)(After 2014.09)		Electronic key reader				Erase Fault Code		Y		
408(T93)(After 2014.09)		Electronic key reader				Live Data		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Read ECU Information		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Read Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Erase Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Live Data		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Actuation Test		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Read ECU Information		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Read Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Erase Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Live Data		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Actuation Test		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Read ECU Information		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Read Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Erase Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Live Data		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Actuation Test		Y		
408(T93)(After 2014.09)		Air conditioning				Read ECU Information		Y		
408(T93)(After 2014.09)		Air conditioning				Read Fault Code		Y		
408(T93)(After 2014.09)		Air conditioning				Erase Fault Code		Y		
408(T93)(After 2014.09)		Air conditioning				Live Data		Y		
408(T93)(After 2014.09)		Air conditioning				Actuation Test		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	YES			Read ECU Information		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	YES			Read Fault Code		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	YES			Erase Fault Code		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	YES			Live Data		Y		

408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	YES			Actuation Test		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	NO			Read ECU Information		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	NO			Read Fault Code		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	NO			Erase Fault Code		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	NO			Live Data		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	NO			Actuation Test		Y		
408(T93)(After 2014.09)		Rain-sunlight sensor				Read ECU Information		Y		
408(T93)(After 2014.09)		Rain-sunlight sensor				Read Fault Code		Y		
408(T93)(After 2014.09)		Rain-sunlight sensor				Erase Fault Code		Y		
408(T93)(After 2014.09)		Rain-sunlight sensor				Live Data		Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Read ECU Information		Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Read Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Erase Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Live Data		Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Actuation Test		Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Read ECU Information		Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Read Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Erase Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Live Data		Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Actuation Test		Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Read ECU Information		Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Read Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Erase Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Live Data		Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Actuation Test		Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Read ECU Information		Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Read Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Erase Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Live Data		Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Actuation Test		Y		

408(T93)(After 2014.09)		Seat Driver positon memory module				Read ECU Information		Y		
408(T93)(After 2014.09)		Seat Driver positon memory module				Read Fault Code		Y		
408(T93)(After 2014.09)		Seat Driver positon memory module				Erase Fault Code		Y		
408(T93)(After 2014.09)		Seat Driver positon memory module				Live Data		Y		
408(T93)(After 2014.09)		Seat Driver positon memory module				Actuation Test		Y		
408(T93)(After 2014.09)		Battery charge status unit				Read ECU Information		Y		
408(T93)(After 2014.09)		Battery charge status unit				Live Data		Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Read ECU Information		Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Read Fault Code		Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Erase Fault Code		Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Live Data		Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Actuation Test		Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA CN			Read ECU Information		Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA CN			Read Fault Code		Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA CN			Erase Fault Code		Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA CN			Live Data		Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA CN			Actuation Test		Y		
408(T93)(After 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read ECU Information		Y		
408(T93)(After 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read Fault Code		Y		
408(T93)(After 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Erase Fault Code		Y		
408(T93)(After 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Live Data		Y		
408(T93)(After 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Actuation Test		Y		
408(T93)(After 2014.09)		Multiplexed control panel	MRN audio-navigation			Read ECU Information		Y		
408(T93)(After 2014.09)		Multiplexed control panel	MRN audio-navigation			Read Fault Code		Y		
408(T93)(After 2014.09)		Multiplexed control panel	MRN audio-navigation			Erase Fault Code		Y		
408(T93)(After 2014.09)		Multiplexed control panel	MRN audio-navigation			Live Data		Y		
408(T93)(After 2014.09)		Multiplexed control panel	MRN audio-navigation			Actuation Test		Y		
408(T93)(After 2014.09)		Control of the telematic unit				Read ECU Information		Y		
408(T93)(After 2014.09)		Control of the telematic unit				Read Fault Code		Y		
408(T93)(After 2014.09)		Control of the telematic unit				Erase Fault Code		Y		
408(T93)(After 2014.09)		Control of the telematic unit				Live Data		Y		
408(T93)(After 2014.09)		Control of the telematic unit				Actuation Test		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	No			Read ECU Information		Y		

408(T93)(After 2014.09)		Control panel dot matrix display	No			Read Fault Code		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	No			Erase Fault Code		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	No			Actuation Test		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	Yes			Read ECU Information		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	Yes			Read Fault Code		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	Yes			Erase Fault Code		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	Yes			Actuation Test		Y		
408(T93)(After 2014.09)		Voltage retaining device	DMTR DTC3B			Read ECU Information		Y		
408(T93)(After 2014.09)		Voltage retaining device	DMTR DTC3B			Read Fault Code		Y		
408(T93)(After 2014.09)		Voltage retaining device	DMTR DTC3B			Erase Fault Code		Y		
408(T93)(After 2014.09)		Radio				Read ECU Information		Y		
408(T93)(After 2014.09)		Radio				Read Fault Code		Y		
408(T93)(After 2014.09)		Radio				Erase Fault Code		Y		
408(T93)(After 2014.09)		Radio				Live Data		Y		
408(T93)(After 2014.09)		Radio				Actuation Test		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	YES			Read ECU Information		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	YES			Read Fault Code		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	YES			Erase Fault Code		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	YES			Live Data		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	YES			Actuation Test		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	NO			Read ECU Information		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	NO			Read Fault Code		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	NO			Erase Fault Code		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	NO			Live Data		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	NO			Actuation Test		Y		
408(T93)(After 2014.09)		Touch screen				Read ECU Information		Y		
408(T93)(After 2014.09)		Touch screen				Read Fault Code		Y		
408(T93)(After 2014.09)		Touch screen				Erase Fault Code		Y		
408(T93)(After 2014.09)		Touch screen				Live Data		Y		
408(T93)(After 2014.09)		Touch screen				Actuation Test		Y		
408(T93)(After 2014.09)		Anti-theft alarm				Read ECU Information		Y		
408(T93)(After 2014.09)		Anti-theft alarm				Read Fault Code		Y		
408(T93)(After 2014.09)		Anti-theft alarm				Erase Fault Code		Y		

408(T93)(After 2014.09)		Anti-theft alarm				Live Data		Y		
408(T93)(After 2014.09)		Anti-theft alarm				Actuation Test		Y		
508		BSI(Built-in Systems				Read ECU Information		Y		
508		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Read ECU Information		Y		
508		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Read Fault Code		Y		
508		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Erase Fault Code		Y		
508		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Live Data		Y		
508		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Actuation Test		Y		
508		Engine management ECU	petrol	MED17 4 2	14 MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Read ECU Information		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Read Fault Code		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Erase Fault Code		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Live Data		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Actuation Test		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RFJ	Special Function	Pack Repair	Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RHH	Read ECU Information		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RHH	Read Fault Code		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RHH	Erase Fault Code		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RHH	Live Data		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RHH	Actuation Test		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP RHH	Special Function	Pack Repair	Y		
508		Engine management ECU	petrol	MM6KP	MM6KP R	Read ECU Information		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP R	Read Fault Code		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP R	Erase Fault Code		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP R	Live Data		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP R	Actuation Test		Y		
508		Engine management ECU	petrol	MM6KP	MM6KP R	Special Function	Pack Repair	Y		
508		Engine management ECU	petrol	MED17 4 4		Read ECU Information		Y		
508		Engine management ECU	petrol	MED17 4 4		Read Fault Code		Y		
508		Engine management ECU	petrol	MED17 4 4		Erase Fault Code		Y		
508		Engine management ECU	petrol	MED17 4 4		Live Data		Y		
508		Engine management ECU	petrol	MED17 4 4		Actuation Test		Y		
508		Engine management ECU	petrol	MED17 4 4		Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
508		Engine management ECU	petrol	MED17 4 4		Special Function	Work on the ancillaries battery	Y		
508		Engine management ECU	petrol	MED17 4 4		Special Function	Initialisation of the autoadaptive values	Y		
508		Engine management ECU	petrol	MED17 4 4		Special Function	Replacement parts	Y		
508		Engine management ECU	petrol	MED17 4 4 EP8		Read ECU Information		Y		
508		Engine management ECU	petrol	MED17 4 4 EP8		Read Fault Code		Y		
508		Engine management ECU	petrol	MED17 4 4 EP8		Erase Fault Code		Y		
508		Engine management ECU	petrol	MED17 4 4 EP8		Live Data		Y		
508		Engine management ECU	petrol	MED17 4 4 EP8		Actuation Test		Y		
508		Engine management ECU	petrol	MED17 4 4 EP8		Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
508		Engine management ECU	petrol	MED17 4 4 EP8		Special Function	Work on the ancillaries battery	Y		
508		Engine management ECU	petrol	MED17 4 4 EP8		Special Function	Initialisation of the autoadaptive values	Y		
508		Engine management ECU	petrol	MED17 4 4 EP8		Special Function	Replacement parts	Y		
508		Engine management ECU	Diesel	DCM6.2		Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM6.2		Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM6.2		Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM6.2		Live Data		Y		
508		Engine management ECU	Diesel	DCM6.2		Actuation Test		Y		
508		Engine management ECU	Diesel	DCM6.2		Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHR	Read ECU Information		Y		

508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHR	Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHR	Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHR	Live Data		Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHR	Actuation Test		Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHR	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHR	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHF	Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHF	Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHF	Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHF	Live Data		Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHF	Actuation Test		Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHF	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	DCM3.4 P	DCM3.4 P RHF	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Live Data		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Actuation Test		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHD-DW10CTED4-136CV	Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHD-DW10CTED4-136CV	Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHD-DW10CTED4-136CV	Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHD-DW10CTED4-136CV	Live Data		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHD-DW10CTED4-136CV	Actuation Test		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHD-DW10CTED4-136CV	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHD-DW10CTED4-136CV	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Live Data		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Actuation Test		Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	DCM3.5 BR2	RHE-DW10CTED4-150CV	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HL-DV6CTED	Read ECU Information		Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HL-DV6CTED	Read Fault Code		Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HL-DV6CTED	Erase Fault Code		Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HL-DV6CTED	Live Data		Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HL-DV6CTED	Actuation Test		Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HL-DV6CTED	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HL-DV6CTED	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HR-DV6CTED	Read ECU Information		Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HR-DV6CTED	Read Fault Code		Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HR-DV6CTED	Erase Fault Code		Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HR-DV6CTED	Live Data		Y		

508		Engine management ECU	Diesel	HDI SID 807 BR2	9HR-DV6CTED	Actuation Test		Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HR-DV6CTED	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	HDI SID 807 BR2	9HR-DV6CTED	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	EDC17CP42		Read ECU Information		Y		
508		Engine management ECU	Diesel	EDC17CP42		Read Fault Code		Y		
508		Engine management ECU	Diesel	EDC17CP42		Erase Fault Code		Y		
508		Engine management ECU	Diesel	EDC17CP42		Live Data		Y		
508		Engine management ECU	Diesel	EDC17CP42		Actuation Test		Y		
508		Engine management ECU	Diesel	EDC17CP42		Special Function	Configuration	Y		
508		Engine management ECU	Diesel	EDC17CP42		Special Function	Pack Repair	Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read ECU Information		Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Erase Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Live Data		Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Actuation Test		Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Special Function	Pack Repair	Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read ECU Information		Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Erase Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Live Data		Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Actuation Test		Y		
508		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Special Function	Pack Repair	Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Read ECU Information		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Read Fault Code		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Erase Fault Code		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Live Data		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Actuation Test		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Special Function	Pack Repair	Y		

508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
508		Air bags and pre-tensioners control unit				Read ECU Information		Y		
508		Air bags and pre-tensioners control unit				Read Fault Code		Y		
508		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
508		Air bags and pre-tensioners control unit				Live Data		Y		
508		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
508		Power steering				Read ECU Information		Y		
508		Power steering				Read Fault Code		Y		
508		Power steering				Erase Fault Code		Y		
508		Power steering				Live Data		Y		
508		Power steering				Actuation Test		Y		
508		Under inflation detection	DSG UDS			Read ECU Information		Y		
508		Under inflation detection	DSG UDS			Read Fault Code		Y		
508		Under inflation detection	DSG UDS			Erase Fault Code		Y		
508		Under inflation detection	DSG UDS			Live Data		Y		
508		Under inflation detection	DSG			Read ECU Information		Y		
508		Under inflation detection	DSG			Read Fault Code		Y		
508		Under inflation detection	DSG			Erase Fault Code		Y		
508		Under inflation detection	DSG			Live Data		Y		
508		Active damper electronic				Read ECU Information		Y		
508		Active damper electronic				Read Fault Code		Y		
508		Active damper electronic				Erase Fault Code		Y		
508		Active damper electronic				Live Data		Y		
508		Active damper electronic				Actuation Test		Y		
508		Battery charge status unit				Read ECU Information		Y		
508		Battery charge status unit				Live Data		Y		
508		Electric secondary brake				Read ECU Information		Y		
508		Electric secondary brake				Read Fault Code		Y		
508		Electric secondary brake				Erase Fault Code		Y		
508		Electric secondary brake				Live Data		Y		
508		Electric secondary brake				Actuation Test		Y		
508		Dynamic headlamp height adjuster	BEMP			Read ECU Information		Y		
508		Dynamic headlamp height adjuster	BEMP			Read Fault Code		Y		
508		Dynamic headlamp height adjuster	BEMP			Erase Fault Code		Y		
508		Dynamic headlamp height adjuster	BEMP			Live Data		Y		
508		Dynamic headlamp height adjuster	BEMP			Actuation Test		Y		

508		Dynamic headlamp height adjuster	LADCT			Read ECU Information		Y		
508		Dynamic headlamp height adjuster	LADCT			Read Fault Code		Y		
508		Dynamic headlamp height adjuster	LADCT			Erase Fault Code		Y		
508		Dynamic headlamp height adjuster	LADCT			Live Data		Y		
508		Dynamic headlamp height adjuster	LADCT			Actuation Test		Y		
508		Additional heating				Read ECU Information		Y		
508		Additional heating				Read Fault Code		Y		
508		Additional heating				Erase Fault Code		Y		
508		Additional heating				Live Data		Y		
508		Additional heating				Actuation Test		Y		
508		Engine relay unit				Read ECU Information		Y		
508		Engine relay unit				Read Fault Code		Y		
508		Engine relay unit				Erase Fault Code		Y		
508		Engine relay unit				Live Data		Y		
508		Trailer relay unit				Read ECU Information		Y		
508		Trailer relay unit				Read Fault Code		Y		
508		Trailer relay unit				Erase Fault Code		Y		
508		Trailer relay unit				Live Data		Y		
508		Trailer relay unit				Actuation Test		Y		
508		Parking assistance	AAS UDS			Read ECU Information		Y		
508		Parking assistance	AAS UDS			Read Fault Code		Y		
508		Parking assistance	AAS UDS			Erase Fault Code		Y		
508		Parking assistance	AAS UDS			Live Data		Y		
508		Parking assistance	AAS UDS			Actuation Test		Y		
508		Anti-theft alarm	Alarm : China version			Read ECU Information		Y		
508		Anti-theft alarm	Alarm : China version			Read Fault Code		Y		
508		Anti-theft alarm	Alarm : China version			Erase Fault Code		Y		
508		Anti-theft alarm	Alarm : China version			Live Data		Y		
508		Anti-theft alarm	Alarm : China version			Actuation Test		Y		
508		Multifunction screen	EMF C UDS			Read ECU Information		Y		
508		Multifunction screen	EMF C UDS			Read Fault Code		Y		
508		Multifunction screen	EMF C UDS			Erase Fault Code		Y		
508		Multifunction screen	EMF C UDS			Actuation Test		Y		
508		Telematic unit(RTX)or audio-naviggation	MRN			Read ECU Information		Y		
508		Telematic unit(RTX)or audio-naviggation	MRN			Read Fault Code		Y		
508		Telematic unit(RTX)or audio-naviggation	MRN			Erase Fault Code		Y		
508		Telematic unit(RTX)or audio-naviggation	MRN			Live Data		Y		
508		Telematic unit(RTX)or audio-naviggation	MRN			Actuation Test		Y		
508		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read ECU Information		Y		
508		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read Fault Code		Y		
508		Telematic unit(RTX)or audio-naviggation	RNEG2010			Erase Fault Code		Y		
508		Telematic unit(RTX)or audio-naviggation	RNEG2010			Live Data		Y		
508		Telematic unit(RTX)or audio-naviggation	RNEG2010			Actuation Test		Y		
508		Telematic unit(RTX)or audio-naviggation	SMEG PLUS			Read ECU Information		Y		
508		Telematic unit(RTX)or audio-naviggation	SMEG PLUS			Read Fault Code		Y		
508		Telematic unit(RTX)or audio-naviggation	SMEG PLUS			Erase Fault Code		Y		
508		Telematic unit(RTX)or audio-naviggation	SMEG PLUS			Live Data		Y		

508		Telematic unit(RTX)or audio-navigation	SMEG PLUS			Actuation Test		Y		
508		service module /Independent telematic unit				Read ECU Information		Y		
508		service module /Independent telematic unit				Read Fault Code		Y		
508		service module /Independent telematic unit				Erase Fault Code		Y		
508		service module /Independent telematic unit				Live Data		Y		
508		service module /Independent telematic unit				Actuation Test		Y		
508		Multiplexed control panel	RD5 audio system and manual air conditioning			Read ECU Information		Y		
508		Multiplexed control panel	RD5 audio system and manual air conditioning			Read Fault Code		Y		
508		Multiplexed control panel	RD5 audio system and manual air conditioning			Erase Fault Code		Y		
508		Multiplexed control panel	RD5 audio system and manual air conditioning			Live Data		Y		
508		Multiplexed control panel	RD5 audio system and manual air conditioning			Actuation Test		Y		
508		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read ECU Information		Y		
508		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read Fault Code		Y		
508		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Erase Fault Code		Y		
508		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Live Data		Y		
508		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Actuation Test		Y		
508		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Read ECU Information		Y		
508		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Read Fault Code		Y		
508		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Erase Fault Code		Y		
508		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Live Data		Y		
508		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Actuation Test		Y		
508		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read ECU Information		Y		
508		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read Fault Code		Y		
508		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Erase Fault Code		Y		
508		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Live Data		Y		
508		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Actuation Test		Y		
508		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Read ECU Information		Y		
508		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Read Fault Code		Y		
508		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Erase Fault Code		Y		

508		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Live Data		Y		
508		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Actuation Test		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air			Read ECU Information		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air			Read Fault Code		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air			Erase Fault Code		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air			Live Data		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air			Actuation Test		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read ECU Information		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read Fault Code		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Live Data		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Actuation Test		Y		
508		Multiplexed control panel	SMEG+ audio-navigation			Read ECU Information		Y		
508		Multiplexed control panel	SMEG+ audio-navigation			Read Fault Code		Y		
508		Multiplexed control panel	SMEG+ audio-navigation			Erase Fault Code		Y		
508		Multiplexed control panel	SMEG+ audio-navigation			Live Data		Y		
508		Multiplexed control panel	SMEG+ audio-navigation			Actuation Test		Y		
508		Control panel dot matrix display	No			Read ECU Information		Y		
508		Control panel dot matrix display	No			Read Fault Code		Y		
508		Control panel dot matrix display	No			Erase Fault Code		Y		
508		Control panel dot matrix display	No			Actuation Test		Y		
508		Control panel dot matrix display	Yes			Read ECU Information		Y		
508		Control panel dot matrix display	Yes			Read Fault Code		Y		
508		Control panel dot matrix display	Yes			Erase Fault Code		Y		
508		Control panel dot matrix display	Yes			Actuation Test		Y		
508		Radio				Read ECU Information		Y		
508		Radio				Read Fault Code		Y		
508		Radio				Erase Fault Code		Y		
508		Radio				Live Data		Y		
508		Radio				Actuation Test		Y		
508		Hands free starting access electronic module.				Read ECU Information		Y		
508		Hands free starting access electronic module.				Read Fault Code		Y		
508		Hands free starting access electronic module.				Erase Fault Code		Y		
508		Hands free starting access electronic module.				Live Data		Y		

508		Hands free starting access electronic module.				Actuation Test		Y		
508		Telematic navigator / separate control				Read ECU Information		Y		
508		Telematic navigator / separate control				Live Data		Y		
508		Telematic navigator / separate control				Actuation Test		Y		
508		Radio amplifier				Read ECU Information		Y		
508		Radio amplifier				Read Fault Code		Y		
508		Radio amplifier				Erase Fault Code		Y		
508		Radio amplifier				Actuation Test		Y		
508		Controls under the steering wheel				Read ECU Information		Y		
508		Controls under the steering wheel				Read Fault Code		Y		
508		Controls under the steering wheel				Erase Fault Code		Y		
508		Controls under the steering wheel				Live Data		Y		
508		Controls under the steering wheel				Actuation Test		Y		
508		Seat belts not fastened warning lights unit				Read ECU Information		Y		
508		Seat belts not fastened warning lights unit				Actuation Test		Y		
508		Supply protection and management unit				Read ECU Information		Y		
508		Supply protection and management unit				Live Data		Y		
508		Control on the steering wheel / integral controls steering wheel	No			Read ECU Information		Y		
508		Control on the steering wheel / integral controls steering wheel	No			Read Fault Code		Y		
508		Control on the steering wheel / integral controls steering wheel	No			Erase Fault Code		Y		
508		Control on the steering wheel / integral controls steering wheel	No			Live Data		Y		
508		Control on the steering wheel / integral controls steering wheel	Yes			Read ECU Information		Y		
508		Control on the steering wheel / integral controls steering wheel	Yes			Read Fault Code		Y		
508		Control on the steering wheel / integral controls steering wheel	Yes			Erase Fault Code		Y		
508		Control on the steering wheel / integral controls steering wheel	Yes			Live Data		Y		
508		Rain and brightness sensor				Read ECU Information		Y		
508		Rain and brightness sensor				Read Fault Code		Y		
508		Rain and brightness sensor				Erase Fault Code		Y		
508		Rain and brightness sensor				Live Data		Y		
508		Air conditioning	RFTA Four-zone			Read ECU Information		Y		
508		Air conditioning	RFTA Four-zone			Read Fault Code		Y		
508		Air conditioning	RFTA Four-zone			Erase Fault Code		Y		
508		Air conditioning	RFTA Four-zone			Live Data		Y		
508		Air conditioning	RFTA Four-zone			Actuation Test		Y		
508		Rear air conditioning				Read ECU Information		Y		
508		Rear air conditioning				Live Data		Y		
508		Rear air conditioning				Actuation Test		Y		

508		Motorised Boot ECU				Read ECU Information		Y		
508		Motorised Boot ECU				Read Fault Code		Y		
508		Motorised Boot ECU				Erase Fault Code		Y		
508		Motorised Boot ECU				Live Data		Y		
508		Motorised Boot ECU				Actuation Test		Y		
508		Driver's seat position memory module	BDMC			Read ECU Information		Y		
508		Driver's seat position memory module	BDMC			Read Fault Code		Y		
508		Driver's seat position memory module	BDMC			Erase Fault Code		Y		
508		Driver's seat position memory module	BDMC			Live Data		Y		
508		Driver's seat position memory module	BDMC			Actuation Test		Y		
508		Driver's door module	PDPC			Read ECU Information		Y		
508		Driver's door module	PDPC			Read Fault Code		Y		
508		Driver's door module	PDPC			Erase Fault Code		Y		
508		Driver's door module	PDPC			Live Data		Y		
508		Driver's door module	PDPC			Actuation Test		Y		
508		Voltage retaining device	DMTR DTC3B			Read ECU Information		Y		
508		Voltage retaining device	DMTR DTC3B			Read Fault Code		Y		
508		Voltage retaining device	DMTR DTC3B			Erase Fault Code		Y		
508		Electronic key reader				Read ECU Information		Y		
508		Electronic key reader				Read Fault Code		Y		
508		Electronic key reader				Erase Fault Code		Y		
508		Electronic key reader				Live Data		Y		
508		High Head Vision				Read ECU Information		Y		
508		High Head Vision				Read Fault Code		Y		
508		High Head Vision				Erase Fault Code		Y		
508		High Head Vision				Live Data		Y		
508		High Head Vision				Actuation Test		Y		
508		Main beams assistant ECU				Read ECU Information		Y		
508		Main beams assistant ECU				Read Fault Code		Y		
508		Main beams assistant ECU				Erase Fault Code		Y		
508		Main beams assistant ECU				Live Data		Y		
508		Main beams assistant ECU				Actuation Test		Y		
508		Left hand front wiper motor	Yes			Read ECU Information		Y		
508		Left hand front wiper motor	Yes			Read Fault Code		Y		
508		Left hand front wiper motor	Yes			Erase Fault Code		Y		
508		Left hand front wiper motor	Yes			Live Data		Y		
508		Left hand front wiper motor	Yes			Actuation Test		Y		
508		Left hand front wiper motor	No			Read ECU Information		Y		
508		Right hand front wiper motor	Yes			Read ECU Information		Y		
508		Right hand front wiper motor	No			Read ECU Information		Y		
508		Right hand front wiper motor	No			Read Fault Code		Y		
508		Right hand front wiper motor	No			Erase Fault Code		Y		
508		Right hand front wiper motor	No			Live Data		Y		
508		Right hand front wiper motor	No			Actuation Test		Y		
508		External CD player				Read ECU Information		Y		
508		External CD player				Read Fault Code		Y		
508		External CD player				Erase Fault Code		Y		
508		External CD player				Live Data		Y		
508		External CD player				Actuation Test		Y		
508 HYbrid4		BSI(Built-in Systems				Read ECU Information		Y		
508 HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Read ECU Information		Y		
508 HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Read Fault Code		Y		
508 HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Erase Fault Code		Y		
508 HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Live Data		Y		
508 HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Actuation Test		Y		
508 HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Special Function	Configuration	Y		
508 HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Special Function	Pack Repair	Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Read ECU Information		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Read Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Erase Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Live Data		Y		

508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Actuation Test		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Special Function	Pack Repair	Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Read ECU Information		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Read Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Erase Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Live Data		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Actuation Test		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Special Function	Pack Repair	Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Read ECU Information		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Read Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Erase Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Live Data		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Actuation Test		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Special Function	Pack Repair	Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Read ECU Information		Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Read Fault Code		Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Erase Fault Code		Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Live Data		Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Actuation Test		Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Special Function	Programming operations	Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Special Function	Replacement parts	Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
508 HYbrid4		Air bags and pre-tensioners control unit				Read ECU Information		Y		
508 HYbrid4		Air bags and pre-tensioners control unit				Read Fault Code		Y		
508 HYbrid4		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
508 HYbrid4		Air bags and pre-tensioners control unit				Live Data		Y		
508 HYbrid4		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
508 HYbrid4		Power steering				Read ECU Information		Y		
508 HYbrid4		Power steering				Read Fault Code		Y		
508 HYbrid4		Power steering				Erase Fault Code		Y		
508 HYbrid4		Power steering				Live Data		Y		
508 HYbrid4		Power steering				Actuation Test		Y		
508 HYbrid4		Under inflation detection	DSG UDS			Read ECU Information		Y		
508 HYbrid4		Under inflation detection	DSG UDS			Read Fault Code		Y		

508 HYbrid4		Under inflation detection	DSG UDS			Erase Fault Code		Y		
508 HYbrid4		Under inflation detection	DSG UDS			Live Data		Y		
508 HYbrid4		Under inflation detection	DSG			Read ECU Information		Y		
508 HYbrid4		Under inflation detection	DSG			Read Fault Code		Y		
508 HYbrid4		Under inflation detection	DSG			Erase Fault Code		Y		
508 HYbrid4		Under inflation detection	DSG			Live Data		Y		
508 HYbrid4		Battery charge status unit				Read ECU Information		Y		
508 HYbrid4		Battery charge status unit				Live Data		Y		
508 HYbrid4		Electric secondary brake				Read ECU Information		Y		
508 HYbrid4		Electric secondary brake				Read Fault Code		Y		
508 HYbrid4		Electric secondary brake				Erase Fault Code		Y		
508 HYbrid4		Electric secondary brake				Live Data		Y		
508 HYbrid4		Electric secondary brake				Actuation Test		Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Read ECU Information		Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Read Fault Code		Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Erase Fault Code		Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Live Data		Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Actuation Test		Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Read ECU Information		Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Read Fault Code		Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Erase Fault Code		Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Live Data		Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Actuation Test		Y		
508 HYbrid4		Additional heating				Read ECU Information		Y		
508 HYbrid4		Additional heating				Read Fault Code		Y		
508 HYbrid4		Additional heating				Erase Fault Code		Y		
508 HYbrid4		Additional heating				Live Data		Y		
508 HYbrid4		Additional heating				Actuation Test		Y		
508 HYbrid4		Engine relay unit				Read ECU Information		Y		
508 HYbrid4		Engine relay unit				Read Fault Code		Y		
508 HYbrid4		Engine relay unit				Erase Fault Code		Y		
508 HYbrid4		Engine relay unit				Live Data		Y		
508 HYbrid4		Trailer relay unit				Read ECU Information		Y		
508 HYbrid4		Trailer relay unit				Read Fault Code		Y		
508 HYbrid4		Trailer relay unit				Erase Fault Code		Y		
508 HYbrid4		Trailer relay unit				Live Data		Y		
508 HYbrid4		Trailer relay unit				Actuation Test		Y		
508 HYbrid4		Parking assistance	4 Parking assistance			Read ECU Information		Y		
508 HYbrid4		Parking assistance	4 Parking assistance			Read Fault Code		Y		
508 HYbrid4		Parking assistance	4 Parking assistance			Erase Fault Code		Y		
508 HYbrid4		Parking assistance	4 Parking assistance			Live Data		Y		
508 HYbrid4		Parking assistance	4 Parking assistance			Actuation Test		Y		
508 HYbrid4		Parking assistance	10 Parking assistance			Read ECU Information		Y		
508 HYbrid4		Parking assistance	10 Parking assistance			Read Fault Code		Y		
508 HYbrid4		Parking assistance	10 Parking assistance			Erase Fault Code		Y		
508 HYbrid4		Parking assistance	10 Parking assistance			Live Data		Y		
508 HYbrid4		Parking assistance	10 Parking assistance			Actuation Test		Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift			Read ECU Information		Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift			Read Fault Code		Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift			Erase Fault Code		Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift			Live Data		Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift			Actuation Test		Y		
508 HYbrid4		Multifunction screen	EMF C UDS			Read ECU Information		Y		
508 HYbrid4		Multifunction screen	EMF C UDS			Read Fault Code		Y		
508 HYbrid4		Multifunction screen	EMF C UDS			Erase Fault Code		Y		
508 HYbrid4		Multifunction screen	EMF C UDS			Actuation Test		Y		

508 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read ECU Information		Y		
508 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read Fault Code		Y		
508 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Erase Fault Code		Y		
508 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Live Data		Y		
508 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Actuation Test		Y		
508 HYbrid4		Telematic unit(RTX)or audio-naviggation	SMEG_PLUS			Read ECU Information		Y		
508 HYbrid4		Telematic unit(RTX)or audio-naviggation	SMEG_PLUS			Read Fault Code		Y		
508 HYbrid4		Telematic unit(RTX)or audio-naviggation	SMEG_PLUS			Erase Fault Code		Y		
508 HYbrid4		Telematic unit(RTX)or audio-naviggation	SMEG_PLUS			Live Data		Y		
508 HYbrid4		Telematic unit(RTX)or audio-naviggation	SMEG_PLUS			Actuation Test		Y		
508 HYbrid4		service module /Independent telematic unit	BTA			Read ECU Information		Y		
508 HYbrid4		service module /Independent telematic unit	BTA			Read Fault Code		Y		
508 HYbrid4		service module /Independent telematic unit	BTA			Erase Fault Code		Y		
508 HYbrid4		service module /Independent telematic unit	BTA			Live Data		Y		
508 HYbrid4		service module /Independent telematic unit	BTA			Actuation Test		Y		
508 HYbrid4		service module /Independent telematic unit	BTA 2			Read ECU Information		Y		
508 HYbrid4		service module /Independent telematic unit	BTA 2			Read Fault Code		Y		
508 HYbrid4		service module /Independent telematic unit	BTA 2			Erase Fault Code		Y		
508 HYbrid4		service module /Independent telematic unit	BTA 2			Live Data		Y		
508 HYbrid4		service module /Independent telematic unit	BTA 2			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Live Data		Y		
508 HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Live Data		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Erase Fault Code		Y		

508 HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Live Data		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Live Data		Y		
508 HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Live Data		Y		
508 HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air			Live Data		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Live Data		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Live Data		Y		
508 HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Actuation Test		Y		
508 HYbrid4		Control panel dot matrix display	No			Read ECU Information		Y		

508 HYbrid4		Control panel dot matrix display	No			Read Fault Code		Y		
508 HYbrid4		Control panel dot matrix display	No			Erase Fault Code		Y		
508 HYbrid4		Control panel dot matrix display	No			Actuation Test		Y		
508 HYbrid4		Control panel dot matrix display	Yes			Read ECU Information		Y		
508 HYbrid4		Control panel dot matrix display	Yes			Read Fault Code		Y		
508 HYbrid4		Control panel dot matrix display	Yes			Erase Fault Code		Y		
508 HYbrid4		Control panel dot matrix display	Yes			Actuation Test		Y		
508 HYbrid4		Radio				Read ECU Information		Y		
508 HYbrid4		Radio				Read Fault Code		Y		
508 HYbrid4		Radio				Erase Fault Code		Y		
508 HYbrid4		Radio				Live Data		Y		
508 HYbrid4		Radio				Actuation Test		Y		
508 HYbrid4		Hands free starting access electronic module.				Read ECU Information		Y		
508 HYbrid4		Hands free starting access electronic module.				Read Fault Code		Y		
508 HYbrid4		Hands free starting access electronic module.				Erase Fault Code		Y		
508 HYbrid4		Hands free starting access electronic module.				Live Data		Y		
508 HYbrid4		Hands free starting access electronic module.				Actuation Test		Y		
508 HYbrid4		Telematic navigator / separate control				Read ECU Information		Y		
508 HYbrid4		Telematic navigator / separate control				Live Data		Y		
508 HYbrid4		Telematic navigator / separate control				Actuation Test		Y		
508 HYbrid4		Radio amplifier				Read ECU Information		Y		
508 HYbrid4		Radio amplifier				Read Fault Code		Y		
508 HYbrid4		Radio amplifier				Erase Fault Code		Y		
508 HYbrid4		Radio amplifier				Actuation Test		Y		
508 HYbrid4		Controls under the steering wheel				Read ECU Information		Y		
508 HYbrid4		Controls under the steering wheel				Read Fault Code		Y		
508 HYbrid4		Controls under the steering wheel				Erase Fault Code		Y		
508 HYbrid4		Controls under the steering wheel				Live Data		Y		
508 HYbrid4		Controls under the steering wheel				Actuation Test		Y		
508 HYbrid4		Seat belts not fastened warning lights unit				Read ECU Information		Y		
508 HYbrid4		Seat belts not fastened warning lights unit				Actuation Test		Y		
508 HYbrid4		Supply protection and management unit				Read ECU Information		Y		
508 HYbrid4		Supply protection and management unit				Live Data		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Read ECU Information		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Read Fault Code		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Erase Fault Code		Y		

508 HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Live Data		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Read ECU Information		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Read Fault Code		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Erase Fault Code		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Live Data		Y		
508 HYbrid4		Rain and brightness sensor				Read ECU Information		Y		
508 HYbrid4		Rain and brightness sensor				Read Fault Code		Y		
508 HYbrid4		Rain and brightness sensor				Erase Fault Code		Y		
508 HYbrid4		Rain and brightness sensor				Live Data		Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Read ECU Information		Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Read Fault Code		Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Erase Fault Code		Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Live Data		Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Actuation Test		Y		
508 HYbrid4		Rear air conditioning				Read ECU Information		Y		
508 HYbrid4		Rear air conditioning				Live Data		Y		
508 HYbrid4		Rear air conditioning				Actuation Test		Y		
508 HYbrid4		Driver's seat position memory module	BDMC			Read ECU Information		Y		
508 HYbrid4		Driver's seat position memory module	BDMC			Read Fault Code		Y		
508 HYbrid4		Driver's seat position memory module	BDMC			Erase Fault Code		Y		
508 HYbrid4		Driver's seat position memory module	BDMC			Live Data		Y		
508 HYbrid4		Driver's seat position memory module	BDMC			Actuation Test		Y		
508 HYbrid4		Driver's door module	PDPC			Read ECU Information		Y		
508 HYbrid4		Driver's door module	PDPC			Read Fault Code		Y		
508 HYbrid4		Driver's door module	PDPC			Erase Fault Code		Y		
508 HYbrid4		Driver's door module	PDPC			Live Data		Y		
508 HYbrid4		Driver's door module	PDPC			Actuation Test		Y		
508 HYbrid4		Electronic key reader				Read ECU Information		Y		
508 HYbrid4		Electronic key reader				Read Fault Code		Y		
508 HYbrid4		Electronic key reader				Erase Fault Code		Y		
508 HYbrid4		Electronic key reader				Live Data		Y		
508 HYbrid4		High Head Vision				Read ECU Information		Y		
508 HYbrid4		High Head Vision				Read Fault Code		Y		
508 HYbrid4		High Head Vision				Erase Fault Code		Y		
508 HYbrid4		High Head Vision				Live Data		Y		
508 HYbrid4		High Head Vision				Actuation Test		Y		
508 HYbrid4		Main beams assistant ECU				Read ECU Information		Y		
508 HYbrid4		Main beams assistant ECU				Read Fault Code		Y		
508 HYbrid4		Main beams assistant ECU				Erase Fault Code		Y		
508 HYbrid4		Main beams assistant ECU				Live Data		Y		
508 HYbrid4		Main beams assistant ECU				Actuation Test		Y		
508 HYbrid4		Left hand front wiper motor	Yes			Read ECU Information		Y		
508 HYbrid4		Left hand front wiper motor	Yes			Read Fault Code		Y		
508 HYbrid4		Left hand front wiper motor	Yes			Erase Fault Code		Y		
508 HYbrid4		Left hand front wiper motor	Yes			Live Data		Y		
508 HYbrid4		Left hand front wiper motor	Yes			Actuation Test		Y		
508 HYbrid4		Left hand front wiper motor	No			Read ECU Information		Y		
508 HYbrid4		Right hand front wiper motor	Yes			Read ECU Information		Y		
508 HYbrid4		Right hand front wiper motor	No			Read ECU Information		Y		
508 HYbrid4		Right hand front wiper motor	No			Read Fault Code		Y		
508 HYbrid4		Right hand front wiper motor	No			Erase Fault Code		Y		

508 HYbrid4		Right hand front wiper motor	No			Live Data		Y		
508 HYbrid4		Right hand front wiper motor	No			Actuation Test		Y		
508 HYbrid4		External CD player				Read ECU Information		Y		
508 HYbrid4		External CD player				Read Fault Code		Y		
508 HYbrid4		External CD player				Erase Fault Code		Y		
508 HYbrid4		External CD player				Live Data		Y		
508 HYbrid4		External CD player				Actuation Test		Y		
508 HYbrid4		Hybrid control ECU 1				Read ECU Information		Y		
508 HYbrid4		Hybrid control ECU 1				Read Fault Code		Y		
508 HYbrid4		Hybrid control ECU 1				Erase Fault Code		Y		
508 HYbrid4		Hybrid control ECU 1				Live Data		Y		
508 HYbrid4		Hybrid control ECU 1				Actuation Test		Y		
508 HYbrid4		Hybrid control ECU 2				Read ECU Information		Y		
508 HYbrid4		Hybrid control ECU 2				Read Fault Code		Y		
508 HYbrid4		Hybrid control ECU 2				Erase Fault Code		Y		
508 HYbrid4		Hybrid control ECU 2				Live Data		Y		
508 HYbrid4		Traction battery ECU				Read ECU Information		Y		
508 HYbrid4		Traction battery ECU				Read Fault Code		Y		
508 HYbrid4		Traction battery ECU				Erase Fault Code		Y		
508 HYbrid4		Traction battery ECU				Live Data		Y		
508 HYbrid4		Traction battery ECU				Actuation Test		Y		
508 HYbrid4		Hybrid mode selector				Read ECU Information		Y		
508 HYbrid4		Hybrid mode selector				Read Fault Code		Y		
508 HYbrid4		Hybrid mode selector				Live Data		Y		
508 HYbrid4		Hybrid mode selector				Actuation Test		Y		
508 RXH		BSI(Built-in Systems				Read ECU Information		Y		
508 RXH		Engine management ECU	DCM6.2			Read ECU Information		Y		
508 RXH		Engine management ECU	DCM6.2			Read Fault Code		Y		
508 RXH		Engine management ECU	DCM6.2			Erase Fault Code		Y		
508 RXH		Engine management ECU	DCM6.2			Live Data		Y		
508 RXH		Engine management ECU	DCM6.2			Actuation Test		Y		
508 RXH		Engine management ECU	DCM6.2			Special Function	Pack Repair	Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Read ECU Information		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Read Fault Code		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Erase Fault Code		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Live Data		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Actuation Test		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Special Function	Pack Repair	Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		

508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
508 RXH		Air bags and pre-tensioners control unit				Read ECU Information		Y		
508 RXH		Air bags and pre-tensioners control unit				Read Fault Code		Y		
508 RXH		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
508 RXH		Air bags and pre-tensioners control unit				Live Data		Y		
508 RXH		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
508 RXH		Power steering				Read ECU Information		Y		
508 RXH		Power steering				Read Fault Code		Y		
508 RXH		Power steering				Erase Fault Code		Y		
508 RXH		Power steering				Live Data		Y		
508 RXH		Power steering				Actuation Test		Y		
508 RXH		Under inflation detection	DSG UDS			Read ECU Information		Y		
508 RXH		Under inflation detection	DSG UDS			Read Fault Code		Y		
508 RXH		Under inflation detection	DSG UDS			Erase Fault Code		Y		
508 RXH		Under inflation detection	DSG UDS			Live Data		Y		
508 RXH		Battery charge status unit				Read ECU Information		Y		
508 RXH		Battery charge status unit				Live Data		Y		
508 RXH		Electric secondary brake				Read ECU Information		Y		
508 RXH		Electric secondary brake				Read Fault Code		Y		
508 RXH		Electric secondary brake				Erase Fault Code		Y		
508 RXH		Electric secondary brake				Live Data		Y		
508 RXH		Electric secondary brake				Actuation Test		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Read ECU Information		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Read Fault Code		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Erase Fault Code		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Live Data		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Actuation Test		Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Read ECU Information		Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Read Fault Code		Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Erase Fault Code		Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Live Data		Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Actuation Test		Y		
508 RXH		Additional heating				Read ECU Information		Y		
508 RXH		Additional heating				Read Fault Code		Y		

508 RXH		Additional heating				Erase Fault Code		Y		
508 RXH		Additional heating				Live Data		Y		
508 RXH		Additional heating				Actuation Test		Y		
508 RXH		Engine relay unit				Read ECU Information		Y		
508 RXH		Engine relay unit				Read Fault Code		Y		
508 RXH		Engine relay unit				Erase Fault Code		Y		
508 RXH		Engine relay unit				Live Data		Y		
508 RXH		Trailer relay unit				Read ECU Information		Y		
508 RXH		Trailer relay unit				Read Fault Code		Y		
508 RXH		Trailer relay unit				Erase Fault Code		Y		
508 RXH		Trailer relay unit				Live Data		Y		
508 RXH		Trailer relay unit				Actuation Test		Y		
508 RXH		Parking assistance	AAS UDS			Read ECU Information		Y		
508 RXH		Parking assistance	AAS UDS			Read Fault Code		Y		
508 RXH		Parking assistance	AAS UDS			Erase Fault Code		Y		
508 RXH		Parking assistance	AAS UDS			Live Data		Y		
508 RXH		Parking assistance	AAS UDS			Actuation Test		Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift			Read ECU Information		Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift			Read Fault Code		Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift			Erase Fault Code		Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift			Live Data		Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift			Actuation Test		Y		
508 RXH		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read ECU Information		Y		
508 RXH		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read Fault Code		Y		
508 RXH		Telematic unit(RTX)or audio-naviggation	RNEG2010			Erase Fault Code		Y		
508 RXH		Telematic unit(RTX)or audio-naviggation	RNEG2010			Live Data		Y		
508 RXH		Telematic unit(RTX)or audio-naviggation	RNEG2010			Actuation Test		Y		
508 RXH		Telematic unit(RTX)or audio-naviggation	SMEG PLUS			Read ECU Information		Y		
508 RXH		Telematic unit(RTX)or audio-naviggation	SMEG PLUS			Read Fault Code		Y		
508 RXH		Telematic unit(RTX)or audio-naviggation	SMEG PLUS			Erase Fault Code		Y		
508 RXH		Telematic unit(RTX)or audio-naviggation	SMEG PLUS			Live Data		Y		
508 RXH		Telematic unit(RTX)or audio-naviggation	SMEG PLUS			Actuation Test		Y		
508 RXH		service module /Independent telematic unit	BTA			Read ECU Information		Y		
508 RXH		service module /Independent telematic unit	BTA			Read Fault Code		Y		
508 RXH		service module /Independent telematic unit	BTA			Erase Fault Code		Y		
508 RXH		service module /Independent telematic unit	BTA			Live Data		Y		
508 RXH		service module /Independent telematic unit	BTA			Actuation Test		Y		
508 RXH		service module /Independent telematic unit	BTA 2			Read ECU Information		Y		
508 RXH		service module /Independent telematic unit	BTA 2			Read Fault Code		Y		
508 RXH		service module /Independent telematic unit	BTA 2			Erase Fault Code		Y		
508 RXH		service module /Independent telematic unit	BTA 2			Live Data		Y		
508 RXH		service module /Independent telematic unit	BTA 2			Actuation Test		Y		
508 RXH		Multiplexed control panel	RD5 audio system and manual air conditioning			Read ECU Information		Y		
508 RXH		Multiplexed control panel	RD5 audio system and manual air conditioning			Read Fault Code		Y		

508 RXH		Multiplexed control panel	RD5 audio system and manual air conditioning			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	RD5 audio system and manual air conditioning			Live Data		Y		
508 RXH		Multiplexed control panel	RD5 audio system and manual air conditioning			Actuation Test		Y		
508 RXH		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read ECU Information		Y		
508 RXH		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read Fault Code		Y		
508 RXH		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Live Data		Y		
508 RXH		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Actuation Test		Y		
508 RXH		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Read ECU Information		Y		
508 RXH		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Read Fault Code		Y		
508 RXH		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Live Data		Y		
508 RXH		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Actuation Test		Y		
508 RXH		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read ECU Information		Y		
508 RXH		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read Fault Code		Y		
508 RXH		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Live Data		Y		
508 RXH		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Actuation Test		Y		
508 RXH		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Read ECU Information		Y		
508 RXH		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Read Fault Code		Y		
508 RXH		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Live Data		Y		
508 RXH		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Actuation Test		Y		
508 RXH		Multiplexed control panel	Accessory radio and dual-zone automatic air			Read ECU Information		Y		
508 RXH		Multiplexed control panel	Accessory radio and dual-zone automatic air			Read Fault Code		Y		
508 RXH		Multiplexed control panel	Accessory radio and dual-zone automatic air			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	Accessory radio and dual-zone automatic air			Live Data		Y		
508 RXH		Multiplexed control panel	Accessory radio and dual-zone automatic air			Actuation Test		Y		

508 RXH		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read ECU Information		Y		
508 RXH		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read Fault Code		Y		
508 RXH		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Live Data		Y		
508 RXH		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Actuation Test		Y		
508 RXH		Multiplexed control panel	SMEG+ audio-navigation			Read ECU Information		Y		
508 RXH		Multiplexed control panel	SMEG+ audio-navigation			Read Fault Code		Y		
508 RXH		Multiplexed control panel	SMEG+ audio-navigation			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	SMEG+ audio-navigation			Live Data		Y		
508 RXH		Multiplexed control panel	SMEG+ audio-navigation			Actuation Test		Y		
508 RXH		Control panel dot matrix display	No			Read ECU Information		Y		
508 RXH		Control panel dot matrix display	No			Read Fault Code		Y		
508 RXH		Control panel dot matrix display	No			Erase Fault Code		Y		
508 RXH		Control panel dot matrix display	No			Actuation Test		Y		
508 RXH		Control panel dot matrix display	Yes			Read ECU Information		Y		
508 RXH		Control panel dot matrix display	Yes			Read Fault Code		Y		
508 RXH		Control panel dot matrix display	Yes			Erase Fault Code		Y		
508 RXH		Control panel dot matrix display	Yes			Actuation Test		Y		
508 RXH		Hands free starting access electronic module.				Read ECU Information		Y		
508 RXH		Hands free starting access electronic module.				Read Fault Code		Y		
508 RXH		Hands free starting access electronic module.				Erase Fault Code		Y		
508 RXH		Hands free starting access electronic module.				Live Data		Y		
508 RXH		Hands free starting access electronic module.				Actuation Test		Y		
508 RXH		Radio amplifier				Read ECU Information		Y		
508 RXH		Radio amplifier				Read Fault Code		Y		
508 RXH		Radio amplifier				Erase Fault Code		Y		
508 RXH		Radio amplifier				Actuation Test		Y		
508 RXH		Controls under the steering wheel				Read ECU Information		Y		
508 RXH		Controls under the steering wheel				Read Fault Code		Y		
508 RXH		Controls under the steering wheel				Erase Fault Code		Y		
508 RXH		Controls under the steering wheel				Live Data		Y		
508 RXH		Controls under the steering wheel				Actuation Test		Y		
508 RXH		Seat belts not fastened warning lights unit				Read ECU Information		Y		
508 RXH		Seat belts not fastened warning lights unit				Actuation Test		Y		
508 RXH		Supply protection and management unit				Read ECU Information		Y		

508 RXH		Supply protection and management unit				Live Data		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	No			Read ECU Information		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	No			Read Fault Code		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	No			Erase Fault Code		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	No			Live Data		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	Yes			Read ECU Information		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	Yes			Read Fault Code		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	Yes			Erase Fault Code		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	Yes			Live Data		Y		
508 RXH		Rain and brightness sensor				Read ECU Information		Y		
508 RXH		Rain and brightness sensor				Read Fault Code		Y		
508 RXH		Rain and brightness sensor				Erase Fault Code		Y		
508 RXH		Rain and brightness sensor				Live Data		Y		
508 RXH		Air conditioning	RFTA Four-zone			Read ECU Information		Y		
508 RXH		Air conditioning	RFTA Four-zone			Read Fault Code		Y		
508 RXH		Air conditioning	RFTA Four-zone			Erase Fault Code		Y		
508 RXH		Air conditioning	RFTA Four-zone			Live Data		Y		
508 RXH		Air conditioning	RFTA Four-zone			Actuation Test		Y		
508 RXH		Rear air conditioning				Read ECU Information		Y		
508 RXH		Rear air conditioning				Live Data		Y		
508 RXH		Rear air conditioning				Actuation Test		Y		
508 RXH		Motorised Boot ECU				Read ECU Information		Y		
508 RXH		Motorised Boot ECU				Read Fault Code		Y		
508 RXH		Motorised Boot ECU				Erase Fault Code		Y		
508 RXH		Motorised Boot ECU				Live Data		Y		
508 RXH		Motorised Boot ECU				Actuation Test		Y		
508 RXH		Driver's seat position memory module	BDMC			Read ECU Information		Y		
508 RXH		Driver's seat position memory module	BDMC			Read Fault Code		Y		
508 RXH		Driver's seat position memory module	BDMC			Erase Fault Code		Y		
508 RXH		Driver's seat position memory module	BDMC			Live Data		Y		
508 RXH		Driver's seat position memory module	BDMC			Actuation Test		Y		
508 RXH		Driver's door module	PDPC			Read ECU Information		Y		
508 RXH		Driver's door module	PDPC			Read Fault Code		Y		
508 RXH		Driver's door module	PDPC			Erase Fault Code		Y		
508 RXH		Driver's door module	PDPC			Live Data		Y		
508 RXH		Driver's door module	PDPC			Actuation Test		Y		
508 RXH		Electronic key reader				Read ECU Information		Y		
508 RXH		Electronic key reader				Read Fault Code		Y		
508 RXH		Electronic key reader				Erase Fault Code		Y		
508 RXH		Electronic key reader				Live Data		Y		
508 RXH		High Head Vision				Read ECU Information		Y		
508 RXH		High Head Vision				Read Fault Code		Y		
508 RXH		High Head Vision				Erase Fault Code		Y		
508 RXH		High Head Vision				Live Data		Y		

508 RXH		High Head Vision				Actuation Test		Y		
508 RXH		Main beams assistant ECU				Read ECU Information		Y		
508 RXH		Main beams assistant ECU				Read Fault Code		Y		
508 RXH		Main beams assistant ECU				Erase Fault Code		Y		
508 RXH		Main beams assistant ECU				Live Data		Y		
508 RXH		Main beams assistant ECU				Actuation Test		Y		
508 RXH		Left hand front wiper motor	Yes			Read ECU Information		Y		
508 RXH		Left hand front wiper motor	Yes			Read Fault Code		Y		
508 RXH		Left hand front wiper motor	Yes			Erase Fault Code		Y		
508 RXH		Left hand front wiper motor	Yes			Live Data		Y		
508 RXH		Left hand front wiper motor	Yes			Actuation Test		Y		
508 RXH		Left hand front wiper motor	No			Read ECU Information		Y		
508 RXH		Right hand front wiper motor	Yes			Read ECU Information		Y		
508 RXH		Right hand front wiper motor	No			Read ECU Information		Y		
508 RXH		Right hand front wiper motor	No			Read Fault Code		Y		
508 RXH		Right hand front wiper motor	No			Erase Fault Code		Y		
508 RXH		Right hand front wiper motor	No			Live Data		Y		
508 RXH		Right hand front wiper motor	No			Actuation Test		Y		
508 RXH		External CD player				Read ECU Information		Y		
508 RXH		External CD player				Read Fault Code		Y		
508 RXH		External CD player				Erase Fault Code		Y		
508 RXH		External CD player				Live Data		Y		
508 RXH		External CD player				Actuation Test		Y		
508 RXH		Voltage retaining device	DMTR DTC3B			Read ECU Information		Y		
508 RXH		Voltage retaining device	DMTR DTC3B			Read Fault Code		Y		
508 RXH		Voltage retaining device	DMTR DTC3B			Erase Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Read ECU Information		Y		
508 RXH HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Read Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Erase Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Live Data		Y		
508 RXH HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Actuation Test		Y		
508 RXH HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Special Function	Configuration	Y		
508 RXH HYbrid4		Engine management ECU	DCM35 HY	RHC-DW10CTED4-163CV		Special Function	Pack Repair	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Read ECU Information		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Read Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Erase Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Live Data		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Actuation Test		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Special Function	Pack Repair	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Read ECU Information		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Read Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Erase Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Live Data		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Actuation Test		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Special Function	Pack Repair	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Read ECU Information		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Read Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Erase Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Live Data		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Actuation Test		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Special Function	Pack Repair	Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P HY			Read ECU Information		Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P HY			Read Fault Code		Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P HY			Erase Fault Code		Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P HY			Live Data		Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P HY			Actuation Test		Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P HY			Special Function	Programming operations	Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P HY			Special Function	Replacement parts	Y		

508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
508 RXH HYbrid4		Air bags and pre-tensioners control unit				Read ECU Information		Y		
508 RXH HYbrid4		Air bags and pre-tensioners control unit				Read Fault Code		Y		
508 RXH HYbrid4		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
508 RXH HYbrid4		Air bags and pre-tensioners control unit				Live Data		Y		
508 RXH HYbrid4		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
508 RXH HYbrid4		Power steering				Read ECU Information		Y		
508 RXH HYbrid4		Power steering				Read Fault Code		Y		
508 RXH HYbrid4		Power steering				Erase Fault Code		Y		
508 RXH HYbrid4		Power steering				Live Data		Y		
508 RXH HYbrid4		Power steering				Actuation Test		Y		
508 RXH HYbrid4		Under inflation detection	DSG UDS			Read ECU Information		Y		
508 RXH HYbrid4		Under inflation detection	DSG UDS			Read Fault Code		Y		
508 RXH HYbrid4		Under inflation detection	DSG UDS			Erase Fault Code		Y		
508 RXH HYbrid4		Under inflation detection	DSG UDS			Live Data		Y		
508 RXH HYbrid4		Under inflation detection	DSG			Read ECU Information		Y		
508 RXH HYbrid4		Under inflation detection	DSG			Read Fault Code		Y		
508 RXH HYbrid4		Under inflation detection	DSG			Erase Fault Code		Y		
508 RXH HYbrid4		Under inflation detection	DSG			Live Data		Y		
508 RXH HYbrid4		Battery charge status unit				Read ECU Information		Y		
508 RXH HYbrid4		Battery charge status unit				Live Data		Y		
508 RXH HYbrid4		Electric secondary brake				Read ECU Information		Y		
508 RXH HYbrid4		Electric secondary brake				Read Fault Code		Y		
508 RXH HYbrid4		Electric secondary brake				Erase Fault Code		Y		
508 RXH HYbrid4		Electric secondary brake				Live Data		Y		
508 RXH HYbrid4		Electric secondary brake				Actuation Test		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Read ECU Information		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Read Fault Code		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Erase Fault Code		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Live Data		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Actuation Test		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Read ECU Information		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Read Fault Code		Y		

508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Erase Fault Code		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Live Data		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Actuation Test		Y		
508 RXH HYbrid4		Additional heating				Read ECU Information		Y		
508 RXH HYbrid4		Additional heating				Read Fault Code		Y		
508 RXH HYbrid4		Additional heating				Erase Fault Code		Y		
508 RXH HYbrid4		Additional heating				Live Data		Y		
508 RXH HYbrid4		Additional heating				Actuation Test		Y		
508 RXH HYbrid4		Engine relay unit				Read ECU Information		Y		
508 RXH HYbrid4		Engine relay unit				Read Fault Code		Y		
508 RXH HYbrid4		Engine relay unit				Erase Fault Code		Y		
508 RXH HYbrid4		Engine relay unit				Live Data		Y		
508 RXH HYbrid4		Trailer relay unit				Read ECU Information		Y		
508 RXH HYbrid4		Trailer relay unit				Read Fault Code		Y		
508 RXH HYbrid4		Trailer relay unit				Erase Fault Code		Y		
508 RXH HYbrid4		Trailer relay unit				Live Data		Y		
508 RXH HYbrid4		Trailer relay unit				Actuation Test		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Read ECU Information		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Read Fault Code		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Erase Fault Code		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Live Data		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Actuation Test		Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift			Read ECU Information		Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift			Read Fault Code		Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift			Erase Fault Code		Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift			Live Data		Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift			Actuation Test		Y		
508 RXH HYbrid4		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
508 RXH HYbrid4		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
508 RXH HYbrid4		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
508 RXH HYbrid4		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
508 RXH HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read ECU Information		Y		
508 RXH HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read Fault Code		Y		
508 RXH HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Erase Fault Code		Y		
508 RXH HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Live Data		Y		
508 RXH HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Actuation Test		Y		
508 RXH HYbrid4		Telematic unit(RTX)or audio-naviggation	SMEG_PLUS			Read ECU Information		Y		
508 RXH HYbrid4		Telematic unit(RTX)or audio-naviggation	SMEG_PLUS			Read Fault Code		Y		
508 RXH HYbrid4		Telematic unit(RTX)or audio-naviggation	SMEG_PLUS			Erase Fault Code		Y		
508 RXH HYbrid4		Telematic unit(RTX)or audio-naviggation	SMEG_PLUS			Live Data		Y		
508 RXH HYbrid4		Telematic unit(RTX)or audio-naviggation	SMEG_PLUS			Actuation Test		Y		
508 RXH HYbrid4		service module /Independent telematic unit	BTA			Read ECU Information		Y		
508 RXH HYbrid4		service module /Independent telematic unit	BTA			Read Fault Code		Y		
508 RXH HYbrid4		service module /Independent telematic unit	BTA			Erase Fault Code		Y		
508 RXH HYbrid4		service module /Independent telematic unit	BTA			Live Data		Y		
508 RXH HYbrid4		service module /Independent telematic unit	BTA			Actuation Test		Y		
508 RXH HYbrid4		service module /Independent telematic unit	BTA_2			Read ECU Information		Y		

508 RXH HYbrid4		service module /Independent telematic unit	BTA 2			Read Fault Code		Y		
508 RXH HYbrid4		service module /Independent telematic unit	BTA 2			Erase Fault Code		Y		
508 RXH HYbrid4		service module /Independent telematic unit	BTA 2			Live Data		Y		
508 RXH HYbrid4		service module /Independent telematic unit	BTA 2			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Live Data		Y		

508 RXH HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioningFour-zone			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Actuation Test		Y		
508 RXH HYbrid4		Control panel dot matrix display	No			Read ECU Information		Y		
508 RXH HYbrid4		Control panel dot matrix display	No			Read Fault Code		Y		
508 RXH HYbrid4		Control panel dot matrix display	No			Erase Fault Code		Y		
508 RXH HYbrid4		Control panel dot matrix display	No			Actuation Test		Y		
508 RXH HYbrid4		Control panel dot matrix display	Yes			Read ECU Information		Y		
508 RXH HYbrid4		Control panel dot matrix display	Yes			Read Fault Code		Y		
508 RXH HYbrid4		Control panel dot matrix display	Yes			Erase Fault Code		Y		
508 RXH HYbrid4		Control panel dot matrix display	Yes			Actuation Test		Y		
508 RXH HYbrid4		Radio				Read ECU Information		Y		
508 RXH HYbrid4		Radio				Read Fault Code		Y		
508 RXH HYbrid4		Radio				Erase Fault Code		Y		
508 RXH HYbrid4		Radio				Live Data		Y		
508 RXH HYbrid4		Radio				Actuation Test		Y		
508 RXH HYbrid4		Hands free starting access electronic module.				Read ECU Information		Y		
508 RXH HYbrid4		Hands free starting access electronic module.				Read Fault Code		Y		
508 RXH HYbrid4		Hands free starting access electronic module.				Erase Fault Code		Y		
508 RXH HYbrid4		Hands free starting access electronic module.				Live Data		Y		
508 RXH HYbrid4		Hands free starting access electronic module.				Actuation Test		Y		
508 RXH HYbrid4		Telematic navigator / separate control				Read ECU Information		Y		

508 RXH HYbrid4		Telematic navigator / separate control				Live Data		Y		
508 RXH HYbrid4		Telematic navigator / separate control				Actuation Test		Y		
508 RXH HYbrid4		Radio amplifier				Read ECU Information		Y		
508 RXH HYbrid4		Radio amplifier				Read Fault Code		Y		
508 RXH HYbrid4		Radio amplifier				Erase Fault Code		Y		
508 RXH HYbrid4		Radio amplifier				Actuation Test		Y		
508 RXH HYbrid4		Controls under the steering wheel				Read ECU Information		Y		
508 RXH HYbrid4		Controls under the steering wheel				Read Fault Code		Y		
508 RXH HYbrid4		Controls under the steering wheel				Erase Fault Code		Y		
508 RXH HYbrid4		Controls under the steering wheel				Live Data		Y		
508 RXH HYbrid4		Controls under the steering wheel				Actuation Test		Y		
508 RXH HYbrid4		Seat belts not fastened warning lights unit				Read ECU Information		Y		
508 RXH HYbrid4		Seat belts not fastened warning lights unit				Actuation Test		Y		
508 RXH HYbrid4		Supply protection and management unit				Read ECU Information		Y		
508 RXH HYbrid4		Supply protection and management unit				Live Data		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Read ECU Information		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Read Fault Code		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Erase Fault Code		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Live Data		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Read ECU Information		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Read Fault Code		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Erase Fault Code		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Live Data		Y		
508 RXH HYbrid4		Rain and brightness sensor				Read ECU Information		Y		
508 RXH HYbrid4		Rain and brightness sensor				Read Fault Code		Y		
508 RXH HYbrid4		Rain and brightness sensor				Erase Fault Code		Y		
508 RXH HYbrid4		Rain and brightness sensor				Live Data		Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Read ECU Information		Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Read Fault Code		Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Erase Fault Code		Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Live Data		Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Actuation Test		Y		
508 RXH HYbrid4		Rear air conditioning				Read ECU Information		Y		
508 RXH HYbrid4		Rear air conditioning				Live Data		Y		
508 RXH HYbrid4		Rear air conditioning				Actuation Test		Y		
508 RXH HYbrid4		Motorised Boot ECU				Read ECU Information		Y		
508 RXH HYbrid4		Motorised Boot ECU				Read Fault Code		Y		
508 RXH HYbrid4		Motorised Boot ECU				Erase Fault Code		Y		
508 RXH HYbrid4		Motorised Boot ECU				Live Data		Y		

508 RXH HYbrid4		Motorised Boot ECU				Actuation Test		Y		
508 RXH HYbrid4		Driver's seat position memory module	BDMC			Read ECU Information		Y		
508 RXH HYbrid4		Driver's seat position memory module	BDMC			Read Fault Code		Y		
508 RXH HYbrid4		Driver's seat position memory module	BDMC			Erase Fault Code		Y		
508 RXH HYbrid4		Driver's seat position memory module	BDMC			Live Data		Y		
508 RXH HYbrid4		Driver's seat position memory module	BDMC			Actuation Test		Y		
508 RXH HYbrid4		Driver's door module	PDPC			Read ECU Information		Y		
508 RXH HYbrid4		Driver's door module	PDPC			Read Fault Code		Y		
508 RXH HYbrid4		Driver's door module	PDPC			Erase Fault Code		Y		
508 RXH HYbrid4		Driver's door module	PDPC			Live Data		Y		
508 RXH HYbrid4		Driver's door module	PDPC			Actuation Test		Y		
508 RXH HYbrid4		Electronic key reader				Read ECU Information		Y		
508 RXH HYbrid4		Electronic key reader				Read Fault Code		Y		
508 RXH HYbrid4		Electronic key reader				Erase Fault Code		Y		
508 RXH HYbrid4		Electronic key reader				Live Data		Y		
508 RXH HYbrid4		High Head Vision				Read ECU Information		Y		
508 RXH HYbrid4		High Head Vision				Read Fault Code		Y		
508 RXH HYbrid4		High Head Vision				Erase Fault Code		Y		
508 RXH HYbrid4		High Head Vision				Live Data		Y		
508 RXH HYbrid4		High Head Vision				Actuation Test		Y		
508 RXH HYbrid4		Main beams assistant ECU				Read ECU Information		Y		
508 RXH HYbrid4		Main beams assistant ECU				Read Fault Code		Y		
508 RXH HYbrid4		Main beams assistant ECU				Erase Fault Code		Y		
508 RXH HYbrid4		Main beams assistant ECU				Live Data		Y		
508 RXH HYbrid4		Main beams assistant ECU				Actuation Test		Y		
508 RXH HYbrid4		Left hand front wiper motor	Yes			Read ECU Information		Y		
508 RXH HYbrid4		Left hand front wiper motor	Yes			Read Fault Code		Y		
508 RXH HYbrid4		Left hand front wiper motor	Yes			Erase Fault Code		Y		
508 RXH HYbrid4		Left hand front wiper motor	Yes			Live Data		Y		
508 RXH HYbrid4		Left hand front wiper motor	Yes			Actuation Test		Y		
508 RXH HYbrid4		Left hand front wiper motor	No			Read ECU Information		Y		
508 RXH HYbrid4		Right hand front wiper motor	Yes			Read ECU Information		Y		
508 RXH HYbrid4		Right hand front wiper motor	No			Read ECU Information		Y		
508 RXH HYbrid4		Right hand front wiper motor	No			Read Fault Code		Y		
508 RXH HYbrid4		Right hand front wiper motor	No			Erase Fault Code		Y		
508 RXH HYbrid4		Right hand front wiper motor	No			Live Data		Y		
508 RXH HYbrid4		Right hand front wiper motor	No			Actuation Test		Y		
508 RXH HYbrid4		External CD player				Read ECU Information		Y		
508 RXH HYbrid4		External CD player				Read Fault Code		Y		
508 RXH HYbrid4		External CD player				Erase Fault Code		Y		
508 RXH HYbrid4		External CD player				Live Data		Y		
508 RXH HYbrid4		External CD player				Actuation Test		Y		
508 RXH HYbrid4		Hybrid control ECU 1				Read ECU Information		Y		
508 RXH HYbrid4		Hybrid control ECU 1				Read Fault Code		Y		
508 RXH HYbrid4		Hybrid control ECU 1				Erase Fault Code		Y		
508 RXH HYbrid4		Hybrid control ECU 1				Live Data		Y		
508 RXH HYbrid4		Hybrid control ECU 1				Actuation Test		Y		
508 RXH HYbrid4		Hybrid control ECU 2				Read ECU Information		Y		
508 RXH HYbrid4		Hybrid control ECU 2				Read Fault Code		Y		
508 RXH HYbrid4		Hybrid control ECU 2				Erase Fault Code		Y		
508 RXH HYbrid4		Hybrid control ECU 2				Live Data		Y		
508 RXH HYbrid4		Traction battery ECU				Read ECU Information		Y		
508 RXH HYbrid4		Traction battery ECU				Read Fault Code		Y		
508 RXH HYbrid4		Traction battery ECU				Erase Fault Code		Y		
508 RXH HYbrid4		Traction battery ECU				Live Data		Y		
508 RXH HYbrid4		Traction battery ECU				Actuation Test		Y		
508 RXH HYbrid4		Hybrid mode selector				Read ECU Information		Y		
508 RXH HYbrid4		Hybrid mode selector				Read Fault Code		Y		
508 RXH HYbrid4		Hybrid mode selector				Live Data		Y		
508 RXH HYbrid4		Hybrid mode selector				Actuation Test		Y		
2008		BSI(Built-in Systems				Read ECU Information		Y		

2008		BSI(Built-in Systems				Read Fault Code		Y		
2008		BSI(Built-in Systems				Erase Fault Code		Y		
2008		BSI(Built-in Systems				Special Function	Maintenance - BSI operating mode	Y		
2008		BSI(Built-in Systems				Special Function	Configuration	Y		
2008		BSI(Built-in Systems				Special Function	Pack Repair	Y		
2008		Engine management ECU	VD46			Read ECU Information		Y		
2008		Engine management ECU	VD46			Read Fault Code		Y		
2008		Engine management ECU	VD46			Erase Fault Code		Y		
2008		Engine management ECU	VD46			Live Data		Y		
2008		Engine management ECU	VD46			Actuation Test		Y		
2008		Engine management ECU	VD46			Special Function	Pack Repair	Y		
2008		Engine management ECU	MED17 4 4			Read ECU Information		Y		
2008		Engine management ECU	MED17 4 4			Read Fault Code		Y		
2008		Engine management ECU	MED17 4 4			Erase Fault Code		Y		
2008		Engine management ECU	MED17 4 4			Live Data		Y		
2008		Engine management ECU	MED17 4 4			Actuation Test		Y		
2008		Engine management ECU	MED17 4 4			Special Function	Pack Repair	Y		
2008		Engine management ECU	ME745 EC5	ME745 EC5 NFP		Read ECU Information		Y		
2008		Engine management ECU	ME745 EC5	ME745 EC5 NFP		Read Fault Code		Y		
2008		Engine management ECU	ME745 EC5	ME745 EC5 NFP		Erase Fault Code		Y		
2008		Engine management ECU	ME745 EC5	ME745 EC5 NFP		Live Data		Y		
2008		Engine management ECU	ME745 EC5	ME745 EC5 NFP		Actuation Test		Y		
2008		Engine management ECU	ME745 EC5	ME745 EC5 NFP		Special Function	Configuration	Y		
2008		Engine management ECU	ME745 EC5	ME745 EC5 NFP		Special Function	Pack Repair	Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Read ECU Information		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Read Fault Code		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Erase Fault Code		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Live Data		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Actuation Test		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Special Function	OK	Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Read ECU Information		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Read Fault Code		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Erase Fault Code		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Live Data		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Actuation Test		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Special Function	OK	Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AL4			Read ECU Information		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AL4			Read Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AL4			Erase Fault Code		Y		

2008		Automatic gearbox or controlled manual gearbox	BVA AL4			Live Data		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AL4			Actuation Test		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AL4			Special Function	Configuration	Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AL4			Special Function	Pack Repair	Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read ECU Information		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Erase Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Live Data		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Actuation Test		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Special Function	Pack Repair	Y		
2008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Special Function	Configuration	Y		
2008		Air bags and pre-tensioners control unit				Read ECU Information		Y		
2008		Air bags and pre-tensioners control unit				Read Fault Code		Y		
2008		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
2008		Air bags and pre-tensioners control unit				Live Data		Y		
2008		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
2008		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
2008		Traction control mode				Read ECU Information		Y		
2008		Traction control mode				Read Fault Code		Y		
2008		Traction control mode				Live Data		Y		
2008		Traction control mode				Actuation Test		Y		
2008		Telematic unit (RTx) or audio-navigation	MRN			Read ECU Information		Y		
2008		Telematic unit (RTx) or audio-navigation	MRN			Read Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	MRN			Erase Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	MRN			Live Data		Y		
2008		Telematic unit (RTx) or audio-navigation	MRN			Actuation Test		Y		
2008		Control panel dot matrix display	Yes	Colour matrix screen		Read ECU Information		Y		
2008		Control panel dot matrix display	Yes	Colour matrix screen		Read Fault Code		Y		
2008		Control panel dot matrix display	Yes	Colour matrix screen		Erase Fault Code		Y		
2008		Control panel dot matrix display	Yes	Colour matrix screen		Actuation Test		Y		
2008		Control panel dot matrix display	No	Monochrome matrix screen		Read ECU Information		Y		
2008		Control panel dot matrix display	No	Monochrome matrix screen		Read Fault Code		Y		
2008		Control panel dot matrix display	No	Monochrome matrix screen		Erase Fault Code		Y		
2008		Control panel dot matrix display	No	Monochrome matrix screen		Actuation Test		Y		
2008		Parking assistance	AAS UDS			Read ECU Information		Y		
2008		Parking assistance	AAS UDS			Read Fault Code		Y		

2008		Parking assistance	AAS UDS			Erase Fault Code		Y		
2008		Parking assistance	AAS UDS			Live Data		Y		
2008		Parking assistance	AAS UDS			Actuation Test		Y		
2008		Controls under the steering wheel				Read ECU Information		Y		
2008		Controls under the steering wheel				Read Fault Code		Y		
2008		Controls under the steering wheel				Erase Fault Code		Y		
2008		Controls under the steering wheel				Live Data		Y		
2008		Controls under the steering wheel				Actuation Test		Y		
2008		Power steering	DAE A515			Read ECU Information		Y		
2008		Power steering	DAE A515			Read Fault Code		Y		
2008		Power steering	DAE A515			Erase Fault Code		Y		
2008		Power steering	DAE A515			Live Data		Y		
2008		Power steering	DAE A515			Actuation Test		Y		
2008		Rain and brightness sensor				Read ECU Information		Y		
2008		Rain and brightness sensor				Read Fault Code		Y		
2008		Rain and brightness sensor				Erase Fault Code		Y		
2008		Rain and brightness sensor				Live Data		Y		
2008		Rain and brightness sensor				Special Function	Pack Repair	Y		
2008		Hands-free control unit				Read ECU Information		Y		
2008		Hands-free control unit				Read Fault Code		Y		
2008		Hands-free control unit				Erase Fault Code		Y		
2008		Hands-free control unit				Live Data		Y		
2008		Hands-free control unit				Special Function	Configuration	Y		
2008		Electric steering lock				Read ECU Information		Y		
2008		Electric steering lock				Read Fault Code		Y		
2008		Electric steering lock				Erase Fault Code		Y		
2008		Electric steering lock				Live Data		Y		
2008		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
2008		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
2008		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
2008		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
2008		Control on the steering wheel / integral controls steering wheel				Actuation Test		Y		
2008		Electronic key reader				Read ECU Information		Y		
2008		Electronic key reader				Read Fault Code		Y		
2008		Electronic key reader				Erase Fault Code		Y		
2008		Electronic key reader				Live Data		Y		
2008		Air conditioning	TDC RFTA MUX			Read ECU Information		Y		
2008		Air conditioning	TDC RFTA MUX			Read Fault Code		Y		
2008		Air conditioning	TDC RFTA MUX			Erase Fault Code		Y		
2008		Air conditioning	TDC RFTA MUX			Live Data		Y		
2008		Air conditioning	TDC RFTA MUX			Actuation Test		Y		
2008		Air conditioning	TDC RFTA MUX			Special Function	Configuration	Y		
2008		Air conditioning	TDC RFTA MUX			Special Function	Pack Repair	Y		
2008		Air conditioning	TDC CH MUX			Read ECU Information		Y		
2008		Air conditioning	TDC CH MUX			Read Fault Code		Y		
2008		Air conditioning	TDC CH MUX			Erase Fault Code		Y		
2008		Air conditioning	TDC CH MUX			Live Data		Y		
2008		Air conditioning	TDC CH MUX			Actuation Test		Y		
2008		Air conditioning	TDC CH MUX			Special Function	Pack Repair	Y		
2008		Air conditioning	TDC RF MUX			Read ECU Information		Y		
2008		Air conditioning	TDC RF MUX			Read Fault Code		Y		

2008		Air conditioning	TDC RF MUX			Erase Fault Code		Y		
2008		Air conditioning	TDC RF MUX			Live Data		Y		
2008		Air conditioning	TDC RF MUX			Actuation Test		Y		
2008		Air conditioning	TDC RF MUX			Special Function	Pack Repair	Y		
2008		Instrument panel				Read ECU Information		Y		
2008		Instrument panel				Read Fault Code		Y		
2008		Instrument panel				Erase Fault Code		Y		
2008		Instrument panel				Live Data		Y		
2008		Instrument panel				Actuation Test		Y		
2008		Instrument panel				Special Function	Configuration	Y		
2008		Instrument panel				Special Function	Pack Repair	Y		
2008		Multiplexed control panel				Read ECU Information		Y		
2008		Multiplexed control panel				Read Fault Code		Y		
2008		Multiplexed control panel				Erase Fault Code		Y		
2008		Multiplexed control panel				Live Data		Y		
2008		Multiplexed control panel				Actuation Test		Y		
2008		Voltage retaining device	DMTC			Read ECU Information		Y		
2008		Voltage retaining device	DMTR			Read ECU Information		Y		
2008		Voltage retaining device	DMTR			Read Fault Code		Y		
2008		Voltage retaining device	DMTR			Erase Fault Code		Y		
2008		Voltage retaining device	DMTR DTC3B			Read ECU Information		Y		
2008		Voltage retaining device	DMTR DTC3B			Read Fault Code		Y		
2008		Voltage retaining device	DMTR DTC3B			Erase Fault Code		Y		
2008		Battery charge status unit				Read ECU Information		Y		
2008		Battery charge status unit				Live Data		Y		
3008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
3008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
3008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
3008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
3008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
3008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Special Function	Configuration	Y		
3008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Read ECU Information		Y		
3008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Read Fault Code		Y		
3008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Erase Fault Code		Y		
3008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Live Data		Y		
3008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Actuation Test		Y		
3008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Special Function	Configuration	Y		
3008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Read ECU Information		Y		
3008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Read Fault Code		Y		
3008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Erase Fault Code		Y		
3008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Live Data		Y		
3008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Actuation Test		Y		
3008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Special Function	Configuration	Y		
3008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Read ECU Information		Y		
3008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Read Fault Code		Y		
3008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Erase Fault Code		Y		
3008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Live Data		Y		
3008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Actuation Test		Y		
3008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Special Function	Configuration	Y		
3008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Read ECU Information		Y		
3008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Read Fault Code		Y		
3008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Erase Fault Code		Y		
3008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Live Data		Y		
3008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Actuation Test		Y		
3008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Special Function	Configuration	Y		

3008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17_4_4			Read ECU Information		Y		
3008		Engine management ECU	MED17_4_4			Read Fault Code		Y		
3008		Engine management ECU	MED17_4_4			Erase Fault Code		Y		
3008		Engine management ECU	MED17_4_4			Live Data		Y		
3008		Engine management ECU	MED17_4_4			Actuation Test		Y		
3008		Engine management ECU	MED17_4_4			Special Function	Pack Repair	Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4_5FW		Read ECU Information		Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4_5FW		Read Fault Code		Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4_5FW		Erase Fault Code		Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4_5FW		Live Data		Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4_5FW		Actuation Test		Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4_5FW		Special Function	Configuration	Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4_5FW		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4_5FX		Read ECU Information		Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4_5FX		Read Fault Code		Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4_5FX		Erase Fault Code		Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4_5FX		Live Data		Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4_5FX		Actuation Test		Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4_5FX		Special Function	Configuration	Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4_5FX		Special Function	Pack Repair	Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5_5FS		Read ECU Information		Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5_5FS		Read Fault Code		Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5_5FS		Erase Fault Code		Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5_5FS		Live Data		Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5_5FS		Actuation Test		Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5_5FS		Special Function	Configuration	Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5_5FS		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5_5FV		Read ECU Information		Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5_5FV		Read Fault Code		Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5_5FV		Erase Fault Code		Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5_5FV		Live Data		Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5_5FV		Actuation Test		Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5_5FV		Special Function	Configuration	Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5_5FV		Special Function	Pack Repair	Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Read ECU Information		Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Read Fault Code		Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Erase Fault Code		Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Live Data		Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Actuation Test		Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Special Function	Pack Repair	Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Read ECU Information		Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Read Fault Code		Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Erase Fault Code		Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Live Data		Y		

3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Actuation Test		Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Special Function	Pack Repair	Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read ECU Information		Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read Fault Code		Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Erase Fault Code		Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Live Data		Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Actuation Test		Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Configuration	Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Pack Repair	Y		
3008		Engine management ECU	EDC17C60			Read ECU Information		Y		
3008		Engine management ECU	EDC17C60			Read Fault Code		Y		
3008		Engine management ECU	EDC17C60			Erase Fault Code		Y		
3008		Engine management ECU	EDC17C60			Live Data		Y		
3008		Engine management ECU	EDC17C60			Actuation Test		Y		
3008		Engine management ECU	EDC17C60			Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Read ECU Information		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Read Fault Code		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Erase Fault Code		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Live Data		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Actuation Test		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Read ECU Information		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Read Fault Code		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Erase Fault Code		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Live Data		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Actuation Test		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Read ECU Information		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Read Fault Code		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Erase Fault Code		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Live Data		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Actuation Test		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Special Function	Configuration	Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Read ECU Information		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Read Fault Code		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Erase Fault Code		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Live Data		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Actuation Test		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Special Function	Configuration	Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Read ECU Information		Y		
3008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Read Fault Code		Y		
3008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Erase Fault Code		Y		
3008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Live Data		Y		
3008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Actuation Test		Y		
3008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Special Function	Configuration	Y		
3008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Read ECU Information		Y		
3008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Read Fault Code		Y		
3008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Erase Fault Code		Y		
3008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Live Data		Y		
3008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Actuation Test		Y		
3008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Special Function	Configuration	Y		
3008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Special Function	Pack Repair	Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HR		Read ECU Information		Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HR		Read Fault Code		Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HR		Erase Fault Code		Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HR		Live Data		Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HR		Actuation Test		Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HR		Special Function	Configuration	Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HR		Special Function	Pack Repair	Y		

3008		Engine management ECU	HDI SID807	HDI SID807 9HL		Read ECU Information		Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HL		Read Fault Code		Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HL		Erase Fault Code		Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HL		Live Data		Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HL		Actuation Test		Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HL		Special Function	Configuration	Y		
3008		Engine management ECU	HDI SID807	HDI SID807 9HL		Special Function	Pack Repair	Y		
3008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Read ECU Information		Y		
3008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Read Fault Code		Y		
3008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Erase Fault Code		Y		
3008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Live Data		Y		
3008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Actuation Test		Y		
3008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Special Function	Configuration	Y		
3008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Special Function	Pack Repair	Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read ECU Information		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read Fault Code		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Erase Fault Code		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Live Data		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Actuation Test		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Special Function	Configuration	Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Special Function	Pack Repair	Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read ECU Information		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read Fault Code		Y		

3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Erase Fault Code		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Live Data		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Actuation Test		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Special Function	Pack Repair	Y		
3008		Air bags and pre-tensioners control unit				Read ECU Information		Y		
3008		Air bags and pre-tensioners control unit				Read Fault Code		Y		
3008		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
3008		Air bags and pre-tensioners control unit				Live Data		Y		
3008		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
3008		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
3008		Power steering				Read ECU Information		Y		
3008		Power steering				Read Fault Code		Y		
3008		Power steering				Erase Fault Code		Y		
3008		Power steering				Live Data		Y		
3008		Power steering				Actuation Test		Y		
3008		Diesel additive function	PADDGO			Read ECU Information		Y		
3008		Diesel additive function	PADDGO			Read Fault Code		Y		
3008		Diesel additive function	PADDGO			Erase Fault Code		Y		
3008		Diesel additive function	PADDGO			Live Data		Y		
3008		Diesel additive function	PADDGO			Actuation Test		Y		
3008		Diesel additive function	PADDGO			Special Function	Configuration	Y		
3008		Diesel additive function	POMPE MUX TI			Read ECU Information		Y		
3008		Diesel additive function	POMPE MUX TI			Read Fault Code		Y		
3008		Diesel additive function	POMPE MUX TI			Erase Fault Code		Y		
3008		Diesel additive function	POMPE MUX TI			Live Data		Y		
3008		Diesel additive function	POMPE MUX TI			Actuation Test		Y		
3008		Diesel additive function	POMPE MUX TI			Special Function	Configuration	Y		
3008		Diesel additive function	PADDGO TI E6			Read ECU Information		Y		
3008		Diesel additive function	PADDGO TI E6			Read Fault Code		Y		
3008		Diesel additive function	PADDGO TI E6			Erase Fault Code		Y		
3008		Diesel additive function	PADDGO TI E6			Live Data		Y		
3008		Diesel additive function	PADDGO TI E6			Special Function	Configuration	Y		
3008		Under inflation detection	DSG UDS			Read ECU Information		Y		
3008		Under inflation detection	DSG UDS			Read Fault Code		Y		
3008		Under inflation detection	DSG UDS			Erase Fault Code		Y		
3008		Under inflation detection	DSG UDS			Live Data		Y		
3008		Under inflation detection	DSG UDS			Special Function	Pack Reparation	Y		
3008		Under inflation detection	DSG			Read ECU Information		Y		
3008		Under inflation detection	DSG			Read Fault Code		Y		
3008		Under inflation detection	DSG			Erase Fault Code		Y		
3008		Under inflation detection	DSG			Live Data		Y		
3008		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
3008		Dynamic headlamp height adjuster				Read ECU Information		Y		
3008		Dynamic headlamp height adjuster				Read Fault Code		Y		
3008		Dynamic headlamp height adjuster				Erase Fault Code		Y		
3008		Dynamic headlamp height adjuster				Live Data		Y		
3008		Dynamic headlamp height adjuster				Actuation Test		Y		
3008		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
3008		Dynamic headlamp height adjuster				Special Function	Pack repair	Y		

3008		Battery charge status unit	BECB			Read ECU Information		Y		
3008		Battery charge status unit	BECB			Live Data		Y		
3008		Battery charge status unit	BECB GEN2			Read ECU Information		Y		
3008		Battery charge status unit	BECB GEN2			Live Data		Y		
3008		Battery charge status unit	BECB GEN2			Special Function	Configuration	Y		
3008		Battery charge status unit	BECB GEN2			Special Function	Pack Repair	Y		
3008		Vehicle Distance Assistance				Read ECU Information		Y		
3008		Vehicle Distance Assistance				Read Fault Code		Y		
3008		Vehicle Distance Assistance				Erase Fault Code		Y		
3008		Vehicle Distance Assistance				Live Data		Y		
3008		Vehicle Distance Assistance				Special Function	Configuration	Y		
3008		Vehicle Distance Assistance				Special Function	Pack repair	Y		
3008		Electric secondary brake				Read ECU Information		Y		
3008		Electric secondary brake				Read Fault Code		Y		
3008		Electric secondary brake				Erase Fault Code		Y		
3008		Electric secondary brake				Live Data		Y		
3008		Electric secondary brake				Actuation Test		Y		
3008		Electric secondary brake				Special Function	Pack Repair	Y		
3008		Trailer relay unit				Read ECU Information		Y		
3008		Trailer relay unit				Read Fault Code		Y		
3008		Trailer relay unit				Erase Fault Code		Y		
3008		Engine relay unit				Read ECU Information		Y		
3008		Engine relay unit				Read Fault Code		Y		
3008		Engine relay unit				Erase Fault Code		Y		
3008		Engine relay unit				Actuation Test		Y		
3008		Air conditioning				Read ECU Information		Y		
3008		Air conditioning				Read Fault Code		Y		
3008		Air conditioning				Erase Fault Code		Y		
3008		Air conditioning				Live Data		Y		
3008		Air conditioning				Actuation Test		Y		
3008		Air conditioning				Special Function	Configuration	Y		
3008		Air conditioning				Special Function	Pack Repair	Y		
3008		Controls under the steering wheel				Read ECU Information		Y		
3008		Controls under the steering wheel				Read Fault Code		Y		
3008		Controls under the steering wheel				Erase Fault Code		Y		
3008		Controls under the steering wheel				Live Data		Y		
3008		Controls under the steering wheel				Actuation Test		Y		
3008		Controls under the steering wheel				Special Function	Pack repair	Y		
3008		Multifunction screen	Type "A" (segments),with buttons			Read ECU Information		Y		
3008		Multifunction screen	Type "A" (segments),with buttons			Read Fault Code		Y		
3008		Multifunction screen	Type "A" (segments),with buttons			Erase Fault Code		Y		
3008		Multifunction screen	Type "A" (segments),with buttons			Live Data		Y		
3008		Multifunction screen	Type "A" (segments),with buttons			Actuation Test		Y		
3008		Multifunction screen	Type "A" (segments),with buttons			Special Function	Configuration	Y		
3008		Multifunction screen	Type "A" (segments),with buttons			Special Function	Pack repair	Y		
3008		Multifunction screen	Type "A" (segments),without			Read ECU Information		Y		
3008		Multifunction screen	Type "A" (segments),without			Read Fault Code		Y		
3008		Multifunction screen	Type "A" (segments),without			Erase Fault Code		Y		
3008		Multifunction screen	Type "A" (segments),without			Live Data		Y		

3008		Multifunction screen	Type "A" (segments),without			Actuation Test		Y		
3008		Multifunction screen	Type "A" (segments),without			Special Function	Configuration	Y		
3008		Multifunction screen	Type "A" (segments),without			Special Function	Pack repair	Y		
3008		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
3008		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
3008		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
3008		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
3008		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
3008		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
3008		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack repair	Y		
3008		Multifunction screen	Type "C colour" (dot			Read ECU Information		Y		
3008		Multifunction screen	Type "C colour" (dot			Read Fault Code		Y		
3008		Multifunction screen	Type "C colour" (dot			Erase Fault Code		Y		
3008		Multifunction screen	Type "C colour" (dot			Live Data		Y		
3008		Multifunction screen	Type "C colour" (dot			Actuation Test		Y		
3008		Multifunction screen	Type "C colour" (dot			Special Function	Configuration	Y		
3008		Multifunction screen	Type "C colour" (dot			Special Function	Pack repair	Y		
3008		Instrument panel				Read ECU Information		Y		
3008		Instrument panel				Read Fault Code		Y		
3008		Instrument panel				Erase Fault Code		Y		
3008		Instrument panel				Live Data		Y		
3008		Instrument panel				Actuation Test		Y		
3008		Windscreen wiper				Read ECU Information		Y		
3008		Windscreen wiper				Actuation Test		Y		
3008		Windscreen wiper				Special Function	Configuration	Y		
3008		Windscreen wiper				Special Function	Pack Repair	Y		
3008		Parking assistance				Read ECU Information		Y		
3008		Parking assistance				Read Fault Code		Y		
3008		Parking assistance				Erase Fault Code		Y		
3008		Parking assistance				Live Data		Y		
3008		Parking assistance				Special Function	Configuration	Y		
3008		Parking assistance				Special Function	Pack Repair	Y		
3008		Radio	RD4			Read ECU Information		Y		
3008		Radio	RD4			Read Fault Code		Y		
3008		Radio	RD4			Erase Fault Code		Y		
3008		Radio	RD4			Live Data		Y		
3008		Radio	RD4			Actuation Test		Y		
3008		Radio	RD4			Special Function	Configuration	Y		
3008		Radio	RD4			Special Function	Replacement parts	Y		
3008		Radio	RD45			Read ECU Information		Y		
3008		Radio	RD45			Read Fault Code		Y		
3008		Radio	RD45			Erase Fault Code		Y		
3008		Radio	RD45			Live Data		Y		
3008		Radio	RD45			Actuation Test		Y		
3008		Radio	RD45			Special Function	Configuration	Y		
3008		Radio	RD45			Special Function	Pack Repair	Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Read ECU Information		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Read Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Erase Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Live Data		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Actuation Test		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Special Function	Configuration	Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Read ECU Information		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Read Fault Code		Y		

3008		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Erase Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Live Data		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Actuation Test		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Special Function	Configuration	Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read ECU Information		Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Erase Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Live Data		Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Actuation Test		Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Configuration	Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Pack repair	Y		
3008		Audio amplifier				Read ECU Information		Y		
3008		Audio amplifier				Read Fault Code		Y		
3008		Audio amplifier				Erase Fault Code		Y		
3008		Audio amplifier				Actuation Test		Y		
3008		Audio amplifier				Special Function	Configuration	Y		
3008		Audio amplifier				Special Function	Pack Repair	Y		
3008		CD player / External CD				Read ECU Information		Y		
3008		CD player / External CD				Read Fault Code		Y		
3008		CD player / External CD				Erase Fault Code		Y		
3008		CD player / External CD				Actuation Test		Y		
3008		CD player / External CD				Special Function	Configuration	Y		
3008		Hands-free kit / Portable				Read ECU Information		Y		
3008		Hands-free kit / Portable				Read Fault Code		Y		
3008		Hands-free kit / Portable				Erase Fault Code		Y		
3008		Hands-free kit / Portable				Live Data		Y		
3008		Hands-free kit / Portable				Actuation Test		Y		
3008		Hands-free kit / Portable				Special Function	Configuration	Y		
3008		Hands-free kit / Portable				Special Function	Pack repair	Y		
3008		Anti-theft alarm				Read ECU Information		Y		
3008		Anti-theft alarm				Read Fault Code		Y		
3008		Anti-theft alarm				Erase Fault Code		Y		
3008		Anti-theft alarm				Live Data		Y		
3008		Anti-theft alarm				Actuation Test		Y		
3008		Anti-theft alarm				Special Function	Configuration	Y		
3008		Anti-theft alarm				Special Function	Pack repair	Y		
3008		Traction control mode				Read ECU Information		Y		
3008		Traction control mode				Read Fault Code		Y		
3008		Traction control mode				Live Data		Y		
3008		Traction control mode				Actuation Test		Y		
3008		Driver's door module	Driver's door module			Read ECU Information		Y		
3008		Driver's door module	Driver's door module			Read Fault Code		Y		
3008		Driver's door module	Driver's door module			Erase Fault Code		Y		
3008		Driver's door module	Driver's door module			Live Data		Y		
3008		Driver's door module	Driver's door module			Actuation Test		Y		
3008		Control panel dot matrix display				Read ECU Information		Y		
3008		Control panel dot matrix display				Read Fault Code		Y		
3008		Control panel dot matrix display				Erase Fault Code		Y		
3008		Control panel dot matrix display				Live Data		Y		
3008		Control panel dot matrix display				Actuation Test		Y		

3008		Control panel dot matrix display				Special Function	Configuration	Y		
3008		service module /Independent telematic unit	MD_SERV			Read ECU Information		Y		
3008		service module /Independent telematic unit	MD_SERV			Read Fault Code		Y		
3008		service module /Independent telematic unit	MD_SERV			Erase Fault Code		Y		
3008		service module /Independent telematic unit	MD_SERV			Live Data		Y		
3008		service module /Independent telematic unit	MD_SERV			Actuation Test		Y		
3008		service module /Independent telematic unit	MD_SERV			Special Function	Configuration	Y		
3008		service module /Independent telematic unit	MD_SERV			Special Function	Pack Repair	Y		
3008		service module /Independent telematic unit	BTA			Read ECU Information		Y		
3008		service module /Independent telematic unit	BTA			Read Fault Code		Y		
3008		service module /Independent telematic unit	BTA			Erase Fault Code		Y		
3008		service module /Independent telematic unit	BTA			Live Data		Y		
3008		service module /Independent telematic unit	BTA			Actuation Test		Y		
3008		service module /Independent telematic unit	BTA			Special Function	Configuration	Y		
3008		service module /Independent telematic unit	BTA			Special Function	Pack Repair	Y		
3008		Network isolation control				Read ECU Information		Y		
3008		Network isolation control				Live Data		Y		
3008		Rain and brightness sensor				Read ECU Information		Y		
3008		Rain and brightness sensor				Read Fault Code		Y		
3008		Rain and brightness sensor				Erase Fault Code		Y		
3008		Voltage retaining device	DMTC			Read ECU Information		Y		
3008		Voltage retaining device	DMTR			Read ECU Information		Y		
3008		Voltage retaining device	DMTR			Read Fault Code		Y		
3008		Voltage retaining device	DMTR			Erase Fault Code		Y		
3008		High Head Vision	VTH			Read ECU Information		Y		
3008		High Head Vision	VTH			Read Fault Code		Y		
3008		High Head Vision	VTH			Erase Fault Code		Y		
3008		High Head Vision	VTH			Live Data		Y		
3008		High Head Vision	VTH			Actuation Test		Y		
3008		High Head Vision	VTH			Special Function	Configuration	Y		
3008		High Head Vision	VTH_UDS			Read ECU Information		Y		
3008		High Head Vision	VTH_UDS			Read Fault Code		Y		
3008		High Head Vision	VTH_UDS			Erase Fault Code		Y		
3008		High Head Vision	VTH_UDS			Live Data		Y		
3008		High Head Vision	VTH_UDS			Actuation Test		Y		
3008		High Head Vision	VTH_UDS			Special Function	Configuration	Y		
3008		High Head Vision	VTH_UDS			Special Function	Pack repair	Y		
3008		High frequency receiver				Read ECU Information		Y		
3008		High frequency receiver				Read Fault Code		Y		
3008		High frequency receiver				Erase Fault Code		Y		
3008		High frequency receiver				Live Data		Y		
3008		Seat belts not fastened LED unit				Read ECU Information		Y		
3008		Seat belts not fastened LED unit				Actuation Test		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Read ECU Information		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Read Fault Code		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Erase Fault Code		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Live Data		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Actuation Test		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Special Function	Configuration	Y		

3008 HYbrid4		Engine management ECU	DCM35 HY	RHC DW10CTED4-163CV		Special Function	Pack Repair	Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Read ECU Information		Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Read Fault Code		Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Live Data		Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
3008 HYbrid4		Power steering				Read ECU Information		Y		
3008 HYbrid4		Power steering				Read Fault Code		Y		
3008 HYbrid4		Power steering				Erase Fault Code		Y		
3008 HYbrid4		Power steering				Live Data		Y		
3008 HYbrid4		Power steering				Actuation Test		Y		
3008 HYbrid4		Under inflation detection	DSG UDS			Read ECU Information		Y		
3008 HYbrid4		Under inflation detection	DSG UDS			Read Fault Code		Y		
3008 HYbrid4		Under inflation detection	DSG UDS			Erase Fault Code		Y		
3008 HYbrid4		Under inflation detection	DSG UDS			Live Data		Y		
3008 HYbrid4		Under inflation detection	DSG UDS			Special Function	Pack Reparation	Y		
3008 HYbrid4		Under inflation detection	DSG			Read ECU Information		Y		
3008 HYbrid4		Under inflation detection	DSG			Read Fault Code		Y		
3008 HYbrid4		Under inflation detection	DSG			Erase Fault Code		Y		
3008 HYbrid4		Under inflation detection	DSG			Live Data		Y		
3008 HYbrid4		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
3008 HYbrid4		Electric secondary brake				Read ECU Information		Y		
3008 HYbrid4		Electric secondary brake				Read Fault Code		Y		
3008 HYbrid4		Electric secondary brake				Erase Fault Code		Y		
3008 HYbrid4		Electric secondary brake				Live Data		Y		
3008 HYbrid4		Electric secondary brake				Actuation Test		Y		
3008 HYbrid4		Electric secondary brake				Special Function	Pack Repair	Y		
3008 HYbrid4		Trailer relay unit				Read ECU Information		Y		
3008 HYbrid4		Trailer relay unit				Read Fault Code		Y		
3008 HYbrid4		Trailer relay unit				Erase Fault Code		Y		
3008 HYbrid4		Engine relay unit				Read ECU Information		Y		
3008 HYbrid4		Engine relay unit				Read Fault Code		Y		
3008 HYbrid4		Engine relay unit				Erase Fault Code		Y		
3008 HYbrid4		Engine relay unit				Actuation Test		Y		
3008 HYbrid4		Air conditioning				Read ECU Information		Y		
3008 HYbrid4		Air conditioning				Read Fault Code		Y		
3008 HYbrid4		Air conditioning				Erase Fault Code		Y		
3008 HYbrid4		Air conditioning				Live Data		Y		

3008 HYbrid4		Air conditioning				Actuation Test		Y		
3008 HYbrid4		Air conditioning				Special Function	Configuration	Y		
3008 HYbrid4		Air conditioning				Special Function	Pack Repair	Y		
3008 HYbrid4		Controls under the steering wheel				Read ECU Information		Y		
3008 HYbrid4		Controls under the steering wheel				Read Fault Code		Y		
3008 HYbrid4		Controls under the steering wheel				Erase Fault Code		Y		
3008 HYbrid4		Controls under the steering wheel				Live Data		Y		
3008 HYbrid4		Controls under the steering wheel				Actuation Test		Y		
3008 HYbrid4		Controls under the steering wheel				Special Function	Pack repair	Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),with buttons			Read ECU Information		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),with buttons			Read Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),with buttons			Erase Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),with buttons			Live Data		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),with buttons			Actuation Test		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),with buttons			Special Function	Configuration	Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),with buttons			Special Function	Pack repair	Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),without			Read ECU Information		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),without			Read Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),without			Erase Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),without			Live Data		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),without			Actuation Test		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),without			Special Function	Configuration	Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments),without			Special Function	Pack repair	Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack repair	Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot			Read ECU Information		Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot			Read Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot			Erase Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot			Live Data		Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot			Actuation Test		Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot			Special Function	Configuration	Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot			Special Function	Pack repair	Y		
3008 HYbrid4		Instrument panel				Read ECU Information		Y		
3008 HYbrid4		Instrument panel				Read Fault Code		Y		
3008 HYbrid4		Instrument panel				Erase Fault Code		Y		
3008 HYbrid4		Instrument panel				Live Data		Y		
3008 HYbrid4		Instrument panel				Actuation Test		Y		
3008 HYbrid4		Windscreen wiper				Read ECU Information		Y		
3008 HYbrid4		Windscreen wiper				Actuation Test		Y		
3008 HYbrid4		Windscreen wiper				Special Function	Configuration	Y		
3008 HYbrid4		Windscreen wiper				Special Function	Pack Repair	Y		

3008 HYbrid4		Parking assistance				Read ECU Information		Y		
3008 HYbrid4		Parking assistance				Read Fault Code		Y		
3008 HYbrid4		Parking assistance				Erase Fault Code		Y		
3008 HYbrid4		Parking assistance				Live Data		Y		
3008 HYbrid4		Parking assistance				Special Function	Configuration	Y		
3008 HYbrid4		Parking assistance				Special Function	Pack Repair	Y		
3008 HYbrid4		Radio	RD4			Read ECU Information		Y		
3008 HYbrid4		Radio	RD4			Read Fault Code		Y		
3008 HYbrid4		Radio	RD4			Erase Fault Code		Y		
3008 HYbrid4		Radio	RD4			Live Data		Y		
3008 HYbrid4		Radio	RD4			Actuation Test		Y		
3008 HYbrid4		Radio	RD4			Special Function	Configuration	Y		
3008 HYbrid4		Radio	RD4			Special Function	Replacement parts	Y		
3008 HYbrid4		Radio	RD45			Read ECU Information		Y		
3008 HYbrid4		Radio	RD45			Read Fault Code		Y		
3008 HYbrid4		Radio	RD45			Erase Fault Code		Y		
3008 HYbrid4		Radio	RD45			Live Data		Y		
3008 HYbrid4		Radio	RD45			Actuation Test		Y		
3008 HYbrid4		Radio	RD45			Special Function	Configuration	Y		
3008 HYbrid4		Radio	RD45			Special Function	Pack Repair	Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Read ECU Information		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Read Fault Code		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Erase Fault Code		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Live Data		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Actuation Test		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Special Function	Configuration	Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read ECU Information		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read Fault Code		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Erase Fault Code		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Live Data		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Actuation Test		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Configuration	Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Pack repair	Y		
3008 HYbrid4		Audio amplifier				Read ECU Information		Y		
3008 HYbrid4		Audio amplifier				Read Fault Code		Y		
3008 HYbrid4		Audio amplifier				Erase Fault Code		Y		
3008 HYbrid4		Audio amplifier				Actuation Test		Y		
3008 HYbrid4		Audio amplifier				Special Function	Configuration	Y		
3008 HYbrid4		Audio amplifier				Special Function	Pack Repair	Y		
3008 HYbrid4		CD player / External CD				Read ECU Information		Y		
3008 HYbrid4		CD player / External CD				Read Fault Code		Y		
3008 HYbrid4		CD player / External CD				Erase Fault Code		Y		
3008 HYbrid4		CD player / External CD				Actuation Test		Y		
3008 HYbrid4		CD player / External CD				Special Function	Configuration	Y		
3008 HYbrid4		Hands-free kit / Portable				Read ECU Information		Y		
3008 HYbrid4		Hands-free kit / Portable				Read Fault Code		Y		
3008 HYbrid4		Hands-free kit / Portable				Erase Fault Code		Y		
3008 HYbrid4		Hands-free kit / Portable				Live Data		Y		
3008 HYbrid4		Hands-free kit / Portable				Actuation Test		Y		
3008 HYbrid4		Hands-free kit / Portable				Special Function	Configuration	Y		
3008 HYbrid4		Hands-free kit / Portable				Special Function	Pack repair	Y		
3008 HYbrid4		Anti-theft alarm				Read ECU Information		Y		
3008 HYbrid4		Anti-theft alarm				Read Fault Code		Y		

3008 HYbrid4		Anti-theft alarm				Erase Fault Code		Y		
3008 HYbrid4		Anti-theft alarm				Live Data		Y		
3008 HYbrid4		Anti-theft alarm				Actuation Test		Y		
3008 HYbrid4		Anti-theft alarm				Special Function	Configuration	Y		
3008 HYbrid4		Anti-theft alarm				Special Function	Pack repair	Y		
3008 HYbrid4		Driver's door module	Driver's door module			Read ECU Information		Y		
3008 HYbrid4		Driver's door module	Driver's door module			Read Fault Code		Y		
3008 HYbrid4		Driver's door module	Driver's door module			Erase Fault Code		Y		
3008 HYbrid4		Driver's door module	Driver's door module			Live Data		Y		
3008 HYbrid4		Driver's door module	Driver's door module			Actuation Test		Y		
3008 HYbrid4		Control panel dot matrix display				Read ECU Information		Y		
3008 HYbrid4		Control panel dot matrix display				Read Fault Code		Y		
3008 HYbrid4		Control panel dot matrix display				Erase Fault Code		Y		
3008 HYbrid4		Control panel dot matrix display				Live Data		Y		
3008 HYbrid4		Control panel dot matrix display				Actuation Test		Y		
3008 HYbrid4		Control panel dot matrix display				Special Function	Configuration	Y		
3008 HYbrid4		Service module /Independent telematic unit	MD SERV			Read ECU Information		Y		
3008 HYbrid4		Service module /Independent telematic unit	MD SERV			Read Fault Code		Y		
3008 HYbrid4		Service module /Independent telematic unit	MD SERV			Erase Fault Code		Y		
3008 HYbrid4		Service module /Independent telematic unit	MD SERV			Live Data		Y		
3008 HYbrid4		Service module /Independent telematic unit	MD SERV			Actuation Test		Y		
3008 HYbrid4		Service module /Independent telematic unit	MD SERV			Special Function	Configuration	Y		
3008 HYbrid4		Service module /Independent telematic unit	MD SERV			Special Function	Pack Repair	Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Read ECU Information		Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Read Fault Code		Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Erase Fault Code		Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Live Data		Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Actuation Test		Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Special Function	Configuration	Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Special Function	Pack Repair	Y		
3008 HYbrid4		Rain and brightness sensor				Read ECU Information		Y		
3008 HYbrid4		Rain and brightness sensor				Read Fault Code		Y		
3008 HYbrid4		Rain and brightness sensor				Erase Fault Code		Y		
3008 HYbrid4		High Head Vision	VTH			Read ECU Information		Y		
3008 HYbrid4		High Head Vision	VTH			Read Fault Code		Y		
3008 HYbrid4		High Head Vision	VTH			Erase Fault Code		Y		
3008 HYbrid4		High Head Vision	VTH			Live Data		Y		
3008 HYbrid4		High Head Vision	VTH			Actuation Test		Y		
3008 HYbrid4		High Head Vision	VTH			Special Function	Configuration	Y		
3008 HYbrid4		High Head Vision	VTH UDS			Read ECU Information		Y		
3008 HYbrid4		High Head Vision	VTH UDS			Read Fault Code		Y		
3008 HYbrid4		High Head Vision	VTH UDS			Erase Fault Code		Y		
3008 HYbrid4		High Head Vision	VTH UDS			Live Data		Y		
3008 HYbrid4		High Head Vision	VTH UDS			Actuation Test		Y		
3008 HYbrid4		High Head Vision	VTH UDS			Special Function	Configuration	Y		
3008 HYbrid4		High Head Vision	VTH UDS			Special Function	Pack repair	Y		

3008 HYbrid4		Hybrid mode selector				Read ECU Information		Y		
3008 HYbrid4		Hybrid mode selector				Read Fault Code		Y		
3008 HYbrid4		Hybrid mode selector				Live Data		Y		
3008 HYbrid4		Hybrid mode selector				Actuation Test		Y		
3008 HYbrid4		Traction battery ECU				Read ECU Information		Y		
3008 HYbrid4		Traction battery ECU				Read Fault Code		Y		
3008 HYbrid4		Traction battery ECU				Erase Fault Code		Y		
3008 HYbrid4		Traction battery ECU				Live Data		Y		
3008 HYbrid4		Traction battery ECU				Actuation Test		Y		
3008 HYbrid4		Hybrid control ECU 1				Read ECU Information		Y		
3008 HYbrid4		Hybrid control ECU 1				Read Fault Code		Y		
3008 HYbrid4		Hybrid control ECU 1				Erase Fault Code		Y		
3008 HYbrid4		Hybrid control ECU 1				Live Data		Y		
3008 HYbrid4		Hybrid control ECU 1				Actuation Test		Y		
3008 HYbrid4		Hybrid control ECU 1				Special Function	Pack repair	Y		
3008 HYbrid4		Hybrid control ECU 2				Read ECU Information		Y		
3008 HYbrid4		Hybrid control ECU 2				Read Fault Code		Y		
3008 HYbrid4		Hybrid control ECU 2				Erase Fault Code		Y		
3008 HYbrid4		Hybrid control ECU 2				Live Data		Y		
3008 HYbrid4		Battery charge status unit				Read ECU Information		Y		
3008 HYbrid4		Battery charge status unit				Live Data		Y		
3008 HYbrid4		Battery charge status unit				Special Function	Configuration	Y		
3008 HYbrid4		Battery charge status unit				Special Function	Pack Repair	Y		
3008 HYbrid4		Diesel additive function				Read ECU Information		Y		
3008 HYbrid4		Diesel additive function				Read Fault Code		Y		
3008 HYbrid4		Diesel additive function				Erase Fault Code		Y		
3008 HYbrid4		Diesel additive function				Live Data		Y		
3008 HYbrid4		Diesel additive function				Actuation Test		Y		
3008 HYbrid4		Diesel additive function				Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 2	14 MED17.4.2 EURO 5	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 2	14 MED17.4.2 EURO 5	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 2	14 MED17.4.2 EURO 5	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 2	14 MED17.4.2 EURO 5	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 2	14 MED17.4.2 EURO 5	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 2	14 MED17.4.2 EURO 5	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 2	14 MED17.4.2 EURO 5	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 4		Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 4		Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 4		Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 4		Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 4		Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 4		Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO4	MEV17_4_EURO4 5FW	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Read ECU Information		Y		

3008 Chine		Engine management ECU	Petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO4	MED17_4_EURO4 5FX	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MEV17 4 EURO5	MEV17_4_EURO5 5FS	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Actuation Test		Y		

3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HR	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HR	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HR	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HR	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HR	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HR	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HR	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807_9HL	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2_9HR	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2_9HR	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2_9HR	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2_9HR	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2_9HR	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2_9HR	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2_9HR	Special Function	Pack Repair	Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EUR05			Read ECU Information		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EUR05			Read Fault Code		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EUR05			Erase Fault Code		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EUR05			Live Data		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EUR05			Actuation Test		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EUR05			Special Function	Configuration	Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EUR05			Special Function	Pack Repair	Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		

3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read ECU Information		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read Fault Code		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Erase Fault Code		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Live Data		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Actuation Test		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Special Function	Pack Repair	Y		
3008 Chine		Air bags and pre-tensioners control unit				Read ECU Information		Y		
3008 Chine		Air bags and pre-tensioners control unit				Read Fault Code		Y		
3008 Chine		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
3008 Chine		Air bags and pre-tensioners control unit				Live Data		Y		
3008 Chine		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
3008 Chine		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
3008 Chine		Power steering				Read ECU Information		Y		
3008 Chine		Power steering				Read Fault Code		Y		
3008 Chine		Power steering				Erase Fault Code		Y		
3008 Chine		Power steering				Live Data		Y		
3008 Chine		Power steering				Actuation Test		Y		
3008 Chine		Under inflation detection	DSG UDS			Read ECU Information		Y		
3008 Chine		Under inflation detection	DSG UDS			Read Fault Code		Y		
3008 Chine		Under inflation detection	DSG UDS			Erase Fault Code		Y		
3008 Chine		Under inflation detection	DSG UDS			Live Data		Y		
3008 Chine		Under inflation detection	DSG UDS			Special Function	Pack Reparation	Y		
3008 Chine		Under inflation detection	DSG			Read ECU Information		Y		
3008 Chine		Under inflation detection	DSG			Read Fault Code		Y		
3008 Chine		Under inflation detection	DSG			Erase Fault Code		Y		
3008 Chine		Under inflation detection	DSG			Live Data		Y		
3008 Chine		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
3008 Chine		Battery charge status unit				Read ECU Information		Y		
3008 Chine		Battery charge status unit				Live Data		Y		
3008 Chine		Electric secondary brake				Read ECU Information		Y		

3008 Chine		Electric secondary brake				Read Fault Code		Y		
3008 Chine		Electric secondary brake				Erase Fault Code		Y		
3008 Chine		Electric secondary brake				Live Data		Y		
3008 Chine		Electric secondary brake				Actuation Test		Y		
3008 Chine		Electric secondary brake				Special Function	Pack Repair	Y		
3008 Chine		Engine relay unit				Read ECU Information		Y		
3008 Chine		Engine relay unit				Read Fault Code		Y		
3008 Chine		Engine relay unit				Erase Fault Code		Y		
3008 Chine		Engine relay unit				Actuation Test		Y		
3008 Chine		Air conditioning				Read ECU Information		Y		
3008 Chine		Air conditioning				Read Fault Code		Y		
3008 Chine		Air conditioning				Erase Fault Code		Y		
3008 Chine		Air conditioning				Live Data		Y		
3008 Chine		Air conditioning				Actuation Test		Y		
3008 Chine		Air conditioning				Special Function	Configuration	Y		
3008 Chine		Air conditioning				Special Function	Pack Repair	Y		
3008 Chine		Multifunction screen	Type "A" (segments),with buttons			Read ECU Information		Y		
3008 Chine		Multifunction screen	Type "A" (segments),with buttons			Read Fault Code		Y		
3008 Chine		Multifunction screen	Type "A" (segments),with buttons			Erase Fault Code		Y		
3008 Chine		Multifunction screen	Type "A" (segments),with buttons			Live Data		Y		
3008 Chine		Multifunction screen	Type "A" (segments),with buttons			Actuation Test		Y		
3008 Chine		Multifunction screen	Type "A" (segments),with buttons			Special Function	Configuration	Y		
3008 Chine		Multifunction screen	Type "A" (segments),with buttons			Special Function	Pack repair	Y		
3008 Chine		Multifunction screen	Type "A" (segments),without			Read ECU Information		Y		
3008 Chine		Multifunction screen	Type "A" (segments),without			Read Fault Code		Y		
3008 Chine		Multifunction screen	Type "A" (segments),without			Erase Fault Code		Y		
3008 Chine		Multifunction screen	Type "A" (segments),without			Live Data		Y		
3008 Chine		Multifunction screen	Type "A" (segments),without			Actuation Test		Y		
3008 Chine		Multifunction screen	Type "A" (segments),without			Special Function	Configuration	Y		
3008 Chine		Multifunction screen	Type "A" (segments),without			Special Function	Pack repair	Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack repair	Y		
3008 Chine		Multifunction screen	Type "C colour" (dot			Read ECU Information		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot			Read Fault Code		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot			Erase Fault Code		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot			Live Data		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot			Actuation Test		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot			Special Function	Configuration	Y		
3008 Chine		Multifunction screen	Type "C colour" (dot			Special Function	Pack repair	Y		
3008 Chine		Instrument panel				Read ECU Information		Y		
3008 Chine		Instrument panel				Read Fault Code		Y		
3008 Chine		Instrument panel				Erase Fault Code		Y		
3008 Chine		Instrument panel				Live Data		Y		
3008 Chine		Instrument panel				Actuation Test		Y		
3008 Chine		Radio	RD43			Read ECU Information		Y		
3008 Chine		Radio	RD43			Read Fault Code		Y		
3008 Chine		Radio	RD43			Erase Fault Code		Y		

3008 Chine		Radio	RD43			Live Data		Y		
3008 Chine		Radio	RD43			Actuation Test		Y		
3008 Chine		Radio	RD43			Special Function	Configuration	Y		
3008 Chine		Radio	RD43			Special Function	Replacement parts	Y		
3008 Chine		Radio	RD45			Read ECU Information		Y		
3008 Chine		Radio	RD45			Read Fault Code		Y		
3008 Chine		Radio	RD45			Erase Fault Code		Y		
3008 Chine		Radio	RD45			Live Data		Y		
3008 Chine		Radio	RD45			Actuation Test		Y		
3008 Chine		Radio	RD45			Special Function	Configuration	Y		
3008 Chine		Radio	RD45			Special Function	Pack Repair	Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEGC			Read ECU Information		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEGC			Read Fault Code		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEGC			Erase Fault Code		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEGC			Live Data		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEGC			Actuation Test		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEGC			Special Function	Configuration	Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEGC			Special Function	Pack repair	Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Read ECU Information		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Read Fault Code		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Erase Fault Code		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Live Data		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Actuation Test		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Special Function	Configuration	Y		
3008 Chine		Anti-theft alarm				Read ECU Information		Y		
3008 Chine		Anti-theft alarm				Read Fault Code		Y		
3008 Chine		Anti-theft alarm				Erase Fault Code		Y		
3008 Chine		Anti-theft alarm				Live Data		Y		
3008 Chine		Anti-theft alarm				Actuation Test		Y		
3008 Chine		Traction control mode				Read ECU Information		Y		
3008 Chine		Traction control mode				Read Fault Code		Y		
3008 Chine		Traction control mode				Live Data		Y		
3008 Chine		Traction control mode				Actuation Test		Y		
3008 Chine		Driver's door module	Driver's door module			Read ECU Information		Y		
3008 Chine		Driver's door module	Driver's door module			Read Fault Code		Y		
3008 Chine		Driver's door module	Driver's door module			Erase Fault Code		Y		
3008 Chine		Driver's door module	Driver's door module			Live Data		Y		
3008 Chine		Driver's door module	Driver's door module			Actuation Test		Y		
3008 Chine		Control panel dot matrix display				Read ECU Information		Y		
3008 Chine		Control panel dot matrix display				Read Fault Code		Y		
3008 Chine		Control panel dot matrix display				Erase Fault Code		Y		
3008 Chine		Control panel dot matrix display				Live Data		Y		
3008 Chine		Control panel dot matrix display				Actuation Test		Y		
3008 Chine		Control panel dot matrix display				Special Function	Configuration	Y		
3008 Chine		Rain and brightness sensor				Read ECU Information		Y		
3008 Chine		Rain and brightness sensor				Read Fault Code		Y		
3008 Chine		Rain and brightness sensor				Erase Fault Code		Y		

3008 Chine		Voltage retaining device	DMTC			Read ECU Information		Y		
3008 Chine		Voltage retaining device	DMTR			Read ECU Information		Y		
3008 Chine		Voltage retaining device	DMTR			Read Fault Code		Y		
3008 Chine		Voltage retaining device	DMTR			Erase Fault Code		Y		
3008 Chine		Controls under the steering wheel	YES			Read ECU Information		Y		
3008 Chine		Controls under the steering wheel	YES			Read Fault Code		Y		
3008 Chine		Controls under the steering wheel	YES			Erase Fault Code		Y		
3008 Chine		Controls under the steering wheel	YES			Live Data		Y		
3008 Chine		Controls under the steering wheel	YES			Actuation Test		Y		
3008 Chine		Controls under the steering wheel	NO			Read ECU Information		Y		
3008 Chine		Controls under the steering wheel	NO			Read Fault Code		Y		
3008 Chine		Controls under the steering wheel	NO			Erase Fault Code		Y		
3008 Chine		Controls under the steering wheel	NO			Live Data		Y		
3008 Chine		Controls under the steering wheel	NO			Actuation Test		Y		
3008 Chine		Controls under the steering wheel	NO			Special Function	Pack repair	Y		
3008 Chine		Windscreen wiper				Read ECU Information		Y		
3008 Chine		Windscreen wiper				Actuation Test		Y		
3008 Chine		High Head Vision	VTH			Read ECU Information		Y		
3008 Chine		High Head Vision	VTH			Read Fault Code		Y		
3008 Chine		High Head Vision	VTH			Erase Fault Code		Y		
3008 Chine		High Head Vision	VTH			Live Data		Y		
3008 Chine		High Head Vision	VTH			Actuation Test		Y		
3008 Chine		High Head Vision	VTH			Special Function	Configuration	Y		
3008 Chine		High Head Vision	VTH UDS			Read ECU Information		Y		
3008 Chine		High Head Vision	VTH UDS			Read Fault Code		Y		
3008 Chine		High Head Vision	VTH UDS			Erase Fault Code		Y		
3008 Chine		High Head Vision	VTH UDS			Live Data		Y		
3008 Chine		High Head Vision	VTH UDS			Actuation Test		Y		
3008 Chine		High Head Vision	VTH UDS			Special Function	Configuration	Y		
3008 Chine		High Head Vision	VTH UDS			Special Function	Pack repair	Y		
3008 Chine		Parking assistance				Read ECU Information		Y		
3008 Chine		Parking assistance				Read Fault Code		Y		
3008 Chine		Parking assistance				Erase Fault Code		Y		
3008 Chine		Parking assistance				Live Data		Y		
3008 Chine		Parking assistance				Special Function	Configuration	Y		
3008 Chine		Parking assistance				Special Function	Pack Repair	Y		
3008 Chine		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
3008 Chine		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
3008 Chine		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
3008 Chine		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
3008 Chine		Multifunction video				Read ECU Information		Y		
3008 Chine		Multifunction video				Read Fault Code		Y		
3008 Chine		Multifunction video				Erase Fault Code		Y		
3008 Chine		Multifunction video				Live Data		Y		
3008 Chine		Multifunction video				Actuation Test		Y		
3008 Chine		Panoramic vision assistance				Read ECU Information		Y		
3008 Chine		Panoramic vision assistance				Read Fault Code		Y		

3008 Chine		Panoramic vision assistance				Erase Fault Code		Y		
3008 Chine		Panoramic vision assistance				Live Data		Y		
3008 Chine		Panoramic vision assistance				Actuation Test		Y		
3008 Chine		Panoramic vision assistance				Special Function	Pack Repair	Y		
3008 Chine		Panoramic vision assistance				Special Function	Learning	Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Read ECU Information		Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Read Fault Code		Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Erase Fault Code		Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Live Data		Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Actuation Test		Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Special Function	Pack Repair	Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17 4 4		Read ECU Information		Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17 4 4		Read Fault Code		Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17 4 4		Erase Fault Code		Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17 4 4		Live Data		Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17 4 4		Actuation Test		Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17 4 4		Special Function	Pack Repair	Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Read ECU Information		Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Read Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Erase Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Live Data		Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Actuation Test		Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Special Function	Pack Repair	Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Read ECU Information		Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Read Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Erase Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Live Data		Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Actuation Test		Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Special Function	Pack Repair	Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Special Function	Configuration	Y		
3008(P84)		Engine management ECU	Diesel Engine	CMM DCM71		Read ECU Information		Y		
3008(P84)		Engine management ECU	Diesel Engine	CMM DCM71		Read Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	CMM DCM71		Erase Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	CMM DCM71		Live Data		Y		
3008(P84)		Engine management ECU	Diesel Engine	CMM DCM71		Actuation Test		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read ECU Information		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read Fault Code		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Erase Fault Code		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Live Data		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Actuation Test		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Special Function	Pack Repair	Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read ECU Information		Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read Fault Code		Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Erase Fault Code		Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Live Data		Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Actuation Test		Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Special Function	Pack Repair	Y		

3008(P84)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
3008(P84)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
3008(P84)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
3008(P84)		Air bags and pre-tensioners control unit				Live Data		Y		
3008(P84)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
3008(P84)		Engine relay unit				Read ECU Information		Y		
3008(P84)		Engine relay unit				Read Fault Code		Y		
3008(P84)		Engine relay unit				Erase Fault Code		Y		
3008(P84)		Intrusion alarm siren				Read ECU Information		Y		
3008(P84)		Intrusion alarm siren				Read Fault Code		Y		
3008(P84)		Intrusion alarm siren				Erase Fault Code		Y		
3008(P84)		Intrusion alarm siren				Live Data		Y		
3008(P84)		Intrusion alarm siren				Actuation Test		Y		
3008(P84)		Intrusion alarm siren				Special Function	Configuration	Y		
3008(P84)		Intrusion alarm siren				Special Function	Pack Repair	Y		
3008(P84)		Driver's door module	Yes			Read ECU Information		Y		
3008(P84)		Driver's door module	Yes			Read Fault Code		Y		
3008(P84)		Driver's door module	Yes			Erase Fault Code		Y		
3008(P84)		Driver's door module	Yes			Live Data		Y		
3008(P84)		Driver's door module	Yes			Actuation Test		Y		
3008(P84)		Driver's door module	No			Read ECU Information		Y		
3008(P84)		Driver's door module	No			Read Fault Code		Y		
3008(P84)		Driver's door module	No			Erase Fault Code		Y		
3008(P84)		Driver's door module	No			Live Data		Y		
3008(P84)		Driver's door module	No			Actuation Test		Y		
3008(P84)		Dynamic headlamp height adjuster				Read ECU Information		Y		
3008(P84)		Dynamic headlamp height adjuster				Read Fault Code		Y		
3008(P84)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
3008(P84)		Dynamic headlamp height adjuster				Live Data		Y		
3008(P84)		Dynamic headlamp height adjuster				Actuation Test		Y		
3008(P84)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
3008(P84)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
3008(P84)		Seat belt not fastened warning lights unit				Read ECU Information		Y		
3008(P84)		Seat belt not fastened warning lights unit				Actuation Test		Y		
3008(P84)		Battery charge status unit				Read ECU Information		Y		
3008(P84)		Battery charge status unit				Read Fault Code		Y		
3008(P84)		Battery charge status unit				Erase Fault Code		Y		
3008(P84)		Battery charge status unit				Live Data		Y		
3008(P84)		Battery charge status unit				Special Function	Configuration	Y		
3008(P84)		Battery charge status unit				Special Function	Pack Repair	Y		
3008(P84)		Parking assistance	4 parking assistance			Read ECU Information		Y		
3008(P84)		Parking assistance	4 parking assistance			Read Fault Code		Y		
3008(P84)		Parking assistance	4 parking assistance			Erase Fault Code		Y		
3008(P84)		Parking assistance	4 parking assistance			Live Data		Y		
3008(P84)		Parking assistance	4 parking assistance			Actuation Test		Y		
3008(P84)		Parking assistance	8 parking assistance			Read ECU Information		Y		
3008(P84)		Parking assistance	8 parking assistance			Read Fault Code		Y		
3008(P84)		Parking assistance	8 parking assistance			Erase Fault Code		Y		
3008(P84)		Parking assistance	8 parking assistance			Live Data		Y		
3008(P84)		Parking assistance	8 parking assistance			Actuation Test		Y		
3008(P84)		Parking assistance	10 parking assistance			Read ECU Information		Y		
3008(P84)		Parking assistance	10 parking assistance			Read Fault Code		Y		

3008(P84)		Parking assistance	10 parking assistance			Erase Fault Code		Y		
3008(P84)		Parking assistance	10 parking assistance			Live Data		Y		
3008(P84)		Parking assistance	10 parking assistance			Actuation Test		Y		
3008(P84)		Multifunction screen	EMF C UDS			Read ECU Information		Y		
3008(P84)		Multifunction screen	EMF C UDS			Read Fault Code		Y		
3008(P84)		Multifunction screen	EMF C UDS			Erase Fault Code		Y		
3008(P84)		Multifunction screen	EMF C UDS			Actuation Test		Y		
3008(P84)		Air conditioning				Read ECU Information		Y		
3008(P84)		Air conditioning				Read Fault Code		Y		
3008(P84)		Air conditioning				Erase Fault Code		Y		
3008(P84)		Air conditioning				Live Data		Y		
3008(P84)		Air conditioning				Actuation Test		Y		
3008(P84)		Air conditioning				Special Function	Pack Repair	Y		
3008(P84)		Panoramic vision assistance				Read ECU Information		Y		
3008(P84)		Panoramic vision assistance				Read Fault Code		Y		
3008(P84)		Panoramic vision assistance				Erase Fault Code		Y		
3008(P84)		Panoramic vision assistance				Live Data		Y		
3008(P84)		Panoramic vision assistance				Actuation Test		Y		
3008(P84)		Panoramic vision assistance				Special Function	Pack Repair	Y		
3008(P84)		Hands full access ECU, right-hand side or rear				Read ECU Information		Y		
3008(P84)		Hands full access ECU, right-hand side or rear				Read Fault Code		Y		
3008(P84)		Controls under the steering wheel				Read ECU Information		Y		
3008(P84)		Controls under the steering wheel				Read Fault Code		Y		
3008(P84)		Controls under the steering wheel				Erase Fault Code		Y		
3008(P84)		Controls under the steering wheel				Live Data		Y		
3008(P84)		Controls under the steering wheel				Actuation Test		Y		
3008(P84)		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
3008(P84)		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
3008(P84)		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
3008(P84)		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
3008(P84)		Supply protection and management unit				Read ECU Information		Y		
3008(P84)		Supply protection and management unit				Read Fault Code		Y		
3008(P84)		Supply protection and management unit				Erase Fault Code		Y		
3008(P84)		Supply protection and management unit				Live Data		Y		
3008(P84)		Voltage retaining device	DMTC			Read ECU Information		Y		
3008(P84)		Voltage retaining device	DMTR DTC3B			Read ECU Information		Y		
3008(P84)		Voltage retaining device	DMTR DTC3B			Read Fault Code		Y		
3008(P84)		Voltage retaining device	DMTR DTC3B			Erase Fault Code		Y		
3008(P84)		Diesel additive pump				Read ECU Information		Y		
3008(P84)		Diesel additive pump				Read Fault Code		Y		
3008(P84)		Diesel additive pump				Erase Fault Code		Y		
3008(P84)		Diesel additive pump				Live Data		Y		
3008(P84)		Diesel additive pump				Actuation Test		Y		
3008(P84)		Traction control mode				Read ECU Information		Y		
3008(P84)		Traction control mode				Read Fault Code		Y		
3008(P84)		Traction control mode				Live Data		Y		
3008(P84)		Traction control mode				Actuation Test		Y		

3008(P84)		Electric steering lock				Read ECU Information		Y		
3008(P84)		Electric steering lock				Read Fault Code		Y		
3008(P84)		Electric steering lock				Erase Fault Code		Y		
3008(P84)		Electric steering lock				Live Data		Y		
3008(P84)		Trailer relay unit				Read ECU Information		Y		
3008(P84)		Trailer relay unit				Read Fault Code		Y		
3008(P84)		Trailer relay unit				Erase Fault Code		Y		
3008(P84)		Trailer relay unit				Live Data		Y		
3008(P84)		Trailer relay unit				Actuation Test		Y		
3008(P84)		Power steering				Read ECU Information		Y		
3008(P84)		Power steering				Read Fault Code		Y		
3008(P84)		Power steering				Erase Fault Code		Y		
3008(P84)		Power steering				Live Data		Y		
3008(P84)		Front left seat heated pads and ventilation regulation				Read ECU Information		Y		
3008(P84)		Front left seat heated pads and ventilation regulation				Read Fault Code		Y		
3008(P84)		Front left seat heated pads and ventilation regulation				Live Data		Y		
3008(P84)		Front left seat heated pads and ventilation regulation				Actuation Test		Y		
3008(P84)		Front right seat heated pads and ventilation regulation				Read ECU Information		Y		
3008(P84)		Front right seat heated pads and ventilation regulation				Read Fault Code		Y		
3008(P84)		Front right seat heated pads and ventilation regulation				Live Data		Y		
3008(P84)		Front right seat heated pads and ventilation regulation				Actuation Test		Y		
3008(P84)		Automatic gearbox electric control				Read ECU Information		Y		
3008(P84)		Automatic gearbox electric control				Read Fault Code		Y		
3008(P84)		Automatic gearbox electric control				Erase Fault Code		Y		
3008(P84)		Automatic gearbox electric control				Live Data		Y		
3008(P84)		Automatic gearbox electric control				Actuation Test		Y		
3008(P84)		Automatic gearbox electric control				Special Function	Programming	Y		
3008(P84)		Automatic gearbox electric control				Special Function	Replacement parts	Y		
3008(P84)		Motorised Boot ECU				Read ECU Information		Y		
3008(P84)		Motorised Boot ECU				Read Fault Code		Y		
3008(P84)		Motorised Boot ECU				Erase Fault Code		Y		
3008(P84)		Motorised Boot ECU				Live Data		Y		
3008(P84)		Motorised Boot ECU				Actuation Test		Y		
3008(P84)		External CD player				Read ECU Information		Y		
3008(P84)		External CD player				Read Fault Code		Y		
3008(P84)		External CD player				Erase Fault Code		Y		
3008(P84)		External CD player				Live Data		Y		
3008(P84)		External CD player				Actuation Test		Y		
3008(P84)		Anti-theft alarm				Read ECU Information		Y		
3008(P84)		Anti-theft alarm				Read Fault Code		Y		
3008(P84)		Anti-theft alarm				Erase Fault Code		Y		
3008(P84)		Anti-theft alarm				Live Data		Y		
3008(P84)		Anti-theft alarm				Special Function	Configuration	Y		
3008(P84)		Anti-theft alarm				Special Function	Pack Repair	Y		
3008(P84)		Radio amplifier				Read ECU Information		Y		
3008(P84)		Radio amplifier				Read Fault Code		Y		
3008(P84)		Radio amplifier				Erase Fault Code		Y		
3008(P84)		Radio amplifier				Actuation Test		Y		
3008(P84)		Vehicle Distance Assistance				Read ECU Information		Y		
3008(P84)		Vehicle Distance Assistance				Read Fault Code		Y		
3008(P84)		Vehicle Distance Assistance				Erase Fault Code		Y		

3008(P84)		Vehicle Distance Assistance				Live Data		Y		
3008(P84)		Vehicle Distance Assistance				Actuation Test		Y		
3008(P84)		Radio				Read ECU Information		Y		
3008(P84)		Radio				Read Fault Code		Y		
3008(P84)		Radio				Erase Fault Code		Y		
3008(P84)		Radio				Live Data		Y		
3008(P84)		Radio				Actuation Test		Y		
3008(P84)		Rain and brightness sensor				Read ECU Information		Y		
3008(P84)		Rain and brightness sensor				Read Fault Code		Y		
3008(P84)		Rain and brightness sensor				Erase Fault Code		Y		
3008(P84)		Rain and brightness sensor				Live Data		Y		
3008(P84)		Rain and brightness sensor				Special Function	Pack Repair	Y		
3008(P84)		Multifunction video				Read ECU Information		Y		
3008(P84)		Multifunction video				Read Fault Code		Y		
3008(P84)		Multifunction video				Erase Fault Code		Y		
3008(P84)		Multifunction video				Live Data		Y		
3008(P84)		Multifunction video				Actuation Test		Y		
3008(P84)		Push gear lever				Read ECU Information		Y		
3008(P84)		Push gear lever				Read Fault Code		Y		
3008(P84)		Push gear lever				Erase Fault Code		Y		
3008(P84)		Push gear lever				Live Data		Y		
3008(P84)		Push gear lever				Actuation Test		Y		
3008(P84)		Service module / Independent telematic unit	BTA 2			Read ECU Information		Y		
3008(P84)		Service module / Independent telematic unit	BTA 2			Read Fault Code		Y		
3008(P84)		Service module / Independent telematic unit	BTA 2			Erase Fault Code		Y		
3008(P84)		Service module / Independent telematic unit	BTA 2			Live Data		Y		
3008(P84)		Service module / Independent telematic unit	BTA 2			Actuation Test		Y		
3008(P84)		Service module / Independent telematic unit	BTA 2			Special Function	Pack Repair	Y		
3008(P84)		Service module / Independent telematic unit	BTA 3R			Read ECU Information		Y		
3008(P84)		Service module / Independent telematic unit	BTA 3R			Read Fault Code		Y		
3008(P84)		Service module / Independent telematic unit	BTA 3R			Erase Fault Code		Y		
3008(P84)		Service module / Independent telematic unit	BTA 3R			Live Data		Y		
3008(P84)		Service module / Independent telematic unit	BTA 3R			Actuation Test		Y		
3008(P84)		Windscreen wiper				Read ECU Information		Y		
3008(P84)		Windscreen wiper				Read Fault Code		Y		
3008(P84)		Windscreen wiper				Erase Fault Code		Y		
3008(P84)		Windscreen wiper				Live Data		Y		
3008(P84)		Windscreen wiper				Actuation Test		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	NAC			Read ECU Information		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	NAC			Read Fault Code		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	NAC			Erase Fault Code		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	NAC			Live Data		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	NAC			Actuation Test		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	RCC			Read ECU Information		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	RCC			Read Fault Code		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	RCC			Erase Fault Code		Y		

3008(P84)		Audio-navigation/telematic unit/connected audio system	RCC			Live Data		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	RCC			Actuation Test		Y		
3008(P84)		Multiplexed control panel	RD6 audio system without air conditioning			Read ECU Information		Y		
3008(P84)		Multiplexed control panel	RD6 audio system without air conditioning			Read Fault Code		Y		
3008(P84)		Multiplexed control panel	RD6 audio system without air conditioning			Erase Fault Code		Y		
3008(P84)		Multiplexed control panel	RD6 audio system without air conditioning			Live Data		Y		
3008(P84)		Multiplexed control panel	RD6 audio system without air conditioning			Actuation Test		Y		
3008(P84)		Multiplexed control panel	RD6 audio system and manual air conditioning			Read ECU Information		Y		
3008(P84)		Multiplexed control panel	RD6 audio system and manual air conditioning			Read Fault Code		Y		
3008(P84)		Multiplexed control panel	RD6 audio system and manual air conditioning			Erase Fault Code		Y		
3008(P84)		Multiplexed control panel	RD6 audio system and manual air conditioning			Live Data		Y		
3008(P84)		Multiplexed control panel	RD6 audio system and manual air conditioning			Actuation Test		Y		
3008(P84)		Multiplexed control panel	Audio/Navigation NAC			Read ECU Information		Y		
3008(P84)		Multiplexed control panel	Audio/Navigation NAC			Read Fault Code		Y		
3008(P84)		Multiplexed control panel	Audio/Navigation NAC			Erase Fault Code		Y		
3008(P84)		Multiplexed control panel	Audio/Navigation NAC			Live Data		Y		
3008(P84)		Multiplexed control panel	Audio/Navigation NAC			Actuation Test		Y		
3008(P84)		Touch screen				Read ECU Information		Y		
3008(P84)		Touch screen				Read Fault Code		Y		
3008(P84)		Touch screen				Erase Fault Code		Y		
3008(P84)		Touch screen				Live Data		Y		
3008(P84)		Touch screen				Actuation Test		Y		
3008(P84)		Rear air conditioning ECU				Read ECU Information		Y		
3008(P84)		Rear air conditioning ECU				Read Fault Code		Y		
3008(P84)		Rear air conditioning ECU				Erase Fault Code		Y		
3008(P84)		Rear air conditioning ECU				Live Data		Y		
3008(P84)		Rear air conditioning ECU				Actuation Test		Y		
3008(P84)		Rear air conditioning ECU				Special Function	Pack Repair	Y		
3008(P84)		Driver's seat comfort ECU				Read ECU Information		Y		
3008(P84)		Driver's seat comfort ECU				Read Fault Code		Y		
3008(P84)		Driver's seat comfort ECU				Erase Fault Code		Y		
3008(P84)		Driver's seat comfort ECU				Live Data		Y		
3008(P84)		Driver's seat comfort ECU				Actuation Test		Y		
3008(P84)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read ECU Information		Y		
3008(P84)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read Fault Code		Y		
3008(P84)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Live Data		Y		
3008(P84)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Actuation Test		Y		
3008(P84)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read ECU Information		Y		
3008(P84)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read Fault Code		Y		
3008(P84)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Live Data		Y		
3008(P84)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Actuation Test		Y		
4007		BSI(Built-in Systems				Read ECU Information		Y		
4007		BSI(Built-in Systems				Read Fault Code		Y		
4007		BSI(Built-in Systems				Erase Fault Code		Y		
4007		BSI(Built-in Systems				Live Data		Y		
4007		BSI(Built-in Systems				Actuation Test		Y		

4007		Engine ECU	petrol	SFZ 4B12 MIVEC EURO4 .		Read ECU Information		Y		
4007		Engine ECU	petrol	SFZ 4B12 MIVEC EURO4 .		Read Fault Code		Y		
4007		Engine ECU	petrol	SFZ 4B12 MIVEC EURO4 .		Erase Fault Code		Y		
4007		Engine ECU	petrol	SFZ 4B12 MIVEC EURO4 .		Live Data		Y		
4007		Engine ECU	petrol	SFZ 4B12 MIVEC EURO4 .		Actuation Test		Y		
4007		Engine ECU	petrol	SFZ 4B12 MIVEC EURO4 .		Special Function	Pack Repair	Y		
4007		Engine ECU	petrol	AFZ 4B11 MIVEC EURO4 .		Read ECU Information		Y		
4007		Engine ECU	petrol	AFZ 4B11 MIVEC EURO4 .		Read Fault Code		Y		
4007		Engine ECU	petrol	AFZ 4B11 MIVEC EURO4 .		Erase Fault Code		Y		
4007		Engine ECU	petrol	AFZ 4B11 MIVEC EURO4 .		Live Data		Y		
4007		Engine ECU	petrol	AFZ 4B11 MIVEC EURO4 .		Actuation Test		Y		
4007		Engine ECU	petrol	AFZ 4B11 MIVEC EURO4 .		Special Function	Pack Repair	Y		
4007		Engine ECU	petrol	SFY 4B12 MIVEC EURO5 .		Read ECU Information		Y		
4007		Engine ECU	petrol	SFY 4B12 MIVEC EURO5 .		Read Fault Code		Y		
4007		Engine ECU	petrol	SFY 4B12 MIVEC EURO5 .		Erase Fault Code		Y		
4007		Engine ECU	petrol	SFY 4B12 MIVEC EURO5 .		Live Data		Y		
4007		Engine ECU	petrol	SFY 4B12 MIVEC EURO5 .		Actuation Test		Y		
4007		Engine ECU	petrol	SFY 4B12 MIVEC EURO5 .		Special Function	Pack Repair	Y		
4007		Engine ECU	Diesel	4HN EDC16CP39 .		Read ECU Information		Y		
4007		Engine ECU	Diesel	4HN EDC16CP39 .		Read Fault Code		Y		
4007		Engine ECU	Diesel	4HN EDC16CP39 .		Erase Fault Code		Y		
4007		Engine ECU	Diesel	4HN EDC16CP39 .		Live Data		Y		
4007		Engine ECU	Diesel	4HN EDC16CP39 .		Actuation Test		Y		
4007		Engine ECU	Diesel	4HN EDC16CP39 .		Special Function	Pack Repair	Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5 .		Read ECU Information		Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5 .		Read Fault Code		Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5 .		Erase Fault Code		Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5 .		Live Data		Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5 .		Actuation Test		Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5 .		Special Function	Pack Repair	Y		
4007		ABS or ESP ECU	ABS.			Read ECU Information		Y		
4007		ABS or ESP ECU	ABS.			Read Fault Code		Y		
4007		ABS or ESP ECU	ABS.			Erase Fault Code		Y		
4007		ABS or ESP ECU	ABS.			Live Data		Y		
4007		ABS or ESP ECU	ABS.			Actuation Test		Y		
4007		ABS or ESP ECU	ABS.			Special Function	Pack Repair	Y		
4007		ABS or ESP ECU	ESP.			Read ECU Information		Y		
4007		ABS or ESP ECU	ESP.			Read Fault Code		Y		
4007		ABS or ESP ECU	ESP.			Erase Fault Code		Y		
4007		ABS or ESP ECU	ESP.			Live Data		Y		
4007		ABS or ESP ECU	ESP.			Actuation Test		Y		
4007		ABS or ESP ECU	ESP.			Special Function	Pack Repair	Y		
4007		Air bag				Read ECU Information		Y		
4007		Air bag				Read Fault Code		Y		
4007		Air bag				Erase Fault Code		Y		
4007		Air bag				Live Data		Y		
4007		Air bag				Actuation Test		Y		
4007		heating/ventilation				Read ECU Information		Y		
4007		heating/ventilation				Read Fault Code		Y		
4007		heating/ventilation				Erase Fault Code		Y		
4007		heating/ventilation				Live Data		Y		
4007		heating/ventilation				Actuation Test		Y		
4007		Radio				Read ECU Information		Y		
4007		Radio				Read Fault Code		Y		
4007		Radio				Erase Fault Code		Y		
4007		Radio				Live Data		Y		
4007		Radio				Actuation Test		Y		
4007		Navigation				Read ECU Information		Y		
4007		Navigation				Read Fault Code		Y		
4007		Navigation				Erase Fault Code		Y		
4007		Instrument panel				Read ECU Information		Y		
4007		Instrument panel				Read Fault Code		Y		
4007		Instrument panel				Erase Fault Code		Y		
4007		Instrument panel				Live Data		Y		
4007		Instrument panel				Actuation Test		Y		
4007		Instrument panel				Special Function	Pack Repair	Y		

4007		Hands Free Kit				Read ECU Information		Y		
4007		Hands Free Kit				Read Fault Code		Y		
4007		Hands Free Kit				Erase Fault Code		Y		
4007		Hands Free Kit				Live Data		Y		
4007		Hands Free Kit				Actuation Test		Y		
4007		LEVIER GETRAG				Read ECU Information		Y		
4007		LEVIER GETRAG				Read Fault Code		Y		
4007		LEVIER GETRAG				Erase Fault Code		Y		
4007		LEVIER GETRAG				Live Data		Y		
4007		LEVIER GETRAG				Actuation Test		Y		
4007		Coded anti-start				Read ECU Information		Y		
4007		Coded anti-start				Read Fault Code		Y		
4007		Coded anti-start				Erase Fault Code		Y		
4007		Coded anti-start				Live Data		Y		
4007		Driver's door control pad				Read ECU Information		Y		
4007		Driver's door control pad				Read Fault Code		Y		
4007		Driver's door control pad				Erase Fault Code		Y		
4007		Driver's door control pad				Live Data		Y		
4007		Passenger's door control				Read ECU Information		Y		
4007		Passenger's door control				Read Fault Code		Y		
4007		Passenger's door control				Erase Fault Code		Y		
4007		Passenger's door control				Live Data		Y		
4007		Rear LH door switch panel				Read ECU Information		Y		
4007		Rear LH door switch panel				Read Fault Code		Y		
4007		Rear LH door switch panel				Erase Fault Code		Y		
4007		Rear LH door switch panel				Live Data		Y		
4007		Rear RH door switch panel				Read ECU Information		Y		
4007		Rear RH door switch panel				Read Fault Code		Y		
4007		Rear RH door switch panel				Erase Fault Code		Y		
4007		Rear RH door switch panel				Live Data		Y		
4007		Sun roof				Read ECU Information		Y		
4007		Sun roof				Read Fault Code		Y		
4007		Sun roof				Erase Fault Code		Y		
4007		Sun roof				Live Data		Y		
4007		Steering wheel angle sensor				Read ECU Information		Y		
4007		Steering wheel angle sensor				Read Fault Code		Y		
4007		Steering wheel angle sensor				Erase Fault Code		Y		
4007		Steering wheel angle sensor				Special Function	Pack Repair	Y		
4007		Static AFS				Read ECU Information		Y		
4007		Static AFS				Read Fault Code		Y		
4007		Static AFS				Erase Fault Code		Y		
4007		Static AFS				Live Data		Y		
4007		Static AFS				Actuation Test		Y		
4007		Rain and brightness sensor				Read ECU Information		Y		
4007		Rain and brightness sensor				Read Fault Code		Y		
4007		Rain and brightness sensor				Erase Fault Code		Y		
4007		Rain and brightness sensor				Live Data		Y		
4007		Rain and brightness sensor				Special Function	Replacement Parts	Y		
4007		Directional headlamps				Read ECU Information		Y		
4007		Directional headlamps				Read Fault Code		Y		
4007		Directional headlamps				Erase Fault Code		Y		
4007		Directional headlamps				Live Data		Y		
4007		Directional headlamps				Actuation Test		Y		
4007		Directional headlamps				Special Function	Calibration	Y		
4008		BSI(Built-in Systems				Read ECU Information		Y		
4008		BSI(Built-in Systems				Read Fault Code		Y		
4008		BSI(Built-in Systems				Erase Fault Code		Y		
4008		BSI(Built-in Systems				Live Data		Y		
4008		Engine ECU	MIVEC	MIVEC SFZ		Read ECU Information		Y		
4008		Engine ECU	MIVEC	MIVEC SFZ		Read Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC SFZ		Erase Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC SFZ		Actuation Test		Y		
4008		Engine ECU	MIVEC	MIVEC SFZ		Special Function	Pack Repair	Y		
4008		Engine ECU	MIVEC	MIVEC SFY		Read ECU Information		Y		
4008		Engine ECU	MIVEC	MIVEC SFY		Read Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC SFY		Erase Fault Code		Y		

4008		Engine ECU	MIVEC	MIVEC SFY		Actuation Test		Y		
4008		Engine ECU	MIVEC	MIVEC SFY		Special Function	Pack Repair	Y		
4008		Engine ECU	MIVEC	MIVEC AFZ		Read ECU Information		Y		
4008		Engine ECU	MIVEC	MIVEC AFZ		Read Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC AFZ		Erase Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC AFZ		Actuation Test		Y		
4008		Engine ECU	MIVEC	MIVEC AFZ		Special Function	Pack Repair	Y		
4008		Engine ECU	MIVEC	MIVEC AFY		Read ECU Information		Y		
4008		Engine ECU	MIVEC	MIVEC AFY		Read Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC AFY		Erase Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC AFY		Actuation Test		Y		
4008		Engine ECU	MIVEC	MIVEC AFY		Special Function	Pack Repair	Y		
4008		Engine ECU	CMM 4A92			Read ECU Information		Y		
4008		Engine ECU	CMM 4A92			Read Fault Code		Y		
4008		Engine ECU	CMM 4A92			Erase Fault Code		Y		
4008		Engine ECU	CMM 4A92			Live Data		Y		
4008		Engine ECU	CMM 4A92			Actuation Test		Y		
4008		Engine ECU	CMM 4A92			Special Function	Pack Repair	Y		
4008		Engine ECU	HDI 4N13	HDI 4N13		Read ECU Information		Y		
4008		Engine ECU	HDI 4N13	HDI 4N13		Read Fault Code		Y		
4008		Engine ECU	HDI 4N13	HDI 4N13		Erase Fault Code		Y		
4008		Engine ECU	HDI 4N13	HDI 4N13		Live Data		Y		
4008		Engine ECU	HDI 4N13	HDI 4N13 STT		Read ECU Information		Y		
4008		Engine ECU	HDI 4N13	HDI 4N13 STT		Read Fault Code		Y		
4008		Engine ECU	HDI 4N13	HDI 4N13 STT		Erase Fault Code		Y		
4008		Engine ECU	HDI 4N13	HDI 4N13 STT		Live Data		Y		
4008		Engine ECU	HDI SID807 J3J4			Read ECU Information		Y		
4008		Engine ECU	HDI SID807 J3J4			Read Fault Code		Y		
4008		Engine ECU	HDI SID807 J3J4			Erase Fault Code		Y		
4008		Engine ECU	HDI SID807 J3J4			Live Data		Y		
4008		Engine ECU	HDI SID807 J3J4			Actuation Test		Y		
4008		Engine ECU	HDI SID807 J3J4			Special Function	Pack Repair	Y		
4008		gearbox				Read ECU Information		Y		
4008		gearbox				Read Fault Code		Y		
4008		gearbox				Erase Fault Code		Y		
4008		gearbox				Live Data		Y		
4008		gearbox				Special Function	Pack Repair	Y		
4008		ABS/traction control	ABS			Read ECU Information		Y		
4008		ABS/traction control	ABS			Read Fault Code		Y		
4008		ABS/traction control	ABS			Erase Fault Code		Y		
4008		ABS/traction control	ABS			Live Data		Y		
4008		ABS/traction control	ABS			Actuation Test		Y		
4008		ABS/traction control	ESP			Read ECU Information		Y		
4008		ABS/traction control	ESP			Read Fault Code		Y		
4008		ABS/traction control	ESP			Erase Fault Code		Y		
4008		ABS/traction control	ESP			Live Data		Y		
4008		ABS/traction control	ESP			Actuation Test		Y		
4008		ABS/traction control	ESP			Special Function	Pack Repair	Y		
4008		Rear final drive piloted				Read ECU Information		Y		
4008		Rear final drive piloted				Read Fault Code		Y		
4008		Rear final drive piloted				Erase Fault Code		Y		
4008		Rear final drive piloted				Live Data		Y		
4008		Rear final drive piloted				Actuation Test		Y		
4008		Coded anti-start / Hands free starting access electronic module.	WCM			Read ECU Information		Y		
4008		Coded anti-start / Hands free starting access electronic module.	WCM			Read Fault Code		Y		
4008		Coded anti-start / Hands free starting access electronic module.	WCM			Erase Fault Code		Y		
4008		Coded anti-start / Hands free starting access electronic module.	WCM			Live Data		Y		

4008		Coded anti-start / Hands free starting access electronic module.	KOS			Read ECU Information		Y		
4008		Coded anti-start / Hands free starting access electronic module.	KOS			Read Fault Code		Y		
4008		Coded anti-start / Hands free starting access electronic module.	KOS			Erase Fault Code		Y		
4008		Coded anti-start / Hands free starting access electronic module.	KOS			Live Data		Y		
4008		Coded anti-start / Hands free starting access electronic module.	KOS			Actuation Test		Y		
4008		Driver and passenger airbags				Read ECU Information		Y		
4008		Driver and passenger airbags				Read Fault Code		Y		
4008		Driver and passenger airbags				Erase Fault Code		Y		
4008		Driver and passenger airbags				Live Data		Y		
4008		Anti-theft alarm				Read Fault Code		Y		
4008		Anti-theft alarm				Erase Fault Code		Y		
4008		Anti-theft alarm				Live Data		Y		
4008		Starting authorisation ECU				Read ECU Information		Y		
4008		Starting authorisation ECU				Read Fault Code		Y		
4008		Starting authorisation ECU				Erase Fault Code		Y		
4008		Starting authorisation ECU				Live Data		Y		
4008		Calculateur stop and start				Read ECU Information		Y		
4008		Calculateur stop and start				Read Fault Code		Y		
4008		Calculateur stop and start				Erase Fault Code		Y		
4008		Calculateur stop and start				Live Data		Y		
4008		Steering wheel angle sensor				Read ECU Information		Y		
4008		Steering wheel angle sensor				Read Fault Code		Y		
4008		Steering wheel angle sensor				Erase Fault Code		Y		
4008		Steering wheel angle sensor				Special Function	Pack Repair	Y		
4008		Parking aid				Read ECU Information		Y		
4008		Parking aid				Read Fault Code		Y		
4008		Parking aid				Erase Fault Code		Y		
4008		Parking aid				Live Data		Y		
4008		Instrument panel				Read ECU Information		Y		
4008		Instrument panel				Read Fault Code		Y		
4008		Instrument panel				Erase Fault Code		Y		
4008		Instrument panel				Live Data		Y		
4008		Instrument panel				Actuation Test		Y		
4008		Instrument panel				Special Function	Pack Repair	Y		
4008		heating/ventilation				Read ECU Information		Y		
4008		heating/ventilation				Read Fault Code		Y		
4008		heating/ventilation				Erase Fault Code		Y		
4008		heating/ventilation				Live Data		Y		
4008		heating/ventilation				Actuation Test		Y		
4008		Directional headlamps				Read ECU Information		Y		
4008		Directional headlamps				Read Fault Code		Y		
4008		Directional headlamps				Erase Fault Code		Y		
4008		Directional headlamps				Live Data		Y		
4008		Directional headlamps				Actuation Test		Y		
4008		Directional headlamps				Special Function	Calibration	Y		
4008		Power steering				Read ECU Information		Y		
4008		Power steering				Read Fault Code		Y		
4008		Power steering				Erase Fault Code		Y		
4008		Power steering				Live Data		Y		
4008		Radio or radiotelephone(radio part)				Read ECU Information		Y		
4008		Radio or radiotelephone(radio part)				Read Fault Code		Y		
4008		Radio or radiotelephone(radio part)				Erase Fault Code		Y		

4008		Radio or radiotelephone(radio part)				Live Data		Y		
4008		Radio or radiotelephone(radio part)				Actuation Test		Y		
4008		Navigation				Read ECU Information		Y		
4008		Navigation				Read Fault Code		Y		
4008		Navigation				Erase Fault Code		Y		
4008		Rain and brightness sensor				Read ECU Information		Y		
4008		Rain and brightness sensor				Read Fault Code		Y		
4008		Rain and brightness sensor				Erase Fault Code		Y		
4008		Rain and brightness sensor				Live Data		Y		
4008		Rain and brightness sensor				Special Function	Replacement Parts	Y		
4008(P84C)		Engine management ECU	MED17 4 4			Read ECU Information		Y		
4008(P84C)		Engine management ECU	MED17 4 4			Read Fault Code		Y		
4008(P84C)		Engine management ECU	MED17 4 4			Erase Fault Code		Y		
4008(P84C)		Engine management ECU	MED17 4 4			Live Data		Y		
4008(P84C)		Engine management ECU	MED17 4 4			Actuation Test		Y		
4008(P84C)		Engine management ECU	MED17 4 4			Special Function	Pack Repair	Y		
4008(P84C)		Engine management ECU	MED17 4 4 EP8			Read ECU Information		Y		
4008(P84C)		Engine management ECU	MED17 4 4 EP8			Read Fault Code		Y		
4008(P84C)		Engine management ECU	MED17 4 4 EP8			Erase Fault Code		Y		
4008(P84C)		Engine management ECU	MED17 4 4 EP8			Live Data		Y		
4008(P84C)		Engine management ECU	MED17 4 4 EP8			Actuation Test		Y		
4008(P84C)		Engine management ECU	MED17 4 4 EP8			Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
4008(P84C)		Engine management ECU	MED17 4 4 EP8			Special Function	Work on the ancillaries battery	Y		
4008(P84C)		Engine management ECU	MED17 4 4 EP8			Special Function	Initialisation of the autoadaptive values	Y		
4008(P84C)		Engine management ECU	MED17 4 4 EP8			Special Function	Replacement parts	Y		
4008(P84C)		Engine management ECU	VD46			Read ECU Information		Y		
4008(P84C)		Engine management ECU	VD46			Read Fault Code		Y		
4008(P84C)		Engine management ECU	VD46			Erase Fault Code		Y		
4008(P84C)		Engine management ECU	VD46			Live Data		Y		
4008(P84C)		Engine management ECU	VD46			Actuation Test		Y		
4008(P84C)		Engine management ECU	VD46			Special Function	Pack Repair	Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read ECU Information		Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read Fault Code		Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Erase Fault Code		Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Live Data		Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Actuation Test		Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Special Function	Pack Repair	Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read ECU Information		Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read Fault Code		Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Erase Fault Code		Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Live Data		Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Actuation Test		Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Special Function	Pack Repair	Y		

4008(P84C)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
4008(P84C)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
4008(P84C)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
4008(P84C)		Air bags and pre-tensioners control unit				Live Data		Y		
4008(P84C)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
4008(P84C)		Dynamic headlamp height adjuster				Read ECU Information		Y		
4008(P84C)		Dynamic headlamp height adjuster				Read Fault Code		Y		
4008(P84C)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
4008(P84C)		Dynamic headlamp height adjuster				Live Data		Y		
4008(P84C)		Dynamic headlamp height adjuster				Actuation Test		Y		
4008(P84C)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
4008(P84C)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
4008(P84C)		Battery charge status unit				Read ECU Information		Y		
4008(P84C)		Battery charge status unit				Read Fault Code		Y		
4008(P84C)		Battery charge status unit				Erase Fault Code		Y		
4008(P84C)		Battery charge status unit				Live Data		Y		
4008(P84C)		Battery charge status unit				Special Function	Configuration	Y		
4008(P84C)		Battery charge status unit				Special Function	Pack Repair	Y		
4008(P84C)		Parking assistance	4 parking assistance			Read ECU Information		Y		
4008(P84C)		Parking assistance	4 parking assistance			Read Fault Code		Y		
4008(P84C)		Parking assistance	4 parking assistance			Erase Fault Code		Y		
4008(P84C)		Parking assistance	4 parking assistance			Live Data		Y		
4008(P84C)		Parking assistance	4 parking assistance			Actuation Test		Y		
4008(P84C)		Parking assistance	8 parking assistance			Read ECU Information		Y		
4008(P84C)		Parking assistance	8 parking assistance			Read Fault Code		Y		
4008(P84C)		Parking assistance	8 parking assistance			Erase Fault Code		Y		
4008(P84C)		Parking assistance	8 parking assistance			Live Data		Y		
4008(P84C)		Parking assistance	8 parking assistance			Actuation Test		Y		
4008(P84C)		Parking assistance	10 parking assistance			Read ECU Information		Y		
4008(P84C)		Parking assistance	10 parking assistance			Read Fault Code		Y		
4008(P84C)		Parking assistance	10 parking assistance			Erase Fault Code		Y		
4008(P84C)		Parking assistance	10 parking assistance			Live Data		Y		
4008(P84C)		Parking assistance	10 parking assistance			Actuation Test		Y		
4008(P84C)		Air conditioning				Read ECU Information		Y		
4008(P84C)		Air conditioning				Read Fault Code		Y		
4008(P84C)		Air conditioning				Erase Fault Code		Y		
4008(P84C)		Air conditioning				Live Data		Y		
4008(P84C)		Air conditioning				Actuation Test		Y		
4008(P84C)		Air conditioning				Special Function	Pack Repair	Y		
4008(P84C)		Panoramic vision assistance				Read ECU Information		Y		
4008(P84C)		Panoramic vision assistance				Read Fault Code		Y		
4008(P84C)		Panoramic vision assistance				Erase Fault Code		Y		
4008(P84C)		Panoramic vision assistance				Live Data		Y		
4008(P84C)		Panoramic vision assistance				Actuation Test		Y		
4008(P84C)		Panoramic vision assistance				Special Function	Pack Repair	Y		
4008(P84C)		Hands full access ECU, right-hand side or rear				Read ECU Information		Y		
4008(P84C)		Hands full access ECU, right-hand side or rear				Read Fault Code		Y		
4008(P84C)		Controls under the steering wheel				Read ECU Information		Y		
4008(P84C)		Controls under the steering wheel				Read Fault Code		Y		

4008(P84C)		Controls under the steering wheel				Erase Fault Code		Y		
4008(P84C)		Controls under the steering wheel				Live Data		Y		
4008(P84C)		Controls under the steering wheel				Actuation Test		Y		
4008(P84C)		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
4008(P84C)		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
4008(P84C)		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
4008(P84C)		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
4008(P84C)		Voltage retaining device	DMTC			Read ECU Information		Y		
4008(P84C)		Voltage retaining device	DMTR DTC3B			Read ECU Information		Y		
4008(P84C)		Voltage retaining device	DMTR DTC3B			Read Fault Code		Y		
4008(P84C)		Voltage retaining device	DMTR DTC3B			Erase Fault Code		Y		
4008(P84C)		Front left seat heated pads and ventilation regulation				Read ECU Information		Y		
4008(P84C)		Front left seat heated pads and ventilation regulation				Read Fault Code		Y		
4008(P84C)		Front left seat heated pads and ventilation regulation				Live Data		Y		
4008(P84C)		Front left seat heated pads and ventilation regulation				Actuation Test		Y		
4008(P84C)		Front right seat heated pads and ventilation regulation				Read ECU Information		Y		
4008(P84C)		Front right seat heated pads and ventilation regulation				Read Fault Code		Y		
4008(P84C)		Front right seat heated pads and ventilation regulation				Live Data		Y		
4008(P84C)		Front right seat heated pads and ventilation regulation				Actuation Test		Y		
4008(P84C)		Automatic gearbox electric control				Read ECU Information		Y		
4008(P84C)		Automatic gearbox electric control				Read Fault Code		Y		
4008(P84C)		Automatic gearbox electric control				Erase Fault Code		Y		
4008(P84C)		Automatic gearbox electric control				Live Data		Y		
4008(P84C)		Automatic gearbox electric control				Actuation Test		Y		
4008(P84C)		Automatic gearbox electric control				Special Function	Programming	Y		
4008(P84C)		Automatic gearbox electric control				Special Function	Replacement parts	Y		
4008(P84C)		Motorised Boot ECU				Read ECU Information		Y		
4008(P84C)		Motorised Boot ECU				Read Fault Code		Y		
4008(P84C)		Motorised Boot ECU				Erase Fault Code		Y		
4008(P84C)		Motorised Boot ECU				Live Data		Y		
4008(P84C)		Motorised Boot ECU				Actuation Test		Y		
4008(P84C)		Driver's door module	PDPC			Read ECU Information		Y		
4008(P84C)		Driver's door module	PDPC			Read Fault Code		Y		
4008(P84C)		Driver's door module	PDPC			Erase Fault Code		Y		
4008(P84C)		Driver's door module	PDPC			Live Data		Y		
4008(P84C)		Driver's door module	PDPC			Actuation Test		Y		
4008(P84C)		Driver's door module	PDPC UDS			Read ECU Information		Y		
4008(P84C)		Driver's door module	PDPC UDS			Read Fault Code		Y		
4008(P84C)		Driver's door module	PDPC UDS			Erase Fault Code		Y		
4008(P84C)		Driver's door module	PDPC UDS			Live Data		Y		

4008(P84C)		Driver's door module	PDPC_UDS			Actuation Test		Y		
4008(P84C)		Vehicle Distance Assistance				Read ECU Information		Y		
4008(P84C)		Vehicle Distance Assistance				Read Fault Code		Y		
4008(P84C)		Vehicle Distance Assistance				Erase Fault Code		Y		
4008(P84C)		Vehicle Distance Assistance				Live Data		Y		
4008(P84C)		Vehicle Distance Assistance				Actuation Test		Y		
4008(P84C)		Multiplexed control panel	Audio/Navigation NAC			Read ECU Information		Y		
4008(P84C)		Multiplexed control panel	Audio/Navigation NAC			Read Fault Code		Y		
4008(P84C)		Multiplexed control panel	Audio/Navigation NAC			Erase Fault Code		Y		
4008(P84C)		Multiplexed control panel	Audio/Navigation NAC			Live Data		Y		
4008(P84C)		Multiplexed control panel	Audio/Navigation NAC			Actuation Test		Y		
4008(P84C)		Rear air conditioning ECU				Read ECU Information		Y		
4008(P84C)		Rear air conditioning ECU				Read Fault Code		Y		
4008(P84C)		Rear air conditioning ECU				Erase Fault Code		Y		
4008(P84C)		Rear air conditioning ECU				Live Data		Y		
4008(P84C)		Rear air conditioning ECU				Actuation Test		Y		
4008(P84C)		Rear air conditioning ECU				Special Function	Pack Repair	Y		
4008(P84C)		Electric steering lock				Read ECU Information		Y		
4008(P84C)		Electric steering lock				Read Fault Code		Y		
4008(P84C)		Electric steering lock				Erase Fault Code		Y		
4008(P84C)		Electric steering lock				Live Data		Y		
4008(P84C)		Rain and brightness sensor				Read ECU Information		Y		
4008(P84C)		Rain and brightness sensor				Read Fault Code		Y		
4008(P84C)		Rain and brightness sensor				Erase Fault Code		Y		
4008(P84C)		Rain and brightness sensor				Live Data		Y		
4008(P84C)		Rain and brightness sensor				Special Function	Pack Repair	Y		
4008(P84C)		Radio amplifier				Read ECU Information		Y		
4008(P84C)		Radio amplifier				Read Fault Code		Y		
4008(P84C)		Radio amplifier				Erase Fault Code		Y		
4008(P84C)		Radio amplifier				Actuation Test		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Read ECU Information		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Read Fault Code		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Erase Fault Code		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Live Data		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Actuation Test		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Special Function	Pack Repair	Y		
4008(P84C)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read ECU Information		Y		
4008(P84C)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read Fault Code		Y		
4008(P84C)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Live Data		Y		
4008(P84C)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Actuation Test		Y		
4008(P84C)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read ECU Information		Y		
4008(P84C)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read Fault Code		Y		
4008(P84C)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Live Data		Y		
4008(P84C)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Actuation Test		Y		
4008(P84C)		Traction control mode				Read ECU Information		Y		
4008(P84C)		Traction control mode				Read Fault Code		Y		
4008(P84C)		Traction control mode				Live Data		Y		
4008(P84C)		Traction control mode				Actuation Test		Y		
4008(P84C)		Power steering				Read ECU Information		Y		
4008(P84C)		Power steering				Read Fault Code		Y		
4008(P84C)		Power steering				Erase Fault Code		Y		
4008(P84C)		Power steering				Live Data		Y		

4008(P84C)		Multifunction video				Read ECU Information		Y		
4008(P84C)		Multifunction video				Read Fault Code		Y		
4008(P84C)		Multifunction video				Erase Fault Code		Y		
4008(P84C)		Multifunction video				Live Data		Y		
4008(P84C)		Multifunction video				Actuation Test		Y		
4008(P84C)		Audio-navigation/telematic unit/connected audio system	NAC			Read ECU Information		Y		
4008(P84C)		Audio-navigation/telematic unit/connected audio system	NAC			Read Fault Code		Y		
4008(P84C)		Audio-navigation/telematic unit/connected audio system	NAC			Erase Fault Code		Y		
4008(P84C)		Audio-navigation/telematic unit/connected audio system	NAC			Live Data		Y		
4008(P84C)		Audio-navigation/telematic unit/connected audio system	NAC			Actuation Test		Y		
4008(P84C)		Touch screen				Read ECU Information		Y		
4008(P84C)		Touch screen				Read Fault Code		Y		
4008(P84C)		Touch screen				Erase Fault Code		Y		
4008(P84C)		Touch screen				Live Data		Y		
4008(P84C)		Touch screen				Actuation Test		Y		
4008(P84C)		Driver's seat comfort ECU				Read ECU Information		Y		
4008(P84C)		Driver's seat comfort ECU				Read Fault Code		Y		
4008(P84C)		Driver's seat comfort ECU				Erase Fault Code		Y		
4008(P84C)		Driver's seat comfort ECU				Live Data		Y		
4008(P84C)		Driver's seat comfort ECU				Actuation Test		Y		
4008(P84C)		Push gear lever				Read ECU Information		Y		
4008(P84C)		Push gear lever				Read Fault Code		Y		
4008(P84C)		Push gear lever				Erase Fault Code		Y		
4008(P84C)		Push gear lever				Live Data		Y		
4008(P84C)		Push gear lever				Actuation Test		Y		
4008(P84C)		Windscreen wiper				Read ECU Information		Y		
4008(P84C)		Windscreen wiper				Read Fault Code		Y		
4008(P84C)		Windscreen wiper				Erase Fault Code		Y		
4008(P84C)		Windscreen wiper				Live Data		Y		
4008(P84C)		Windscreen wiper				Actuation Test		Y		
5008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
5008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
5008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
5008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
5008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
5008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Special Function	Configuration	Y		
5008		Engine management ECU	MEV17 4 2	MEV17 4 2EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Read ECU Information		Y		
5008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Read Fault Code		Y		
5008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Erase Fault Code		Y		
5008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Live Data		Y		
5008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Actuation Test		Y		
5008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Special Function	Configuration	Y		
5008		Engine management ECU	MED17 4 2	5FV MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Read ECU Information		Y		
5008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Read Fault Code		Y		
5008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Erase Fault Code		Y		
5008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Live Data		Y		
5008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Actuation Test		Y		
5008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Special Function	Configuration	Y		
5008		Engine management ECU	MED17 4 2	5FN MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Read ECU Information		Y		
5008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Read Fault Code		Y		
5008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Erase Fault Code		Y		

5008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Live Data		Y		
5008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Actuation Test		Y		
5008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Special Function	Configuration	Y		
5008		Engine management ECU	MED17 4 2	5FM MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Read ECU Information		Y		
5008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Read Fault Code		Y		
5008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Erase Fault Code		Y		
5008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Live Data		Y		
5008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Actuation Test		Y		
5008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Special Function	Configuration	Y		
5008		Engine management ECU	MED17 4 2	5FE MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17 4 4			Read ECU Information		Y		
5008		Engine management ECU	MED17 4 4			Read Fault Code		Y		
5008		Engine management ECU	MED17 4 4			Erase Fault Code		Y		
5008		Engine management ECU	MED17 4 4			Live Data		Y		
5008		Engine management ECU	MED17 4 4			Actuation Test		Y		
5008		Engine management ECU	MED17 4 4			Special Function	Pack Repair	Y		
5008		Engine management ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Read ECU Information		Y		
5008		Engine management ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Read Fault Code		Y		
5008		Engine management ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Erase Fault Code		Y		
5008		Engine management ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Live Data		Y		
5008		Engine management ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Actuation Test		Y		
5008		Engine management ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Special Function	Configuration	Y		
5008		Engine management ECU	MEV17 4 EURO4	MEV17 4 EURO4 5FW		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Read ECU Information		Y		
5008		Engine management ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Read Fault Code		Y		
5008		Engine management ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Erase Fault Code		Y		
5008		Engine management ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Live Data		Y		
5008		Engine management ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Actuation Test		Y		
5008		Engine management ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Special Function	Configuration	Y		
5008		Engine management ECU	MED17 4 EURO4	MED17 4 EURO4 5FX		Special Function	Pack Repair	Y		
5008		Engine management ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Read ECU Information		Y		
5008		Engine management ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Read Fault Code		Y		
5008		Engine management ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Erase Fault Code		Y		
5008		Engine management ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Live Data		Y		
5008		Engine management ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Actuation Test		Y		
5008		Engine management ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Special Function	Configuration	Y		
5008		Engine management ECU	MEV17 4 EURO5	MEV17 4 EURO5 5FS		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17 4 EURO5	MED17 4 EURO5 5FV		Read ECU Information		Y		
5008		Engine management ECU	MED17 4 EURO5	MED17 4 EURO5 5FV		Read Fault Code		Y		
5008		Engine management ECU	MED17 4 EURO5	MED17 4 EURO5 5FV		Erase Fault Code		Y		
5008		Engine management ECU	MED17 4 EURO5	MED17 4 EURO5 5FV		Live Data		Y		
5008		Engine management ECU	MED17 4 EURO5	MED17 4 EURO5 5FV		Actuation Test		Y		
5008		Engine management ECU	MED17 4 EURO5	MED17 4 EURO5 5FV		Special Function	Configuration	Y		
5008		Engine management ECU	MED17 4 EURO5	MED17 4 EURO5 5FV		Special Function	Pack Repair	Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Read ECU Information		Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Read Fault Code		Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Erase Fault Code		Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Live Data		Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Actuation Test		Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Special Function	Pack Repair	Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Read ECU Information		Y		

5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Read Fault Code		Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Erase Fault Code		Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Live Data		Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Actuation Test		Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Special Function	Pack Repair	Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read ECU Information		Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read Fault Code		Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Erase Fault Code		Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Live Data		Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Actuation Test		Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Configuration	Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Pack Repair	Y		
5008		Engine management ECU	EDC17C60			Read ECU Information		Y		
5008		Engine management ECU	EDC17C60			Read Fault Code		Y		
5008		Engine management ECU	EDC17C60			Erase Fault Code		Y		
5008		Engine management ECU	EDC17C60			Live Data		Y		
5008		Engine management ECU	EDC17C60			Actuation Test		Y		
5008		Engine management ECU	EDC17C60			Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Read ECU Information		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Read Fault Code		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Erase Fault Code		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Live Data		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Actuation Test		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Read ECU Information		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Read Fault Code		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Erase Fault Code		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Live Data		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Actuation Test		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Read ECU Information		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Read Fault Code		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Erase Fault Code		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Live Data		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Actuation Test		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Special Function	Configuration	Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Read ECU Information		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Read Fault Code		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Erase Fault Code		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Live Data		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Actuation Test		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Special Function	Configuration	Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Read ECU Information		Y		
5008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Read Fault Code		Y		
5008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Erase Fault Code		Y		
5008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Live Data		Y		
5008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Actuation Test		Y		
5008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Special Function	Configuration	Y		
5008		Engine management ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Read ECU Information		Y		
5008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Read Fault Code		Y		
5008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Erase Fault Code		Y		
5008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Live Data		Y		
5008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Actuation Test		Y		

5008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Special Function	Configuration	Y		
5008		Engine management ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Special Function	Pack Repair	Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HR		Read ECU Information		Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HR		Read Fault Code		Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HR		Erase Fault Code		Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HR		Live Data		Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HR		Actuation Test		Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HR		Special Function	Configuration	Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HR		Special Function	Pack Repair	Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HL		Read ECU Information		Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HL		Read Fault Code		Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HL		Erase Fault Code		Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HL		Live Data		Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HL		Actuation Test		Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HL		Special Function	Configuration	Y		
5008		Engine management ECU	HDI SID807	HDI SID807 9HL		Special Function	Pack Repair	Y		
5008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Read ECU Information		Y		
5008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Read Fault Code		Y		
5008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Erase Fault Code		Y		
5008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Live Data		Y		
5008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Actuation Test		Y		
5008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Special Function	Configuration	Y		
5008		Engine management ECU	HDI SID807 BR2	HDI SID807 BR2 9HR		Special Function	Pack Repair	Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
5008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read ECU Information		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Erase Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Live Data		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Actuation Test		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Special Function	Configuration	Y		
5008		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Special Function	Pack Repair	Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		

5008		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
5008		Air bags and pre-tensioners control unit				Read ECU Information		Y		
5008		Air bags and pre-tensioners control unit				Read Fault Code		Y		
5008		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
5008		Air bags and pre-tensioners control unit				Live Data		Y		
5008		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
5008		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
5008		Power steering				Read ECU Information		Y		
5008		Power steering				Read Fault Code		Y		
5008		Power steering				Erase Fault Code		Y		
5008		Power steering				Live Data		Y		
5008		Power steering				Actuation Test		Y		
5008		Diesel additive function	PADDGO			Read ECU Information		Y		
5008		Diesel additive function	PADDGO			Read Fault Code		Y		
5008		Diesel additive function	PADDGO			Erase Fault Code		Y		
5008		Diesel additive function	PADDGO			Live Data		Y		
5008		Diesel additive function	PADDGO			Actuation Test		Y		
5008		Diesel additive function	PADDGO			Special Function	Configuration	Y		
5008		Diesel additive function	POMPE_MUX_TI			Read ECU Information		Y		
5008		Diesel additive function	POMPE_MUX_TI			Read Fault Code		Y		
5008		Diesel additive function	POMPE_MUX_TI			Erase Fault Code		Y		
5008		Diesel additive function	POMPE_MUX_TI			Live Data		Y		
5008		Diesel additive function	POMPE_MUX_TI			Actuation Test		Y		
5008		Diesel additive function	POMPE_MUX_TI			Special Function	Configuration	Y		
5008		Diesel additive function	PADDGO_TI_E6			Read ECU Information		Y		
5008		Diesel additive function	PADDGO_TI_E6			Read Fault Code		Y		
5008		Diesel additive function	PADDGO_TI_E6			Erase Fault Code		Y		
5008		Diesel additive function	PADDGO_TI_E6			Live Data		Y		
5008		Diesel additive function	PADDGO_TI_E6			Special Function	Configuration	Y		
5008		Under inflation detection	DSG_UDS			Read ECU Information		Y		
5008		Under inflation detection	DSG_UDS			Read Fault Code		Y		
5008		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
5008		Under inflation detection	DSG_UDS			Live Data		Y		
5008		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
5008		Under inflation detection	DSG			Read ECU Information		Y		
5008		Under inflation detection	DSG			Read Fault Code		Y		
5008		Under inflation detection	DSG			Erase Fault Code		Y		
5008		Under inflation detection	DSG			Live Data		Y		
5008		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
5008		Dynamic headlamp height adjuster				Read ECU Information		Y		
5008		Dynamic headlamp height adjuster				Read Fault Code		Y		
5008		Dynamic headlamp height adjuster				Erase Fault Code		Y		

5008		Dynamic headlamp height adjuster				Live Data		Y		
5008		Dynamic headlamp height adjuster				Actuation Test		Y		
5008		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
5008		Dynamic headlamp height adjuster				Special Function	Pack repair	Y		
5008		Battery charge status unit	BECB			Read ECU Information		Y		
5008		Battery charge status unit	BECB			Live Data		Y		
5008		Battery charge status unit	BECB GEN2			Read ECU Information		Y		
5008		Battery charge status unit	BECB GEN2			Live Data		Y		
5008		Battery charge status unit	BECB GEN2			Special Function	Configuration	Y		
5008		Battery charge status unit	BECB GEN2			Special Function	Pack Repair	Y		
5008		Vehicle Distance Assistance				Read ECU Information		Y		
5008		Vehicle Distance Assistance				Read Fault Code		Y		
5008		Vehicle Distance Assistance				Erase Fault Code		Y		
5008		Vehicle Distance Assistance				Live Data		Y		
5008		Vehicle Distance Assistance				Special Function	Configuration	Y		
5008		Vehicle Distance Assistance				Special Function	Pack repair	Y		
5008		Electric secondary brake				Read ECU Information		Y		
5008		Electric secondary brake				Read Fault Code		Y		
5008		Electric secondary brake				Erase Fault Code		Y		
5008		Electric secondary brake				Live Data		Y		
5008		Electric secondary brake				Actuation Test		Y		
5008		Electric secondary brake				Special Function	Pack Repair	Y		
5008		Trailer relay unit				Read ECU Information		Y		
5008		Trailer relay unit				Read Fault Code		Y		
5008		Trailer relay unit				Erase Fault Code		Y		
5008		Engine relay unit				Read ECU Information		Y		
5008		Engine relay unit				Read Fault Code		Y		
5008		Engine relay unit				Erase Fault Code		Y		
5008		Engine relay unit				Actuation Test		Y		
5008		Air conditioning				Read ECU Information		Y		
5008		Air conditioning				Read Fault Code		Y		
5008		Air conditioning				Erase Fault Code		Y		
5008		Air conditioning				Live Data		Y		
5008		Air conditioning				Actuation Test		Y		
5008		Air conditioning				Special Function	Configuration	Y		
5008		Air conditioning				Special Function	Pack Repair	Y		
5008		Controls under the steering wheel				Read ECU Information		Y		
5008		Controls under the steering wheel				Read Fault Code		Y		
5008		Controls under the steering wheel				Erase Fault Code		Y		
5008		Controls under the steering wheel				Live Data		Y		
5008		Controls under the steering wheel				Actuation Test		Y		
5008		Controls under the steering wheel				Special Function	Pack repair	Y		
5008		Multifunction screen	Type "A" (segments),with buttons			Read ECU Information		Y		
5008		Multifunction screen	Type "A" (segments),with buttons			Read Fault Code		Y		
5008		Multifunction screen	Type "A" (segments),with buttons			Erase Fault Code		Y		
5008		Multifunction screen	Type "A" (segments),with buttons			Live Data		Y		
5008		Multifunction screen	Type "A" (segments),with buttons			Actuation Test		Y		
5008		Multifunction screen	Type "A" (segments),with buttons			Special Function	Configuration	Y		
5008		Multifunction screen	Type "A" (segments),with buttons			Special Function	Pack repair	Y		

5008		Multifunction screen	Type "A" (segments),without			Read ECU Information		Y		
5008		Multifunction screen	Type "A" (segments),without			Read Fault Code		Y		
5008		Multifunction screen	Type "A" (segments),without			Erase Fault Code		Y		
5008		Multifunction screen	Type "A" (segments),without			Live Data		Y		
5008		Multifunction screen	Type "A" (segments),without			Actuation Test		Y		
5008		Multifunction screen	Type "A" (segments),without			Special Function	Configuration	Y		
5008		Multifunction screen	Type "A" (segments),without			Special Function	Pack repair	Y		
5008		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
5008		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
5008		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
5008		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
5008		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
5008		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
5008		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack repair	Y		
5008		Multifunction screen	Type "C colour" (dot			Read ECU Information		Y		
5008		Multifunction screen	Type "C colour" (dot			Read Fault Code		Y		
5008		Multifunction screen	Type "C colour" (dot			Erase Fault Code		Y		
5008		Multifunction screen	Type "C colour" (dot			Live Data		Y		
5008		Multifunction screen	Type "C colour" (dot			Actuation Test		Y		
5008		Multifunction screen	Type "C colour" (dot			Special Function	Configuration	Y		
5008		Multifunction screen	Type "C colour" (dot			Special Function	Pack repair	Y		
5008		Instrument panel				Read ECU Information		Y		
5008		Instrument panel				Read Fault Code		Y		
5008		Instrument panel				Erase Fault Code		Y		
5008		Instrument panel				Live Data		Y		
5008		Instrument panel				Actuation Test		Y		
5008		Windscreen wiper				Read ECU Information		Y		
5008		Windscreen wiper				Actuation Test		Y		
5008		Windscreen wiper				Special Function	Configuration	Y		
5008		Windscreen wiper				Special Function	Pack Repair	Y		
5008		Parking assistance				Read ECU Information		Y		
5008		Parking assistance				Read Fault Code		Y		
5008		Parking assistance				Erase Fault Code		Y		
5008		Parking assistance				Live Data		Y		
5008		Parking assistance				Special Function	Configuration	Y		
5008		Parking assistance				Special Function	Pack Repair	Y		
5008		Radio	RD4			Read ECU Information		Y		
5008		Radio	RD4			Read Fault Code		Y		
5008		Radio	RD4			Erase Fault Code		Y		
5008		Radio	RD4			Live Data		Y		
5008		Radio	RD4			Actuation Test		Y		
5008		Radio	RD4			Special Function	Configuration	Y		
5008		Radio	RD4			Special Function	Replacement parts	Y		
5008		Radio	RD45			Read ECU Information		Y		
5008		Radio	RD45			Read Fault Code		Y		
5008		Radio	RD45			Erase Fault Code		Y		
5008		Radio	RD45			Live Data		Y		
5008		Radio	RD45			Actuation Test		Y		
5008		Radio	RD45			Special Function	Configuration	Y		
5008		Radio	RD45			Special Function	Pack Repair	Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEG			Read ECU Information		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEG			Read Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEG			Erase Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEG			Live Data		Y		

5008		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEG			Actuation Test		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV RNEG			Special Function	Configuration	Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Read ECU Information		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Read Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Erase Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Live Data		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Actuation Test		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV NG4			Special Function	Configuration	Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read ECU Information		Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Erase Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Live Data		Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Actuation Test		Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Configuration	Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Pack repair	Y		
5008		Audio amplifier				Read ECU Information		Y		
5008		Audio amplifier				Read Fault Code		Y		
5008		Audio amplifier				Erase Fault Code		Y		
5008		Audio amplifier				Actuation Test		Y		
5008		Audio amplifier				Special Function	Configuration	Y		
5008		Audio amplifier				Special Function	Pack Repair	Y		
5008		CD player / External CD				Read ECU Information		Y		
5008		CD player / External CD				Read Fault Code		Y		
5008		CD player / External CD				Erase Fault Code		Y		
5008		CD player / External CD				Actuation Test		Y		
5008		CD player / External CD				Special Function	Configuration	Y		
5008		Hands-free kit / Portable				Read ECU Information		Y		
5008		Hands-free kit / Portable				Read Fault Code		Y		
5008		Hands-free kit / Portable				Erase Fault Code		Y		
5008		Hands-free kit / Portable				Live Data		Y		
5008		Hands-free kit / Portable				Actuation Test		Y		
5008		Hands-free kit / Portable				Special Function	Configuration	Y		
5008		Hands-free kit / Portable				Special Function	Pack repair	Y		
5008		Anti-theft alarm				Read ECU Information		Y		
5008		Anti-theft alarm				Read Fault Code		Y		
5008		Anti-theft alarm				Erase Fault Code		Y		
5008		Anti-theft alarm				Live Data		Y		
5008		Anti-theft alarm				Actuation Test		Y		
5008		Anti-theft alarm				Special Function	Configuration	Y		
5008		Anti-theft alarm				Special Function	Pack repair	Y		
5008		Driver's door module	Driver's door module			Read ECU Information		Y		
5008		Driver's door module	Driver's door module			Read Fault Code		Y		
5008		Driver's door module	Driver's door module			Erase Fault Code		Y		
5008		Driver's door module	Driver's door module			Live Data		Y		
5008		Driver's door module	Driver's door module			Actuation Test		Y		
5008		Control panel dot matrix display				Read ECU Information		Y		
5008		Control panel dot matrix display				Read Fault Code		Y		
5008		Control panel dot matrix display				Erase Fault Code		Y		

5008		Control panel dot matrix display				Live Data		Y		
5008		Control panel dot matrix display				Actuation Test		Y		
5008		Control panel dot matrix display				Special Function	Configuration	Y		
5008		service module /Independent telematic unit	MD_SERV			Read ECU Information		Y		
5008		service module /Independent telematic unit	MD_SERV			Read Fault Code		Y		
5008		service module /Independent telematic unit	MD_SERV			Erase Fault Code		Y		
5008		service module /Independent telematic unit	MD_SERV			Live Data		Y		
5008		service module /Independent telematic unit	MD_SERV			Actuation Test		Y		
5008		service module /Independent telematic unit	MD_SERV			Special Function	Configuration	Y		
5008		service module /Independent telematic unit	MD_SERV			Special Function	Pack Repair	Y		
5008		service module /Independent telematic unit	BTA			Read ECU Information		Y		
5008		service module /Independent telematic unit	BTA			Read Fault Code		Y		
5008		service module /Independent telematic unit	BTA			Erase Fault Code		Y		
5008		service module /Independent telematic unit	BTA			Live Data		Y		
5008		service module /Independent telematic unit	BTA			Actuation Test		Y		
5008		service module /Independent telematic unit	BTA			Special Function	Configuration	Y		
5008		service module /Independent telematic unit	BTA			Special Function	Pack Repair	Y		
5008		Network isolation control				Read ECU Information		Y		
5008		Network isolation control				Live Data		Y		
5008		Rain and brightness sensor				Read ECU Information		Y		
5008		Rain and brightness sensor				Read Fault Code		Y		
5008		Rain and brightness sensor				Erase Fault Code		Y		
5008		Voltage retaining device	DMTC			Read ECU Information		Y		
5008		Voltage retaining device	DMTR			Read ECU Information		Y		
5008		Voltage retaining device	DMTR			Read Fault Code		Y		
5008		Voltage retaining device	DMTR			Erase Fault Code		Y		
5008		High Head Vision	VTH			Read ECU Information		Y		
5008		High Head Vision	VTH			Read Fault Code		Y		
5008		High Head Vision	VTH			Erase Fault Code		Y		
5008		High Head Vision	VTH			Live Data		Y		
5008		High Head Vision	VTH			Actuation Test		Y		
5008		High Head Vision	VTH			Special Function	Configuration	Y		
5008		High Head Vision	VTH_UDS			Read ECU Information		Y		
5008		High Head Vision	VTH_UDS			Read Fault Code		Y		
5008		High Head Vision	VTH_UDS			Erase Fault Code		Y		
5008		High Head Vision	VTH_UDS			Live Data		Y		
5008		High Head Vision	VTH_UDS			Actuation Test		Y		
5008		High Head Vision	VTH_UDS			Special Function	Configuration	Y		
5008		High Head Vision	VTH_UDS			Special Function	Pack repair	Y		
5008		High frequency receiver				Read ECU Information		Y		
5008		High frequency receiver				Read Fault Code		Y		
5008		High frequency receiver				Erase Fault Code		Y		
5008		High frequency receiver				Live Data		Y		
5008		Seat belts not fastened LED unit				Read ECU Information		Y		
5008		Seat belts not fastened LED unit				Actuation Test		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Read ECU Information		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Read Fault Code		Y		

5008(P87)		Engine management ECU	Petrol Engine	VD46		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Live Data		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Actuation Test		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Special Function	Pack Repair	Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17 4 4		Read ECU Information		Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17 4 4		Read Fault Code		Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17 4 4		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17 4 4		Live Data		Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17 4 4		Actuation Test		Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17 4 4		Special Function	Pack Repair	Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Read ECU Information		Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Read Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Live Data		Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Actuation Test		Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Special Function	Pack Repair	Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Read ECU Information		Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Read Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Live Data		Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Actuation Test		Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Special Function	Pack Repair	Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Special Function	Configuration	Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM DCM71		Read ECU Information		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM DCM71		Read Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM DCM71		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM DCM71		Live Data		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM DCM71		Actuation Test		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read ECU Information		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read Fault Code		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Erase Fault Code		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Live Data		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Actuation Test		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Special Function	Pack Repair	Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read ECU Information		Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Read Fault Code		Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Erase Fault Code		Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Live Data		Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Actuation Test		Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 UDS			Special Function	Pack Repair	Y		
5008(P87)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
5008(P87)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
5008(P87)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
5008(P87)		Air bags and pre-tensioners control unit				Live Data		Y		

5008(P87)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
5008(P87)		Engine relay unit				Read ECU Information		Y		
5008(P87)		Engine relay unit				Read Fault Code		Y		
5008(P87)		Engine relay unit				Erase Fault Code		Y		
5008(P87)		Intrusion alarm siren				Read ECU Information		Y		
5008(P87)		Intrusion alarm siren				Read Fault Code		Y		
5008(P87)		Intrusion alarm siren				Erase Fault Code		Y		
5008(P87)		Intrusion alarm siren				Live Data		Y		
5008(P87)		Intrusion alarm siren				Actuation Test		Y		
5008(P87)		Intrusion alarm siren				Special Function	Configuration	Y		
5008(P87)		Intrusion alarm siren				Special Function	Pack Repair	Y		
5008(P87)		Driver's door module	Yes			Read ECU Information		Y		
5008(P87)		Driver's door module	Yes			Read Fault Code		Y		
5008(P87)		Driver's door module	Yes			Erase Fault Code		Y		
5008(P87)		Driver's door module	Yes			Live Data		Y		
5008(P87)		Driver's door module	Yes			Actuation Test		Y		
5008(P87)		Driver's door module	No			Read ECU Information		Y		
5008(P87)		Driver's door module	No			Read Fault Code		Y		
5008(P87)		Driver's door module	No			Erase Fault Code		Y		
5008(P87)		Driver's door module	No			Live Data		Y		
5008(P87)		Driver's door module	No			Actuation Test		Y		
5008(P87)		Dynamic headlamp height adjuster				Read ECU Information		Y		
5008(P87)		Dynamic headlamp height adjuster				Read Fault Code		Y		
5008(P87)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
5008(P87)		Dynamic headlamp height adjuster				Live Data		Y		
5008(P87)		Dynamic headlamp height adjuster				Actuation Test		Y		
5008(P87)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
5008(P87)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
5008(P87)		Seat belt not fastened warning lights unit				Read ECU Information		Y		
5008(P87)		Seat belt not fastened warning lights unit				Actuation Test		Y		
5008(P87)		Battery charge status unit				Read ECU Information		Y		
5008(P87)		Battery charge status unit				Read Fault Code		Y		
5008(P87)		Battery charge status unit				Erase Fault Code		Y		
5008(P87)		Battery charge status unit				Live Data		Y		
5008(P87)		Battery charge status unit				Special Function	Configuration	Y		
5008(P87)		Battery charge status unit				Special Function	Pack Repair	Y		
5008(P87)		Parking assistance	4 parking assistance			Read ECU Information		Y		
5008(P87)		Parking assistance	4 parking assistance			Read Fault Code		Y		
5008(P87)		Parking assistance	4 parking assistance			Erase Fault Code		Y		
5008(P87)		Parking assistance	4 parking assistance			Live Data		Y		
5008(P87)		Parking assistance	4 parking assistance			Actuation Test		Y		
5008(P87)		Parking assistance	8 parking assistance			Read ECU Information		Y		
5008(P87)		Parking assistance	8 parking assistance			Read Fault Code		Y		
5008(P87)		Parking assistance	8 parking assistance			Erase Fault Code		Y		
5008(P87)		Parking assistance	8 parking assistance			Live Data		Y		
5008(P87)		Parking assistance	8 parking assistance			Actuation Test		Y		
5008(P87)		Parking assistance	10 parking assistance			Read ECU Information		Y		
5008(P87)		Parking assistance	10 parking assistance			Read Fault Code		Y		
5008(P87)		Parking assistance	10 parking assistance			Erase Fault Code		Y		
5008(P87)		Parking assistance	10 parking assistance			Live Data		Y		
5008(P87)		Parking assistance	10 parking assistance			Actuation Test		Y		
5008(P87)		Multifunction screen	EMF C UDS			Read ECU Information		Y		
5008(P87)		Multifunction screen	EMF C UDS			Read Fault Code		Y		
5008(P87)		Multifunction screen	EMF C UDS			Erase Fault Code		Y		
5008(P87)		Multifunction screen	EMF C UDS			Actuation Test		Y		
5008(P87)		Air conditioning				Read ECU Information		Y		

5008(P87)		Air conditioning				Read Fault Code		Y		
5008(P87)		Air conditioning				Erase Fault Code		Y		
5008(P87)		Air conditioning				Live Data		Y		
5008(P87)		Air conditioning				Actuation Test		Y		
5008(P87)		Air conditioning				Special Function	Pack Repair	Y		
5008(P87)		Panoramic vision assistance				Read ECU Information		Y		
5008(P87)		Panoramic vision assistance				Read Fault Code		Y		
5008(P87)		Panoramic vision assistance				Erase Fault Code		Y		
5008(P87)		Panoramic vision assistance				Live Data		Y		
5008(P87)		Panoramic vision assistance				Actuation Test		Y		
5008(P87)		Panoramic vision assistance				Special Function	Pack Repair	Y		
5008(P87)		Hands full access ECU, right-hand side or rear				Read ECU Information		Y		
5008(P87)		Hands full access ECU, right-hand side or rear				Read Fault Code		Y		
5008(P87)		Controls under the steering wheel				Read ECU Information		Y		
5008(P87)		Controls under the steering wheel				Read Fault Code		Y		
5008(P87)		Controls under the steering wheel				Erase Fault Code		Y		
5008(P87)		Controls under the steering wheel				Live Data		Y		
5008(P87)		Controls under the steering wheel				Actuation Test		Y		
5008(P87)		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
5008(P87)		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
5008(P87)		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
5008(P87)		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
5008(P87)		Supply protection and management unit				Read ECU Information		Y		
5008(P87)		Supply protection and management unit				Read Fault Code		Y		
5008(P87)		Supply protection and management unit				Erase Fault Code		Y		
5008(P87)		Supply protection and management unit				Live Data		Y		
5008(P87)		Voltage retaining device	DMTC			Read ECU Information		Y		
5008(P87)		Voltage retaining device	DMTR DTC3B			Read ECU Information		Y		
5008(P87)		Voltage retaining device	DMTR DTC3B			Read Fault Code		Y		
5008(P87)		Voltage retaining device	DMTR DTC3B			Erase Fault Code		Y		
5008(P87)		Diesel additive pump				Read ECU Information		Y		
5008(P87)		Diesel additive pump				Read Fault Code		Y		
5008(P87)		Diesel additive pump				Erase Fault Code		Y		
5008(P87)		Diesel additive pump				Live Data		Y		
5008(P87)		Diesel additive pump				Actuation Test		Y		
5008(P87)		Traction control mode				Read ECU Information		Y		
5008(P87)		Traction control mode				Read Fault Code		Y		
5008(P87)		Traction control mode				Live Data		Y		
5008(P87)		Traction control mode				Actuation Test		Y		
5008(P87)		Front left seat heated pads and ventilation regulation				Read ECU Information		Y		
5008(P87)		Front left seat heated pads and ventilation regulation				Read Fault Code		Y		
5008(P87)		Front left seat heated pads and ventilation regulation				Live Data		Y		
5008(P87)		Front left seat heated pads and ventilation regulation				Actuation Test		Y		

5008(P87)		Front right seat heated pads and ventilation regulation				Read ECU Information		Y		
5008(P87)		Front right seat heated pads and ventilation regulation				Read Fault Code		Y		
5008(P87)		Front right seat heated pads and ventilation regulation				Live Data		Y		
5008(P87)		Front right seat heated pads and ventilation regulation				Actuation Test		Y		
5008(P87)		Automatic gearbox electric control				Read ECU Information		Y		
5008(P87)		Automatic gearbox electric control				Read Fault Code		Y		
5008(P87)		Automatic gearbox electric control				Erase Fault Code		Y		
5008(P87)		Automatic gearbox electric control				Live Data		Y		
5008(P87)		Automatic gearbox electric control				Actuation Test		Y		
5008(P87)		Automatic gearbox electric control				Special Function	Programming	Y		
5008(P87)		Automatic gearbox electric control				Special Function	Replacement parts	Y		
5008(P87)		Motorised Boot ECU				Read ECU Information		Y		
5008(P87)		Motorised Boot ECU				Read Fault Code		Y		
5008(P87)		Motorised Boot ECU				Erase Fault Code		Y		
5008(P87)		Motorised Boot ECU				Live Data		Y		
5008(P87)		Motorised Boot ECU				Actuation Test		Y		
5008(P87)		Vehicle Distance Assistance				Read ECU Information		Y		
5008(P87)		Vehicle Distance Assistance				Read Fault Code		Y		
5008(P87)		Vehicle Distance Assistance				Erase Fault Code		Y		
5008(P87)		Vehicle Distance Assistance				Live Data		Y		
5008(P87)		Vehicle Distance Assistance				Actuation Test		Y		
5008(P87)		Multiplexed control panel	RD6 audio system without air conditioning			Read ECU Information		Y		
5008(P87)		Multiplexed control panel	RD6 audio system without air conditioning			Read Fault Code		Y		
5008(P87)		Multiplexed control panel	RD6 audio system without air conditioning			Erase Fault Code		Y		
5008(P87)		Multiplexed control panel	RD6 audio system without air conditioning			Live Data		Y		
5008(P87)		Multiplexed control panel	RD6 audio system without air conditioning			Actuation Test		Y		
5008(P87)		Multiplexed control panel	RD6 audio system and manual air conditioning			Read ECU Information		Y		
5008(P87)		Multiplexed control panel	RD6 audio system and manual air conditioning			Read Fault Code		Y		
5008(P87)		Multiplexed control panel	RD6 audio system and manual air conditioning			Erase Fault Code		Y		
5008(P87)		Multiplexed control panel	RD6 audio system and manual air conditioning			Live Data		Y		
5008(P87)		Multiplexed control panel	RD6 audio system and manual air conditioning			Actuation Test		Y		
5008(P87)		Multiplexed control panel	Audio/Navigation NAC			Read ECU Information		Y		
5008(P87)		Multiplexed control panel	Audio/Navigation NAC			Read Fault Code		Y		
5008(P87)		Multiplexed control panel	Audio/Navigation NAC			Erase Fault Code		Y		
5008(P87)		Multiplexed control panel	Audio/Navigation NAC			Live Data		Y		
5008(P87)		Multiplexed control panel	Audio/Navigation NAC			Actuation Test		Y		
5008(P87)		Rear air conditioning ECU				Read ECU Information		Y		
5008(P87)		Rear air conditioning ECU				Read Fault Code		Y		
5008(P87)		Rear air conditioning ECU				Erase Fault Code		Y		
5008(P87)		Rear air conditioning ECU				Live Data		Y		
5008(P87)		Rear air conditioning ECU				Actuation Test		Y		
5008(P87)		Rear air conditioning ECU				Special Function	Pack Repair	Y		
5008(P87)		Electric steering lock				Read ECU Information		Y		
5008(P87)		Electric steering lock				Read Fault Code		Y		
5008(P87)		Electric steering lock				Erase Fault Code		Y		

5008(P87)		Electric steering lock				Live Data		Y		
5008(P87)		Trailer relay unit				Read ECU Information		Y		
5008(P87)		Trailer relay unit				Read Fault Code		Y		
5008(P87)		Trailer relay unit				Erase Fault Code		Y		
5008(P87)		Trailer relay unit				Live Data		Y		
5008(P87)		Trailer relay unit				Actuation Test		Y		
5008(P87)		Radio amplifier				Read ECU Information		Y		
5008(P87)		Radio amplifier				Read Fault Code		Y		
5008(P87)		Radio amplifier				Erase Fault Code		Y		
5008(P87)		Radio amplifier				Actuation Test		Y		
5008(P87)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read ECU Information		Y		
5008(P87)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read Fault Code		Y		
5008(P87)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Live Data		Y		
5008(P87)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Actuation Test		Y		
5008(P87)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read ECU Information		Y		
5008(P87)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read Fault Code		Y		
5008(P87)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Live Data		Y		
5008(P87)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Actuation Test		Y		
5008(P87)		Radio				Read ECU Information		Y		
5008(P87)		Radio				Read Fault Code		Y		
5008(P87)		Radio				Erase Fault Code		Y		
5008(P87)		Radio				Live Data		Y		
5008(P87)		Radio				Actuation Test		Y		
5008(P87)		Rain and brightness sensor				Read ECU Information		Y		
5008(P87)		Rain and brightness sensor				Read Fault Code		Y		
5008(P87)		Rain and brightness sensor				Erase Fault Code		Y		
5008(P87)		Rain and brightness sensor				Live Data		Y		
5008(P87)		Rain and brightness sensor				Special Function	Pack Repair	Y		
5008(P87)		External CD player				Read ECU Information		Y		
5008(P87)		External CD player				Read Fault Code		Y		
5008(P87)		External CD player				Erase Fault Code		Y		
5008(P87)		External CD player				Live Data		Y		
5008(P87)		External CD player				Actuation Test		Y		
5008(P87)		Power steering				Read ECU Information		Y		
5008(P87)		Power steering				Read Fault Code		Y		
5008(P87)		Power steering				Erase Fault Code		Y		
5008(P87)		Power steering				Live Data		Y		
5008(P87)		Multifunction video				Read ECU Information		Y		
5008(P87)		Multifunction video				Read Fault Code		Y		
5008(P87)		Multifunction video				Erase Fault Code		Y		
5008(P87)		Multifunction video				Live Data		Y		
5008(P87)		Multifunction video				Actuation Test		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	NAC			Read ECU Information		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	NAC			Read Fault Code		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	NAC			Erase Fault Code		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	NAC			Live Data		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	NAC			Actuation Test		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	RCC			Read ECU Information		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	RCC			Read Fault Code		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	RCC			Erase Fault Code		Y		

5008(P87)		Audio-navigation/telematic unit/connected audio system	RCC			Live Data		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	RCC			Actuation Test		Y		
5008(P87)		Touch screen				Read ECU Information		Y		
5008(P87)		Touch screen				Read Fault Code		Y		
5008(P87)		Touch screen				Erase Fault Code		Y		
5008(P87)		Touch screen				Live Data		Y		
5008(P87)		Touch screen				Actuation Test		Y		
5008(P87)		Driver's seat comfort ECU				Read ECU Information		Y		
5008(P87)		Driver's seat comfort ECU				Read Fault Code		Y		
5008(P87)		Driver's seat comfort ECU				Erase Fault Code		Y		
5008(P87)		Driver's seat comfort ECU				Live Data		Y		
5008(P87)		Driver's seat comfort ECU				Actuation Test		Y		
5008(P87)		Push gear lever				Read ECU Information		Y		
5008(P87)		Push gear lever				Read Fault Code		Y		
5008(P87)		Push gear lever				Erase Fault Code		Y		
5008(P87)		Push gear lever				Live Data		Y		
5008(P87)		Push gear lever				Actuation Test		Y		
5008(P87)		Windscreen wiper				Read ECU Information		Y		
5008(P87)		Windscreen wiper				Read Fault Code		Y		
5008(P87)		Windscreen wiper				Erase Fault Code		Y		
5008(P87)		Windscreen wiper				Live Data		Y		
5008(P87)		Windscreen wiper				Actuation Test		Y		
5008(P87)		Service module / Independent telematic unit	BTA 2			Read ECU Information		Y		
5008(P87)		Service module / Independent telematic unit	BTA 2			Read Fault Code		Y		
5008(P87)		Service module / Independent telematic unit	BTA 2			Erase Fault Code		Y		
5008(P87)		Service module / Independent telematic unit	BTA 2			Live Data		Y		
5008(P87)		Service module / Independent telematic unit	BTA 2			Actuation Test		Y		
5008(P87)		Service module / Independent telematic unit	BTA 2			Special Function	Pack Repair	Y		
5008(P87)		Service module / Independent telematic unit	BTA 3R			Read ECU Information		Y		
5008(P87)		Service module / Independent telematic unit	BTA 3R			Read Fault Code		Y		
5008(P87)		Service module / Independent telematic unit	BTA 3R			Erase Fault Code		Y		
5008(P87)		Service module / Independent telematic unit	BTA 3R			Live Data		Y		
5008(P87)		Service module / Independent telematic unit	BTA 3R			Actuation Test		Y		
5008(P87)		Service module / Independent telematic unit	BTA 3R			Special Function	Pack Repair	Y		
5008(P87)		Anti-theft alarm				Read ECU Information		Y		
5008(P87)		Anti-theft alarm				Read Fault Code		Y		
5008(P87)		Anti-theft alarm				Erase Fault Code		Y		
5008(P87)		Anti-theft alarm				Live Data		Y		
5008(P87)		Anti-theft alarm				Special Function	Configuration	Y		
5008(P87)		Anti-theft alarm				Special Function	Pack Repair	Y		
EXPERT 2		Instrument panel				Read Fault Code		Y		
EXPERT 2		Instrument panel				Erase Fault Code		Y		
EXPERT 2		Instrument panel				Live Data		Y		
EXPERT 2		Switch module at the steering wheel				Read ECU Information		Y		
EXPERT 2		Switch module at the steering wheel				Read Fault Code		Y		
EXPERT 2		Switch module at the steering wheel				Erase Fault Code		Y		
EXPERT 2		Switch module at the steering wheel				Live Data		Y		

EXPERT 2		Switch module at the steering wheel				Actuation Test		Y		
EXPERT 2		alarm				Read ECU Information		Y		
EXPERT 2		alarm				Read Fault Code		Y		
EXPERT 2		alarm				Erase Fault Code		Y		
EXPERT 2		alarm				Live Data		Y		
EXPERT 2		alarm				Actuation Test		Y		
EXPERT 2		Rain/sunlight sensor				Read ECU Information		Y		
EXPERT 2		Rain/sunlight sensor				Read Fault Code		Y		
EXPERT 2		Rain/sunlight sensor				Erase Fault Code		Y		
EXPERT 3		Engine ECU	EDC16C3	EDC16C3 9HU		Read ECU Information		Y		
EXPERT 3		Engine ECU	EDC16C3	EDC16C3 9HU		Read Fault Code		Y		
EXPERT 3		Engine ECU	EDC16C3	EDC16C3 9HU		Erase Fault Code		Y		
EXPERT 3		Engine ECU	EDC16C3	EDC16C3 9HU		Live Data		Y		
EXPERT 3		Engine ECU	EDC17C10 BR2	9HM-DV6UC		Read ECU Information		Y		
EXPERT 3		Engine ECU	EDC17C10 BR2	9HM-DV6UC		Read Fault Code		Y		
EXPERT 3		Engine ECU	EDC17C10 BR2	9HM-DV6UC		Erase Fault Code		Y		
EXPERT 3		Engine ECU	EDC17C10 BR2	9HM-DV6UC		Live Data		Y		
EXPERT 3		Engine ECU	EDC17C10 BR2	9HH-DV6UM		Read ECU Information		Y		
EXPERT 3		Engine ECU	EDC17C10 BR2	9HH-DV6UM		Read Fault Code		Y		
EXPERT 3		Engine ECU	EDC17C10 BR2	9HH-DV6UM		Erase Fault Code		Y		
EXPERT 3		Engine ECU	EDC17C10 BR2	9HH-DV6UM		Live Data		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHR		Read ECU Information		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHR		Read Fault Code		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHR		Erase Fault Code		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHR		Live Data		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHK		Read ECU Information		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHK		Read Fault Code		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHK		Erase Fault Code		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHK		Live Data		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHG		Read ECU Information		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHG		Read Fault Code		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHG		Erase Fault Code		Y		
EXPERT 3		Engine ECU	HDI SID803A	HDI SID803A RHG		Live Data		Y		
EXPERT 3		Engine ECU	MM6KP	MM6KP RFH		Read ECU Information		Y		
EXPERT 3		Engine ECU	MM6KP	MM6KP RFH		Read Fault Code		Y		
EXPERT 3		Engine ECU	MM6KP	MM6KP RFH		Erase Fault Code		Y		
EXPERT 3		Engine ECU	MM6KP	MM6KP RFH		Live Data		Y		
EXPERT 3		Engine ECU	MM6KP	MM6KP RFH		Special Function	Initialising the autoadaptives	Y		
EXPERT 3		Engine ECU	DCM3.5	DCM3.5 RHE/RHH		Read ECU Information		Y		
EXPERT 3		Engine ECU	DCM3.5	DCM3.5 RHE/RHH		Read Fault Code		Y		
EXPERT 3		Engine ECU	DCM3.5	DCM3.5 RHE/RHH		Erase Fault Code		Y		
EXPERT 3		Engine ECU	DCM3.5	DCM3.5 RHE/RHH		Live Data		Y		
EXPERT 3		Engine ECU	DCM3.5	DCM3.5 RHE/RHH		Special Function	Initialising the autoadaptives	Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Read ECU Information		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Read Fault Code		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Erase Fault Code		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Live Data		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHH-DW10CTED4-163CV		Special Function	Initialisation of the autoadaptive values	Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHD-DW10CTED4-136CV		Read ECU Information		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHD-DW10CTED4-136CV		Read Fault Code		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHD-DW10CTED4-136CV		Erase Fault Code		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHD-DW10CTED4-136CV		Live Data		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHD-DW10CTED4-136CV		Special Function	Initialisation of the autoadaptive values	Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Read ECU Information		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Read Fault Code		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Erase Fault Code		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Live Data		Y		
EXPERT 3		Engine ECU	DCM3.5 BR2	RHE-DW10CTED4-150CV		Special Function	Initialisation of the autoadaptive values	Y		
EXPERT 3		gearbox				Read ECU Information		Y		
EXPERT 3		gearbox				Read Fault Code		Y		
EXPERT 3		gearbox				Erase Fault Code		Y		
EXPERT 3		gearbox				Live Data		Y		

EXPERT 3		ABS/traction control	ABS 81			Read ECU Information		Y		
EXPERT 3		ABS/traction control	ABS 81			Read Fault Code		Y		
EXPERT 3		ABS/traction control	ABS 81			Erase Fault Code		Y		
EXPERT 3		ABS/traction control	ABS 81			Live Data		Y		
EXPERT 3		ABS/traction control	81 ESP			Read ECU Information		Y		
EXPERT 3		ABS/traction control	81 ESP			Read Fault Code		Y		
EXPERT 3		ABS/traction control	81 ESP			Erase Fault Code		Y		
EXPERT 3		ABS/traction control	81 ESP			Live Data		Y		
EXPERT 3		ABS/traction control	ABS 8 BOSCH			Read ECU Information		Y		
EXPERT 3		ABS/traction control	ABS 8 BOSCH			Read Fault Code		Y		
EXPERT 3		ABS/traction control	ABS 8 BOSCH			Erase Fault Code		Y		
EXPERT 3		ABS/traction control	ABS 8 BOSCH			Live Data		Y		
EXPERT 3		ABS/traction control	ESP 8 BOSCH			Read ECU Information		Y		
EXPERT 3		ABS/traction control	ESP 8 BOSCH			Read Fault Code		Y		
EXPERT 3		ABS/traction control	ESP 8 BOSCH			Erase Fault Code		Y		
EXPERT 3		ABS/traction control	ESP 8 BOSCH			Live Data		Y		
EXPERT 3		Driver and passenger airbags				Read ECU Information		Y		
EXPERT 3		Driver and passenger airbags				Read Fault Code		Y		
EXPERT 3		Driver and passenger airbags				Erase Fault Code		Y		
EXPERT 3		Driver and passenger airbags				Live Data		Y		
EXPERT 3		Power steering electric pump unit				Read ECU Information		Y		
EXPERT 3		Power steering electric pump unit				Read Fault Code		Y		
EXPERT 3		Power steering electric pump unit				Erase Fault Code		Y		
EXPERT 3		Power steering electric pump unit				Live Data		Y		
EXPERT 3		Deflation detection (DSG)				Read ECU Information		Y		
EXPERT 3		Deflation detection (DSG)				Read Fault Code		Y		
EXPERT 3		Deflation detection (DSG)				Erase Fault Code		Y		
EXPERT 3		Deflation detection (DSG)				Live Data		Y		
EXPERT 3		Pneumatic suspension				Read ECU Information		Y		
EXPERT 3		Pneumatic suspension				Read Fault Code		Y		
EXPERT 3		Pneumatic suspension				Erase Fault Code		Y		
EXPERT 3		Pneumatic suspension				Live Data		Y		
EXPERT 3		Additional heating				Read ECU Information		Y		
EXPERT 3		Additional heating				Read Fault Code		Y		
EXPERT 3		Additional heating				Erase Fault Code		Y		
EXPERT 3		Additional heating				Live Data		Y		
EXPERT 3		Trailer relay unit				Read ECU Information		Y		
EXPERT 3		Trailer relay unit				Read Fault Code		Y		
EXPERT 3		Trailer relay unit				Erase Fault Code		Y		
EXPERT 3		Engine relay unit				Read ECU Information		Y		
EXPERT 3		Engine relay unit				Read Fault Code		Y		
EXPERT 3		Engine relay unit				Erase Fault Code		Y		
EXPERT 3		Instrument panel				Read ECU Information		Y		
EXPERT 3		Instrument panel				Read Fault Code		Y		
EXPERT 3		Instrument panel				Erase Fault Code		Y		
EXPERT 3		Instrument panel				Live Data		Y		
EXPERT 3		Parking aid				Read ECU Information		Y		
EXPERT 3		Parking aid				Read Fault Code		Y		
EXPERT 3		Parking aid				Erase Fault Code		Y		
EXPERT 3		Parking aid				Live Data		Y		
EXPERT 3		Switch module under the steering wheel(Top of				Read ECU Information		Y		
EXPERT 3		Switch module under the steering wheel(Top of				Read Fault Code		Y		
EXPERT 3		Switch module under the steering wheel(Top of				Erase Fault Code		Y		
EXPERT 3		Switch module under the steering wheel(Top of				Live Data		Y		
EXPERT 3		Multifunction display	Type 'A' (segments)AVEC buttons			Read ECU Information		Y		
EXPERT 3		Multifunction display	Type 'A' (segments)AVEC buttons			Read Fault Code		Y		

EXPERT 3		Multifunction display	Type 'A' (segments)AVEC buttons			Erase Fault Code		Y		
EXPERT 3		Multifunction display	Type 'A' (segments)AVEC buttons			Live Data		Y		
EXPERT 3		Multifunction display	Type 'A' (segments)SANS buttons			Read ECU Information		Y		
EXPERT 3		Multifunction display	Type 'A' (segments)SANS buttons			Read Fault Code		Y		
EXPERT 3		Multifunction display	Type 'A' (segments)SANS buttons			Erase Fault Code		Y		
EXPERT 3		Multifunction display	Type 'A' (segments)SANS buttons			Live Data		Y		
EXPERT 3		Multifunction display	Type 'C' (dot matrix)			Read ECU Information		Y		
EXPERT 3		Multifunction display	Type 'C' (dot matrix)			Read Fault Code		Y		
EXPERT 3		Multifunction display	Type 'C' (dot matrix)			Erase Fault Code		Y		
EXPERT 3		Multifunction display	Type 'C' (dot matrix)			Live Data		Y		
EXPERT 3		Multifunction display	Type 'C colour' (dot			Read ECU Information		Y		
EXPERT 3		Multifunction display	Type 'C colour' (dot			Read Fault Code		Y		
EXPERT 3		Multifunction display	Type 'C colour' (dot			Erase Fault Code		Y		
EXPERT 3		Multifunction display	Type 'C colour' (dot			Live Data		Y		
EXPERT 3		heating/ventilation				Read ECU Information		Y		
EXPERT 3		heating/ventilation				Read Fault Code		Y		
EXPERT 3		heating/ventilation				Erase Fault Code		Y		
EXPERT 3		heating/ventilation				Live Data		Y		
EXPERT 3		CD player				Read ECU Information		Y		
EXPERT 3		CD player				Read Fault Code		Y		
EXPERT 3		CD player				Erase Fault Code		Y		
EXPERT 3		CD player				Actuation Test		Y		
EXPERT 3		Hands-free kit (Telephone)	KML			Read ECU Information		Y		
EXPERT 3		Hands-free kit (Telephone)	KML			Read Fault Code		Y		
EXPERT 3		Hands-free kit (Telephone)	KML			Erase Fault Code		Y		
EXPERT 3		Hands-free kit (Telephone)	KML			Live Data		Y		
EXPERT 3		Hands-free kit (Telephone)	BOITIER NOMADE			Read ECU Information		Y		
EXPERT 3		Hands-free kit (Telephone)	BOITIER NOMADE			Read Fault Code		Y		
EXPERT 3		Hands-free kit (Telephone)	BOITIER NOMADE			Erase Fault Code		Y		
EXPERT 3		Hands-free kit (Telephone)	BOITIER NOMADE			Live Data		Y		
EXPERT 3		Radio or radiotelephone(radio part)	RD4			Read ECU Information		Y		
EXPERT 3		Radio or radiotelephone(radio part)	RD4			Read Fault Code		Y		
EXPERT 3		Radio or radiotelephone(radio part)	RD4			Erase Fault Code		Y		
EXPERT 3		Radio or radiotelephone(radio part)	RD4			Live Data		Y		
EXPERT 3		Radio or radiotelephone(radio part)	RD45			Read ECU Information		Y		
EXPERT 3		Radio or radiotelephone(radio part)	RD45			Read Fault Code		Y		
EXPERT 3		Radio or radiotelephone(radio part)	RD45			Erase Fault Code		Y		
EXPERT 3		Radio or radiotelephone(radio part)	RD45			Live Data		Y		
EXPERT 3		Telematics	BOITIER TELEMATIQUE			Read ECU Information		Y		
EXPERT 3		Telematics	BOITIER TELEMATIQUE			Read Fault Code		Y		
EXPERT 3		Telematics	BOITIER TELEMATIQUE			Erase Fault Code		Y		
EXPERT 3		Telematics	BOITIER TELEMATIQUE			Live Data		Y		
EXPERT 3		Telematics	RADIOAV RNEG			Read ECU Information		Y		
EXPERT 3		Telematics	RADIOAV RNEG			Read Fault Code		Y		
EXPERT 3		Telematics	RADIOAV RNEG			Erase Fault Code		Y		
EXPERT 3		Telematics	RADIOAV RNEG			Live Data		Y		
EXPERT 3		Telematics	RNEG2010			Read ECU Information		Y		
EXPERT 3		Telematics	RNEG2010			Read Fault Code		Y		
EXPERT 3		Telematics	RNEG2010			Erase Fault Code		Y		
EXPERT 3		Telematics	RNEG2010			Live Data		Y		
EXPERT 3		Anti-theft alarm				Read ECU Information		Y		
EXPERT 3		Anti-theft alarm				Read Fault Code		Y		

EXPERT 3		Anti-theft alarm				Erase Fault Code		Y		
EXPERT 3		Anti-theft alarm				Live Data		Y		
EXPERT 3		Anti-slip mode selector				Read ECU Information		Y		
EXPERT 3		Anti-slip mode selector				Read Fault Code		Y		
EXPERT 3		Anti-slip mode selector				Live Data		Y		
EXPERT 3		Rear air conditioning table				Read ECU Information		Y		
EXPERT 3		Rear air conditioning table				Read Fault Code		Y		
EXPERT 3		Rear air conditioning table				Erase Fault Code		Y		
EXPERT 3		Rear air conditioning table				Live Data		Y		
EXPERT 3		Rain and brightness sensor				Read ECU Information		Y		
EXPERT 3		Rain and brightness sensor				Read Fault Code		Y		
EXPERT 3		Rain and brightness sensor				Erase Fault Code		Y		
EXPERT 3		High frequency receiver				Read ECU Information		Y		
EXPERT 3		High frequency receiver				Read Fault Code		Y		
EXPERT 3		High frequency receiver				Erase Fault Code		Y		
EXPERT 3		High frequency receiver				Live Data		Y		
EXPERT 3		Battery charge status unit				Read ECU Information		Y		
EXPERT 3		Battery charge status unit				Live Data		Y		
HOGGAR		Engine ECU	EDC15C2			Read ECU Information		Y		
HOGGAR		Engine ECU	EDC15C2			Read Fault Code		Y		
HOGGAR		Engine ECU	EDC15C2			Erase Fault Code		Y		
HOGGAR		Engine ECU	EDC15C2			Live Data		Y		
HOGGAR		Engine ECU	EDC15C2			Actuation Test		Y		
HOGGAR		Engine ECU	EDC15C2			Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Erase Fault Code		Y		

HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Read ECU Information		Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Read Fault Code		Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Erase Fault Code		Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Live Data		Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Actuation Test		Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Read ECU Information		Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Read Fault Code		Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Erase Fault Code		Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Live Data		Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Actuation Test		Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Read ECU Information		Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Read Fault Code		Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Erase Fault Code		Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Live Data		Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Actuation Test		Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Special Function	Pack Repair	Y		

HOGGAR		Engine ECU	DCN2	DCN2 HFX		Read ECU Information		Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Read Fault Code		Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Erase Fault Code		Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Live Data		Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Actuation Test		Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Read ECU Information		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Read Fault Code		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Erase Fault Code		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Live Data		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Actuation Test		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Special Function	Pairing	Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Read ECU Information		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Read Fault Code		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Erase Fault Code		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Live Data		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Actuation Test		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Special Function	Pairing	Y		
HOGGAR		Engine ECU	V343	V343 HFV		Read ECU Information		Y		
HOGGAR		Engine ECU	V343	V343 HFV		Read Fault Code		Y		
HOGGAR		Engine ECU	V343	V343 HFV		Erase Fault Code		Y		
HOGGAR		Engine ECU	V343	V343 HFV		Live Data		Y		
HOGGAR		Engine ECU	V343	V343 HFV		Actuation Test		Y		
HOGGAR		Engine ECU	V343	V343 HFV		Special Function	Initialisation of the auto-adaptive components	Y		
HOGGAR		Engine ECU	V343	V343 KFT		Read ECU Information		Y		
HOGGAR		Engine ECU	V343	V343 KFT		Read Fault Code		Y		
HOGGAR		Engine ECU	V343	V343 KFT		Erase Fault Code		Y		
HOGGAR		Engine ECU	V343	V343 KFT		Live Data		Y		
HOGGAR		Engine ECU	V343	V343 KFT		Actuation Test		Y		
HOGGAR		Engine ECU	V343	V343 KFT		Special Function	Initialisation of the auto-adaptive components	Y		
HOGGAR		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
HOGGAR		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
HOGGAR		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
HOGGAR		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Live Data		Y		
HOGGAR		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
HOGGAR		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
HOGGAR		Engine ECU	EDC17C10 BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
HOGGAR		gearbox				Read ECU Information		Y		
HOGGAR		gearbox				Live Data		Y		
HOGGAR		gearbox				Actuation Test		Y		
HOGGAR		gearbox				Special Function	Configuration	Y		
HOGGAR		gearbox				Special Function	Pack Repair	Y		
HOGGAR		ABS/traction control	ABS MK70			Read ECU Information		Y		
HOGGAR		ABS/traction control	ABS MK70			Read Fault Code		Y		
HOGGAR		ABS/traction control	ABS MK70			Erase Fault Code		Y		
HOGGAR		ABS/traction control	ABS MK70			Live Data		Y		
HOGGAR		ABS/traction control	ABS MK70			Actuation Test		Y		
HOGGAR		ABS/traction control	ABS MK70			Special Function	Replacement parts	Y		
HOGGAR		ABS/traction control	ESP MK60			Read ECU Information		Y		
HOGGAR		ABS/traction control	ESP MK60			Read Fault Code		Y		
HOGGAR		ABS/traction control	ESP MK60			Erase Fault Code		Y		
HOGGAR		ABS/traction control	ESP MK60			Live Data		Y		
HOGGAR		ABS/traction control	ESP MK60			Actuation Test		Y		
HOGGAR		ABS/traction control	ESP MK60			Special Function	Replacement parts	Y		
HOGGAR		Driver and passenger airbags				Read ECU Information		Y		
HOGGAR		Driver and passenger airbags				Read Fault Code		Y		
HOGGAR		Driver and passenger airbags				Erase Fault Code		Y		
HOGGAR		Driver and passenger airbags				Special Function	Replacement parts	Y		
HOGGAR		Multifunction display	RT3			Read ECU Information		Y		
HOGGAR		Multifunction display	RT3			Read Fault Code		Y		
HOGGAR		Multifunction display	RT3			Erase Fault Code		Y		
HOGGAR		Multifunction display	RT3			Actuation Test		Y		

HOGGAR		Multifunction display	Display			Read ECU Information		Y		
HOGGAR		Multifunction display	Display			Read Fault Code		Y		
HOGGAR		Multifunction display	Display			Erase Fault Code		Y		
HOGGAR		Multifunction display	Display			Live Data		Y		
HOGGAR		Multifunction display	Display			Actuation Test		Y		
HOGGAR		Anti-theft alarm				Read ECU Information		Y		
HOGGAR		Anti-theft alarm				Read Fault Code		Y		
HOGGAR		Anti-theft alarm				Erase Fault Code		Y		
HOGGAR		Anti-theft alarm				Actuation Test		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio			Read ECU Information		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio			Read Fault Code		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio			Erase Fault Code		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio			Live Data		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio			Actuation Test		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio. RDE filament			Read ECU Information		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio. RDE filament			Read Fault Code		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio. RDE filament			Erase Fault Code		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio. RDE filament			Live Data		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio. RDE filament			Actuation Test		Y		
HOGGAR		BSI				Read ECU Information		Y		
HOGGAR		BSI				Read Fault Code		Y		
HOGGAR		BSI				Erase Fault Code		Y		
HOGGAR		BSI				Live Data		Y		
HOGGAR		BSI				Actuation Test		Y		
HOGGAR		CD player				Read ECU Information		Y		
HOGGAR		CD player				Read Fault Code		Y		
HOGGAR		CD player				Erase Fault Code		Y		
HOGGAR		CD player				Live Data		Y		
HOGGAR		CD player				Actuation Test		Y		
HOGGAR		heating/ventilation				Read ECU Information		Y		
HOGGAR		heating/ventilation				Read Fault Code		Y		
HOGGAR		heating/ventilation				Erase Fault Code		Y		
HOGGAR		heating/ventilation				Live Data		Y		
HOGGAR		Instrument panel				Read ECU Information		Y		
HOGGAR		Instrument panel				Read Fault Code		Y		
HOGGAR		Instrument panel				Erase Fault Code		Y		
HOGGAR		Instrument panel				Live Data		Y		
HOGGAR		Instrument panel				Actuation Test		Y		
HOGGAR		Rain and brightness sensor				Read ECU Information		Y		
HOGGAR		Rain and brightness sensor				Read Fault Code		Y		
HOGGAR		Rain and brightness sensor				Erase Fault Code		Y		
HOGGAR		Switch module at the steering wheel				Read ECU Information		Y		
HOGGAR		Switch module at the steering wheel				Read Fault Code		Y		
HOGGAR		Switch module at the steering wheel				Erase Fault Code		Y		
HOGGAR		Switch module at the steering wheel				Live Data		Y		
HOGGAR		Power steering electric pump unit				Read ECU Information		Y		
HOGGAR		Power steering electric pump unit				Read Fault Code		Y		
HOGGAR		Power steering electric pump unit				Erase Fault Code		Y		

HOGGAR		Power steering electric pump unit				Live Data		Y		
HOGGAR		Services module				Read ECU Information		Y		
HOGGAR		Services module				Read Fault Code		Y		
HOGGAR		Services module				Erase Fault Code		Y		
HOGGAR		Services module				Live Data		Y		
HOGGAR		Services module				Actuation Test		Y		
ION		BSI(Built-in Systems				Read ECU Information		Y		
ION		BSI(Built-in Systems				Read Fault Code		Y		
ION		BSI(Built-in Systems				Erase Fault Code		Y		
ION		BSI(Built-in Systems				Live Data		Y		
ION		computer control of electric machines				Read ECU Information		Y		
ION		computer control of electric machines				Read Fault Code		Y		
ION		computer control of electric machines				Erase Fault Code		Y		
ION		computer control of electric machines				Live Data		Y		
ION		Power steering				Read ECU Information		Y		
ION		Power steering				Read Fault Code		Y		
ION		Power steering				Erase Fault Code		Y		
ION		Power steering				Live Data		Y		
ION		Airbag	SRS			Read ECU Information		Y		
ION		Airbag	SRS			Read Fault Code		Y		
ION		Airbag	SRS			Erase Fault Code		Y		
ION		Airbag	SRS			Live Data		Y		
ION		Airbag	SRS			Actuation Test		Y		
ION		Airbag	ORC			Read ECU Information		Y		
ION		Airbag	ORC			Read Fault Code		Y		
ION		Airbag	ORC			Erase Fault Code		Y		
ION		Airbag	ORC			Live Data		Y		
ION		Airbag	ORC			Actuation Test		Y		
ION		Traction battery ECU				Read ECU Information		Y		
ION		Traction battery ECU				Read Fault Code		Y		
ION		Traction battery ECU				Erase Fault Code		Y		
ION		Traction battery ECU				Live Data		Y		
ION		Traction battery ECU				Actuation Test		Y		
ION		Electric vehicle management				Read ECU Information		Y		
ION		Electric vehicle management				Read Fault Code		Y		
ION		Electric vehicle management				Erase Fault Code		Y		
ION		Electric vehicle management				Live Data		Y		
ION		Electric vehicle management				Actuation Test		Y		
ION		ESP				Read ECU Information		Y		
ION		ESP				Read Fault Code		Y		
ION		ESP				Erase Fault Code		Y		
ION		ESP				Live Data		Y		
ION		Steering wheel angle sensor				Read ECU Information		Y		
ION		Steering wheel angle sensor				Read Fault Code		Y		
ION		Steering wheel angle sensor				Erase Fault Code		Y		
ION		Steering wheel angle sensor				Live Data		Y		
ION		Gateway wiring housing				Read ECU Information		Y		
ION		Gateway wiring housing				Read Fault Code		Y		
ION		Gateway wiring housing				Erase Fault Code		Y		
ION		Gateway wiring housing				Live Data		Y		
ION		Independent telematic unit (BTA)				Read ECU Information		Y		
ION		Independent telematic unit (BTA)				Read Fault Code		Y		
ION		Independent telematic unit (BTA)				Erase Fault Code		Y		
ION		Independent telematic unit (BTA)				Live Data		Y		
ION		Instrument panel				Read ECU Information		Y		
ION		Instrument panel				Read Fault Code		Y		
ION		Instrument panel				Erase Fault Code		Y		

ION		Instrument panel				Live Data		Y		
ION		Radio				Read ECU Information		Y		
ION		Radio				Read Fault Code		Y		
ION		Radio				Erase Fault Code		Y		
ION		Radio				Live Data		Y		
ION		Air conditioning				Read ECU Information		Y		
ION		Air conditioning				Read Fault Code		Y		
ION		Air conditioning				Erase Fault Code		Y		
ION		Air conditioning				Live Data		Y		
ION		Air conditioning compressor and passenger compartment heating control module				Read ECU Information		Y		
ION		Air conditioning compressor and passenger compartment heating control module				Read Fault Code		Y		
ION		Air conditioning compressor and passenger compartment heating control module				Erase Fault Code		Y		
ION		Air conditioning compressor and passenger compartment heating control module				Live Data		Y		
ION		Direct voltage (DC/DC) transformer				Read ECU Information		Y		
ION		Direct voltage (DC/DC) transformer				Read Fault Code		Y		
ION		Direct voltage (DC/DC) transformer				Erase Fault Code		Y		
ION		Direct voltage (DC/DC) transformer				Live Data		Y		
ION		Onboard charger of the traction battery				Read ECU Information		Y		
ION		Onboard charger of the traction battery				Read Fault Code		Y		
ION		Onboard charger of the traction battery				Erase Fault Code		Y		
ION		Onboard charger of the traction battery				Live Data		Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Live Data		Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HDY BOSCH MA3.1.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HDY BOSCH MA3.1.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HDY BOSCH MA3.1.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HDY BOSCH MA3.1.		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HDZ BOSCH MA3.1.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HDZ BOSCH MA3.1.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HDZ BOSCH MA3.1.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HDZ BOSCH MA3.1.		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HFX BOSCH M7.4.4.		Read ECU Information		Y		

PARTNER	Production date before 30 September 2002	engines	Petrol	HFX BOSCH M7.4.4.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HFX BOSCH M7.4.4.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HFX BOSCH M7.4.4.		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	HFX BOSCH M7.4.4.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFW SAGEM S2000.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFW SAGEM S2000.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFW SAGEM S2000.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFW SAGEM S2000.		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFW SAGEM S2000.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	K6D SAGEM S2000.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	K6D SAGEM S2000.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	K6D SAGEM S2000.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	K6D SAGEM S2000.		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	K6D SAGEM S2000.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX BOSCH MP7.3.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX BOSCH MP7.3.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX BOSCH MP7.3.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX BOSCH MP7.3.		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX BOSCH MP7.3.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX MM1AP .		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX MM1AP .		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX MM1AP .		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX MM1AP .		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX SAGEM SL 96.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX SAGEM SL 96.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX SAGEM SL 96.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX SAGEM SL 96.		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	KFX SAGEM SL 96.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	LFX MM1AP.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	LFX MM1AP.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	LFX MM1AP.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	LFX MM1AP.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6A BOSCH ME7.4.4 .		Read ECU Information		Y		

PARTNER	Production date before 30 September 2002	engines	Petrol	N6A BOSCH ME7.4.4 .		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6A BOSCH ME7.4.4 .		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6A BOSCH ME7.4.4 .		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6A BOSCH ME7.4.4 .		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	NFU BOSCH ME7.4.4 .		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	NFU BOSCH ME7.4.4 .		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	NFU BOSCH ME7.4.4 .		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	NFU BOSCH ME7.4.4 .		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	NFU BOSCH ME7.4.4 .		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6A BOSCH ME7.4.5 .		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6A BOSCH ME7.4.5 .		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6A BOSCH ME7.4.5 .		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6A BOSCH ME7.4.5 .		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6A BOSCH ME7.4.5 .		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6B BOSCH ME7.4.5 .		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6B BOSCH ME7.4.5 .		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6B BOSCH ME7.4.5 .		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6B BOSCH ME7.4.5 .		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	N6B BOSCH ME7.4.5 .		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	NFU BOSCH ME7.4.5 .		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	NFU BOSCH ME7.4.5 .		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	NFU BOSCH ME7.4.5 .		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	NFU BOSCH ME7.4.5 .		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Petrol	NFU BOSCH ME7.4.5 .		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	RHY SIEMENS SID801.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	RHY SIEMENS SID801.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	RHY SIEMENS SID801.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	RHY SIEMENS SID801.		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	RHY SIEMENS SID801.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	RHY BOSCH EDC15C2.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	RHY BOSCH EDC15C2.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	RHY BOSCH EDC15C2.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	RHY BOSCH EDC15C2.		Live Data		Y		

PARTNER	Production date before 30 September 2002	engines	Diesel	RHY BOSCH EDC15C2.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	WJY LUCAS DCN2.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	WJY LUCAS DCN2.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	WJY LUCAS DCN2.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	WJY LUCAS DCN2.		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	WJY LUCAS DCN2.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	WJZ LUCAS DCN2.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	WJZ LUCAS DCN2.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	WJZ LUCAS DCN2.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	WJZ LUCAS DCN2.		Live Data		Y		
PARTNER	Production date before 30 September 2002	engines	Diesel	WJZ LUCAS DCN2.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.			Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.			Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.			Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.			Live Data		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.			Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Live Data		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Special Function	Bleeding	Y		
PARTNER	Production date before 30 September 2002	Radio	Radio PHILIPS			Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio PHILIPS			Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio PHILIPS			Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio PHILIPS			Live Data		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio PHILIPS			Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio CLARION			Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio CLARION			Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio CLARION			Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio CLARION			Live Data		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio CLARION			Actuation Test		Y		
PARTNER	Production date before 30 September 2002	CD player				Read ECU Information		Y		

PARTNER	Production date before 30 September 2002	CD player				Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	CD player				Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	CD player				Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Instrument panel				Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Instrument panel				Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Instrument panel				Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Instrument panel				Live Data		Y		
PARTNER	Production date before 30 September 2002	Instrument panel				Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Additional heating				Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Additional heating				Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Additional heating				Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Additional heating				Live Data		Y		
PARTNER	Production date before 30 September 2002	Additional heating				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	BSI(Built-in Systems Interface)				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	BSI(Built-in Systems Interface)				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	BSI(Built-in Systems Interface)				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	HFX MM4.8P .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	HFX MM4.8P .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	HFX MM4.8P .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	HFX MM4.8P .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	HFX MM4.8P .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW SAGEM S2000PM1 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW SAGEM S2000PM1 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW SAGEM S2000PM1 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW SAGEM S2000PM1 .		Live Data		Y		

PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW SAGEM S2000PM1 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW SAGEM S2000PM2 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW SAGEM S2000PM2 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW SAGEM S2000PM2 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW SAGEM S2000PM2 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW SAGEM S2000PM2 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME7.4.4 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME7.4.4 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME7.4.4 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME7.4.4 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME7.4.4 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU BOSCH ME7.4.4 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU BOSCH ME7.4.4 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU BOSCH ME7.4.4 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU BOSCH ME7.4.4 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU BOSCH ME7.4.4 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME7.4.5 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME7.4.5 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME7.4.5 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME7.4.5 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME7.4.5 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6B BOSCH ME7.4.5 .		Read ECU Information		Y		

PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6B BOSCH ME7.4.5 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6B BOSCH ME7.4.5 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6B BOSCH ME7.4.5 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6B BOSCH ME7.4.5 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU BOSCH ME7.4.5 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU BOSCH ME7.4.5 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU BOSCH ME7.4.5 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU BOSCH ME7.4.5 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU BOSCH ME7.4.5 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU Or N6A BOSCH ME749 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU Or N6A BOSCH ME749 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU Or N6A BOSCH ME749 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU Or N6A BOSCH ME749 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	NFU Or N6A BOSCH ME749 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME749 BIO FLEX .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME749 BIO FLEX .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME749 BIO FLEX .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME749 BIO FLEX .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	N6A BOSCH ME749 BIO FLEX .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW BOSCH ME749 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW BOSCH ME749 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW BOSCH ME749 .		Erase Fault Code		Y		

PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW BOSCH ME749 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW BOSCH ME749 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW BOSCH ME749 BIO FLEX .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW BOSCH ME749 BIO FLEX .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW BOSCH ME749 BIO FLEX .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW BOSCH ME749 BIO FLEX .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW BOSCH ME749 BIO FLEX .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW J34P .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW J34P .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW J34P .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW J34P .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Petrol	KFW J34P .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	RHY SIEMENS SID801 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	RHY SIEMENS SID801 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	RHY SIEMENS SID801 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	RHY SIEMENS SID801 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	RHY SIEMENS SID801 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	RHY SIEMENS SID801 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	RHY SIEMENS SID801 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	RHY SIEMENS SID801 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	RHY SIEMENS SID801 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	RHY SIEMENS SID801 .		Actuation Test		Y		

PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	WJY LUCAS DCN2 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	WJY LUCAS DCN2 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	WJY LUCAS DCN2 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	WJY LUCAS DCN2 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	WJY LUCAS DCN2 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HW BOSCH EDC16C3 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HW BOSCH EDC16C3 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HW BOSCH EDC16C3 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HW BOSCH EDC16C3 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HW BOSCH EDC16C3 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HX BOSCH EDC16C3 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HX BOSCH EDC16C3 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HX BOSCH EDC16C3 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HX BOSCH EDC16C3 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HX BOSCH EDC16C3 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HT BOSCH EDC16C3 .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HT BOSCH EDC16C3 .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HT BOSCH EDC16C3 .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HT BOSCH EDC16C3 .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HT BOSCH EDC16C3 .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HJ EDC17C10_BR2 - DV6DTEDM - 92 CV .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HJ EDC17C10_BR2 - DV6DTEDM - 92 CV .		Read Fault Code		Y		

PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HJ EDC17C10_BR2 - DV6DTEDM - 92 CV .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HJ EDC17C10_BR2 - DV6DTEDM - 92 CV .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HJ EDC17C10_BR2 - DV6DTEDM - 92 CV .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HK EDC17C10_BR2 - DV6ETEDM - 75 CV .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HK EDC17C10_BR2 - DV6ETEDM - 75 CV .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HK EDC17C10_BR2 - DV6ETEDM - 75 CV .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HK EDC17C10_BR2 - DV6ETEDM - 75 CV .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HK EDC17C10_BR2 - DV6ETEDM - 75 CV .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HE EDC17C10_BR2 - DV6DBM - 89 CV .		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HE EDC17C10_BR2 - DV6DBM - 89 CV .		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HE EDC17C10_BR2 - DV6DBM - 89 CV .		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HE EDC17C10_BR2 - DV6DBM - 89 CV .		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	engines	Diesel	9HE EDC17C10_BR2 - DV6DBM - 89 CV .		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Special Function	Bleeding	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Erase Fault Code		Y		

PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Special Function	Bleeding	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Special Function	Steering wheel angle sensor calibration	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Special Function	De-calibration of the steering wheel angle sensor	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Special Function	Steering wheel angle sensor calibration	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Special Function	De-calibration of the steering wheel angle sensor	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Special Function	Bleeding	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Live Data		Y		

PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Special Function	Bleeding	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Special Function	Bleeding	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Airbags				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Airbags				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Airbags				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	LPG / GNV	SAGEM SAX500			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	LPG / GNV	SAGEM SAX500			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	LPG / GNV	SAGEM SAX500			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	LPG / GNV	SAGEM SAX500			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Parking aid				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Parking aid				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Parking aid				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Parking aid				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Parking aid				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Additional heating				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Additional heating				Read Fault Code		Y		

PARTNER	Production date between 30 September 2002 and 27 October 2002	Additional heating				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Additional heating				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Additional heating				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	alarm				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	alarm				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	alarm				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	alarm				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	alarm				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Service module				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Service module				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Service module				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Service module				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Service module				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	AMF			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	AMF			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	AMF			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	AMF			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	AMF			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	RT3			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	RT3			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	RT3			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	RT3			Live Data		Y		

PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	RT3			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	CD player				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	CD player				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	CD player				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	CD player				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	CD player				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Instrument panel				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Instrument panel				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Instrument panel				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Instrument panel				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Instrument panel				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Switching module below steering wheel (COM 2000)				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Switching module below steering wheel (COM 2000)				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Switching module below steering wheel (COM 2000)				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Switching module below steering wheel (COM 2000)				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Rain/sunlight sensor				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Rain/sunlight sensor				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Rain/sunlight sensor				Erase Fault Code		Y		
PARTNER B9		Air bag				Read ECU Information		Y		
PARTNER B9		Air bag				Read Fault Code		Y		
PARTNER B9		Air bag				Erase Fault Code		Y		
PARTNER B9		Air bag				Live Data		Y		
PARTNER B9		Power steering				Read ECU Information		Y		
PARTNER B9		Power steering				Read Fault Code		Y		
PARTNER B9		Power steering				Erase Fault Code		Y		
PARTNER B9		Power steering				Live Data		Y		
PARTNER B9		Power steering				Actuation Test		Y		
PARTNER B9		Instrument panel				Read ECU Information		Y		
PARTNER B9		Instrument panel				Read Fault Code		Y		
PARTNER B9		Instrument panel				Erase Fault Code		Y		

PARTNER B9		Instrument panel				Live Data		Y		
PARTNER B9		Instrument panel				Actuation Test		Y		
PARTNER B9		Under inflation detection				Read ECU Information		Y		
PARTNER B9		Under inflation detection				Read Fault Code		Y		
PARTNER B9		Under inflation detection				Erase Fault Code		Y		
PARTNER B9		Under inflation detection				Live Data		Y		
PARTNER B9		Under inflation detection				Actuation Test		Y		
PARTNER B9		alarm				Read ECU Information		Y		
PARTNER B9		alarm				Read Fault Code		Y		
PARTNER B9		alarm				Erase Fault Code		Y		
PARTNER B9		alarm				Live Data		Y		
PARTNER B9		alarm				Actuation Test		Y		
PARTNER B9		BSI(Built-in Systems				Read ECU Information		Y		
PARTNER B9		BSI(Built-in Systems				Read Fault Code		Y		
PARTNER B9		BSI(Built-in Systems				Erase Fault Code		Y		
PARTNER B9		BSI(Built-in Systems				Live Data		Y		
PARTNER B9		BSI(Built-in Systems				Actuation Test		Y		
PARTNER B9		BSI(Built-in Systems				Special Function	Changing the mode Electrical	Y		
PARTNER B9		BSI(Built-in Systems				Special Function	Learning	Y		
PARTNER B9		Parking aid				Read ECU Information		Y		
PARTNER B9		Parking aid				Read Fault Code		Y		
PARTNER B9		Parking aid				Erase Fault Code		Y		
PARTNER B9		Parking aid				Live Data		Y		
PARTNER B9		heating/ventilation				Read ECU Information		Y		
PARTNER B9		heating/ventilation				Read Fault Code		Y		
PARTNER B9		heating/ventilation				Erase Fault Code		Y		
PARTNER B9		heating/ventilation				Live Data		Y		
PARTNER B9		heating/ventilation				Actuation Test		Y		
PARTNER B9		Radio				Read ECU Information		Y		
PARTNER B9		Radio				Read Fault Code		Y		
PARTNER B9		Radio				Erase Fault Code		Y		
PARTNER B9		Radio				Live Data		Y		
PARTNER B9		Radio				Actuation Test		Y		
PARTNER B9		CD player				Read ECU Information		Y		
PARTNER B9		CD player				Read Fault Code		Y		
PARTNER B9		CD player				Erase Fault Code		Y		
PARTNER B9		CD player				Actuation Test		Y		
PARTNER B9		Switch module at the steering wheel				Read ECU Information		Y		
PARTNER B9		Switch module at the steering wheel				Read Fault Code		Y		
PARTNER B9		Switch module at the steering wheel				Erase Fault Code		Y		
PARTNER B9		Switch module at the steering wheel				Live Data		Y		
PARTNER B9		Switch module at the steering wheel				Actuation Test		Y		
PARTNER B9		Battery charge status unit				Read ECU Information		Y		
PARTNER B9		Battery charge status unit				Read Fault Code		Y		
PARTNER B9		Battery charge status unit				Erase Fault Code		Y		
PARTNER B9		Battery charge status unit				Live Data		Y		
PARTNER B9		Independent telematic unit				Read ECU Information		Y		
PARTNER B9		Independent telematic unit				Read Fault Code		Y		
PARTNER B9		Independent telematic unit				Erase Fault Code		Y		
PARTNER B9		Independent telematic unit				Live Data		Y		
PARTNER B9		Independent telematic unit				Actuation Test		Y		
PARTNER B9		Rain sensor				Read ECU Information		Y		
PARTNER B9		Rain sensor				Read Fault Code		Y		
PARTNER B9		Rain sensor				Erase Fault Code		Y		
PARTNER Electric(B9e)		ABS or ESP ECU	81 ESP			Read ECU Information		Y		
PARTNER Electric(B9e)		ABS or ESP ECU	81 ESP			Read Fault Code		Y		
PARTNER Electric(B9e)		ABS or ESP ECU	81 ESP			Erase Fault Code		Y		

PARTNER Electric(B9e)		ABS or ESP ECU	81 ESP			Live Data		Y		
PARTNER Electric(B9e)		Air bag				Read ECU Information		Y		
PARTNER Electric(B9e)		Air bag				Read Fault Code		Y		
PARTNER Electric(B9e)		Air bag				Erase Fault Code		Y		
PARTNER Electric(B9e)		Air bag				Live Data		Y		
PARTNER Electric(B9e)		Power steering electric pump unit				Read ECU Information		Y		
PARTNER Electric(B9e)		Power steering electric pump unit				Read Fault Code		Y		
PARTNER Electric(B9e)		Power steering electric pump unit				Erase Fault Code		Y		
PARTNER Electric(B9e)		Power steering electric pump unit				Live Data		Y		
PARTNER Electric(B9e)		Instrument panel				Read ECU Information		Y		
PARTNER Electric(B9e)		Instrument panel				Read Fault Code		Y		
PARTNER Electric(B9e)		Instrument panel				Erase Fault Code		Y		
PARTNER Electric(B9e)		Instrument panel				Live Data		Y		
PARTNER Electric(B9e)		Alarm				Read ECU Information		Y		
PARTNER Electric(B9e)		Alarm				Read Fault Code		Y		
PARTNER Electric(B9e)		Alarm				Erase Fault Code		Y		
PARTNER Electric(B9e)		Alarm				Live Data		Y		
PARTNER Electric(B9e)		Radio	RD4			Read ECU Information		Y		
PARTNER Electric(B9e)		Radio	RD4			Read Fault Code		Y		
PARTNER Electric(B9e)		Radio	RD4			Erase Fault Code		Y		
PARTNER Electric(B9e)		Radio	RD4			Live Data		Y		
PARTNER Electric(B9e)		Radio	RD45			Read ECU Information		Y		
PARTNER Electric(B9e)		Radio	RD45			Read Fault Code		Y		
PARTNER Electric(B9e)		Radio	RD45			Erase Fault Code		Y		
PARTNER Electric(B9e)		Radio	RD45			Live Data		Y		
PARTNER Electric(B9e)		Parking aid				Read ECU Information		Y		
PARTNER Electric(B9e)		Parking aid				Read Fault Code		Y		
PARTNER Electric(B9e)		Parking aid				Erase Fault Code		Y		
PARTNER Electric(B9e)		Parking aid				Live Data		Y		
PARTNER Electric(B9e)		Air conditioning ECU				Read ECU Information		Y		
PARTNER Electric(B9e)		Air conditioning ECU				Read Fault Code		Y		
PARTNER Electric(B9e)		Air conditioning ECU				Erase Fault Code		Y		
PARTNER Electric(B9e)		Air conditioning ECU				Live Data		Y		

PARTNER Electric(B9e)		Passenger compartment air heating resistor				Read ECU Information		Y		
PARTNER Electric(B9e)		Passenger compartment air heating resistor				Live Data		Y		
PARTNER Electric(B9e)		air conditioning compressor				Read ECU Information		Y		
PARTNER Electric(B9e)		air conditioning compressor				Live Data		Y		
PARTNER Electric(B9e)		Electric vehicle management ECU				Read ECU Information		Y		
PARTNER Electric(B9e)		Electric vehicle management ECU				Read Fault Code		Y		
PARTNER Electric(B9e)		Electric vehicle management ECU				Erase Fault Code		Y		
PARTNER Electric(B9e)		Service module				Read ECU Information		Y		
PARTNER Electric(B9e)		Service module				Read Fault Code		Y		
PARTNER Electric(B9e)		Service module				Erase Fault Code		Y		
PARTNER Electric(B9e)		Service module				Live Data		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'A' (segments)AVEC buttons			Read ECU Information		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'A' (segments)AVEC buttons			Read Fault Code		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'A' (segments)AVEC buttons			Erase Fault Code		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'A' (segments)AVEC buttons			Live Data		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'A' (segments)SANS buttons			Read ECU Information		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'A' (segments)SANS buttons			Read Fault Code		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'A' (segments)SANS buttons			Erase Fault Code		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'A' (segments)SANS buttons			Live Data		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'C' (dot matrix)			Read ECU Information		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'C' (dot matrix)			Read Fault Code		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'C' (dot matrix)			Erase Fault Code		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'C' (dot matrix)			Live Data		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'C colour' (dot matrix)			Read ECU Information		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'C colour' (dot matrix)			Read Fault Code		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'C colour' (dot matrix)			Erase Fault Code		Y		
PARTNER Electric(B9e)		Multifunction display	Type 'C colour' (dot matrix)			Live Data		Y		
PARTNER Electric(B9e)		Drive train interface ECU				Read ECU Information		Y		
PARTNER Electric(B9e)		Rain sensor				Read ECU Information		Y		
PARTNER Electric(B9e)		Rain sensor				Read Fault Code		Y		
PARTNER Electric(B9e)		Rain sensor				Erase Fault Code		Y		
PARTNER Electric(B9e)		Telematics	RADIONAV RNEG			Read ECU Information		Y		
PARTNER Electric(B9e)		Telematics	RADIONAV RNEG			Read Fault Code		Y		

PARTNER Electric(B9e)		Telematics	RADIONAV RNEG			Erase Fault Code		Y		
PARTNER Electric(B9e)		Telematics	RADIONAV RNEG			Live Data		Y		
PARTNER Electric(B9e)		Telematics	RNEG2010			Read ECU Information		Y		
PARTNER Electric(B9e)		Telematics	RNEG2010			Read Fault Code		Y		
PARTNER Electric(B9e)		Telematics	RNEG2010			Erase Fault Code		Y		
PARTNER Electric(B9e)		Telematics	RNEG2010			Live Data		Y		
PARTNER Electric(B9e)		Electric machine management ECU				Read ECU Information		Y		
PARTNER Electric(B9e)		Electric machine management ECU				Read Fault Code		Y		
PARTNER Electric(B9e)		Electric machine management ECU				Erase Fault Code		Y		
PARTNER Electric(B9e)		Electric machine management ECU				Live Data		Y		
PARTNER Electric(B9e)		Engine relay unit				Read ECU Information		Y		
PARTNER Electric(B9e)		Engine relay unit				Read Fault Code		Y		
PARTNER Electric(B9e)		Engine relay unit				Erase Fault Code		Y		
PARTNER Electric(B9e)		Switch module under the steering wheel(Top of				Read ECU Information		Y		
PARTNER Electric(B9e)		Switch module under the steering wheel(Top of				Read Fault Code		Y		
PARTNER Electric(B9e)		Switch module under the steering wheel(Top of				Erase Fault Code		Y		
PARTNER Electric(B9e)		Switch module under the steering wheel(Top of				Live Data		Y		
RCZ		BSI(Built-in Systems				Read ECU Information		Y		
RCZ		BSI(Built-in Systems				Read Fault Code		Y		
RCZ		BSI(Built-in Systems				Erase Fault Code		Y		
RCZ		BSI(Built-in Systems				Live Data		Y		
RCZ		BSI(Built-in Systems				Actuation Test		Y		
RCZ		BSI(Built-in Systems				Special Function	Changing the modeElectrical	Y		
RCZ		BSI(Built-in Systems				Special Function	Learning	Y		
RCZ		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Live Data		Y		
RCZ		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Actuation Test		Y		
RCZ		Engine management ECU	petrol	MM6LPB	MM6LPB RFJ	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6B	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6B	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6B	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6B	Live Data		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6B	Actuation Test		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6B	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6A	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6A	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6A	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6A	Live Data		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6A	Actuation Test		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 N6A	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	ME745	ME745 NFU	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 NFU	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 NFU	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 NFU	Live Data		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 NFU	Actuation Test		Y		
RCZ		Engine management ECU	petrol	ME745	ME745 NFU	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6A	Read ECU Information		Y		

RCZ		Engine management ECU	petrol	ME749	ME749 N6A	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6A	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6A	Live Data		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6A	Actuation Test		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6A	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	ME749	ME749 NFU	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 NFU	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 NFU	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 NFU	Live Data		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 NFU	Actuation Test		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 NFU	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6B	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6B	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6B	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6B	Live Data		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6B	Actuation Test		Y		
RCZ		Engine management ECU	petrol	ME749	ME749 N6B	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	MM6KP		Read ECU Information		Y		
RCZ		Engine management ECU	petrol	MM6KP		Read Fault Code		Y		
RCZ		Engine management ECU	petrol	MM6KP		Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	MM6KP		Live Data		Y		
RCZ		Engine management ECU	petrol	MM6KP		Actuation Test		Y		
RCZ		Engine management ECU	petrol	MM6KP		Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Live Data		Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Actuation Test		Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Special Function	Configuration	Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Live Data		Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Actuation Test		Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Special Function	Configuration	Y		
RCZ		Engine management ECU	petrol	MED17 4 EURO5	MED17_4_EURO5 5FN	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Live Data		Y		
RCZ		Engine management ECU	petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Actuation Test		Y		
RCZ		Engine management ECU	petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6C	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6C	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6C	Erase Fault Code		Y		

RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6C	Live Data		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6C	Actuation Test		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6C	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6CM	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6CM	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6CM	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6CM	Live Data		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6CM	Actuation Test		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP6CM	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP3C	Read ECU Information		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP3C	Read Fault Code		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP3C	Erase Fault Code		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP3C	Live Data		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP3C	Actuation Test		Y		
RCZ		Engine management ECU	petrol	MEV17.4.2	MEV17 4 2 EP3C	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Live Data		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Live Data		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Live Data		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Live Data		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Live Data		Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Live Data		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Read ECU Information		Y		

RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Live Data		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP 90CV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_ 110CV	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_ 110CV	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_ 110CV	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_ 110CV	Live Data		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_ 110CV	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_ 110CV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_ 110CV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110 CV	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110 CV	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110 CV	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110 CV	Live Data		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110 CV	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110 CV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110 CV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Live Data		Y		
RCZ		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	HDI SID807	HDI SID807 9HL	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Live Data		Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Live Data		Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Special Function	Configuration	Y		

RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HD	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Live Data		Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	HDI SID807 BR2	HDI_SID807_BR2 9HG	Special Function	Pack Repair	Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read ECU Information		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read Fault Code		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Erase Fault Code		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Live Data		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Actuation Test		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Configuration	Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Pack Repair	Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read ECU Information		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Read Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Erase Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Live Data		Y		

RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Actuation Test		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6 AT6 EURO5			Special Function	Pack Repair	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AT8			Read ECU Information		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AT8			Read Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AT8			Erase Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AT8			Live Data		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AT8			Actuation Test		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AT8			Special Function	Configuration	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AT8			Special Function	Pack Repair	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6			Read ECU Information		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6			Read Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6			Erase Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6			Live Data		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6			Actuation Test		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA AM6			Special Function	Pack Repair	Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
RCZ		Air bags and pre-tensioners control unit	SAC AUTOLIV			Read ECU Information		Y		
RCZ		Air bags and pre-tensioners control unit	SAC AUTOLIV			Read Fault Code		Y		
RCZ		Air bags and pre-tensioners control unit	SAC AUTOLIV			Erase Fault Code		Y		
RCZ		Air bags and pre-tensioners control unit	SAC AUTOLIV			Live Data		Y		
RCZ		Air bags and pre-tensioners control unit	SAC AUTOLIV			Special Function	Pack Repair	Y		
RCZ		Hands-free Kit / Portable	KML			Read ECU Information		Y		
RCZ		Hands-free Kit / Portable	KML			Read Fault Code		Y		
RCZ		Hands-free Kit / Portable	KML			Erase Fault Code		Y		
RCZ		Hands-free Kit / Portable	KML			Live Data		Y		
RCZ		Hands-free Kit / Portable	KML			Actuation Test		Y		
RCZ		Hands-free Kit / Portable	BOITIER NOMADE			Read ECU Information		Y		
RCZ		Hands-free Kit / Portable	BOITIER NOMADE			Read Fault Code		Y		
RCZ		Hands-free Kit / Portable	BOITIER NOMADE			Erase Fault Code		Y		
RCZ		Hands-free Kit / Portable	BOITIER NOMADE			Live Data		Y		
RCZ		Hands-free Kit / Portable	BOITIER NOMADE			Actuation Test		Y		
RCZ		Power steering				Read ECU Information		Y		
RCZ		Power steering				Read Fault Code		Y		
RCZ		Power steering				Erase Fault Code		Y		
RCZ		Power steering				Live Data		Y		

RCZ		Power steering				Actuation Test		Y		
RCZ		Under inflation detection	DSG UDS			Read ECU Information		Y		
RCZ		Under inflation detection	DSG UDS			Read Fault Code		Y		
RCZ		Under inflation detection	DSG UDS			Erase Fault Code		Y		
RCZ		Under inflation detection	DSG UDS			Live Data		Y		
RCZ		Under inflation detection	DSG			Read ECU Information		Y		
RCZ		Under inflation detection	DSG			Read Fault Code		Y		
RCZ		Under inflation detection	DSG			Erase Fault Code		Y		
RCZ		Under inflation detection	DSG			Live Data		Y		
RCZ		Dynamic headlamp height adjuster				Read ECU Information		Y		
RCZ		Dynamic headlamp height adjuster				Read Fault Code		Y		
RCZ		Dynamic headlamp height adjuster				Erase Fault Code		Y		
RCZ		Dynamic headlamp height adjuster				Live Data		Y		
RCZ		Dynamic headlamp height adjuster				Actuation Test		Y		
RCZ		Battery charge status unit	BECB			Read ECU Information		Y		
RCZ		Battery charge status unit	BECB			Live Data		Y		
RCZ		Battery charge status unit	BECB GEN2			Read ECU Information		Y		
RCZ		Battery charge status unit	BECB GEN2			Live Data		Y		
RCZ		Lane departure warning				Read ECU Information		Y		
RCZ		Lane departure warning				Read Fault Code		Y		
RCZ		Lane departure warning				Erase Fault Code		Y		
RCZ		Lane departure warning				Live Data		Y		
RCZ		Lane departure warning				Actuation Test		Y		
RCZ		Engine relay unit				Read ECU Information		Y		
RCZ		Engine relay unit				Read Fault Code		Y		
RCZ		Engine relay unit				Erase Fault Code		Y		
RCZ		Engine relay unit				Actuation Test		Y		
RCZ		Trailer relay unit				Read ECU Information		Y		
RCZ		Trailer relay unit				Read Fault Code		Y		
RCZ		Trailer relay unit				Erase Fault Code		Y		
RCZ		Multifunction screen	Type 'A' (segments)With buttons			Read ECU Information		Y		
RCZ		Multifunction screen	Type 'A' (segments)With buttons			Read Fault Code		Y		
RCZ		Multifunction screen	Type 'A' (segments)With buttons			Erase Fault Code		Y		
RCZ		Multifunction screen	Type 'A' (segments)With buttons			Live Data		Y		
RCZ		Multifunction screen	Type 'A' (segments)With buttons			Actuation Test		Y		
RCZ		Multifunction screen	Type 'A' (segments)Without button			Read ECU Information		Y		
RCZ		Multifunction screen	Type 'A' (segments)Without button			Read Fault Code		Y		
RCZ		Multifunction screen	Type 'A' (segments)Without button			Erase Fault Code		Y		
RCZ		Multifunction screen	Type 'A' (segments)Without button			Live Data		Y		
RCZ		Multifunction screen	Type 'A' (segments)Without button			Actuation Test		Y		
RCZ		Multifunction screen	Type 'C' (dot matrix)			Read ECU Information		Y		
RCZ		Multifunction screen	Type 'C' (dot matrix)			Read Fault Code		Y		
RCZ		Multifunction screen	Type 'C' (dot matrix)			Erase Fault Code		Y		
RCZ		Multifunction screen	Type 'C' (dot matrix)			Live Data		Y		
RCZ		Multifunction screen	Type 'C' (dot matrix)			Actuation Test		Y		
RCZ		Multifunction screen	Type 'C colour' (dot			Read ECU Information		Y		
RCZ		Multifunction screen	Type 'C colour' (dot			Read Fault Code		Y		
RCZ		Multifunction screen	Type 'C colour' (dot			Erase Fault Code		Y		
RCZ		Multifunction screen	Type 'C colour' (dot			Live Data		Y		
RCZ		Multifunction screen	Type 'C colour' (dot			Actuation Test		Y		
RCZ		Windscreen wiper				Read ECU Information		Y		

RCZ		Windscreen wiper				Actuation Test		Y		
RCZ		Parking assistance	Parking aid			Read ECU Information		Y		
RCZ		Parking assistance	Parking aid			Read Fault Code		Y		
RCZ		Parking assistance	Parking aid			Erase Fault Code		Y		
RCZ		Parking assistance	Parking aid			Live Data		Y		
RCZ		Air conditioning				Read ECU Information		Y		
RCZ		Air conditioning				Read Fault Code		Y		
RCZ		Air conditioning				Erase Fault Code		Y		
RCZ		Air conditioning				Live Data		Y		
RCZ		Air conditioning				Actuation Test		Y		
RCZ		Controls under the steering wheel				Read ECU Information		Y		
RCZ		Controls under the steering wheel				Read Fault Code		Y		
RCZ		Controls under the steering wheel				Erase Fault Code		Y		
RCZ		Controls under the steering wheel				Live Data		Y		
RCZ		Controls under the steering wheel				Actuation Test		Y		
RCZ		Instrument panel				Read ECU Information		Y		
RCZ		Instrument panel				Read Fault Code		Y		
RCZ		Instrument panel				Erase Fault Code		Y		
RCZ		Instrument panel				Live Data		Y		
RCZ		Instrument panel				Actuation Test		Y		
RCZ		CD changer / external CD				Read ECU Information		Y		
RCZ		CD changer / external CD				Read Fault Code		Y		
RCZ		CD changer / external CD				Erase Fault Code		Y		
RCZ		CD changer / external CD				Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV NG4			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Erase Fault Code		Y		

RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV RNEG CEO			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
RCZ		Radio amplifier				Read ECU Information		Y		
RCZ		Radio amplifier				Read Fault Code		Y		
RCZ		Radio amplifier				Erase Fault Code		Y		
RCZ		Radio amplifier				Actuation Test		Y		
RCZ		Radio	RD4			Read ECU Information		Y		
RCZ		Radio	RD4			Read Fault Code		Y		
RCZ		Radio	RD4			Erase Fault Code		Y		
RCZ		Radio	RD4			Live Data		Y		
RCZ		Radio	RD4			Actuation Test		Y		
RCZ		Radio	RD45			Read ECU Information		Y		
RCZ		Radio	RD45			Read Fault Code		Y		
RCZ		Radio	RD45			Erase Fault Code		Y		
RCZ		Radio	RD45			Live Data		Y		
RCZ		Radio	RD45			Actuation Test		Y		
RCZ		Seat driver position memory module.				Read ECU Information		Y		
RCZ		Seat driver position memory module.				Read Fault Code		Y		
RCZ		Seat driver position memory module.				Erase Fault Code		Y		
RCZ		Seat driver position memory module.				Live Data		Y		
RCZ		Seat driver position memory module.				Actuation Test		Y		
RCZ		Anti-theft alarm	Alarm with anti-lift			Read ECU Information		Y		
RCZ		Anti-theft alarm	Alarm with anti-lift			Read Fault Code		Y		
RCZ		Anti-theft alarm	Alarm with anti-lift			Erase Fault Code		Y		
RCZ		Anti-theft alarm	Alarm with anti-lift			Live Data		Y		
RCZ		Anti-theft alarm	Alarm with anti-lift			Actuation Test		Y		
RCZ		Seat passenger position memory module.				Read ECU Information		Y		
RCZ		Seat passenger position memory module.				Read Fault Code		Y		
RCZ		Seat passenger position memory module.				Erase Fault Code		Y		
RCZ		Seat passenger position memory module.				Live Data		Y		
RCZ		Seat passenger position memory module.				Actuation Test		Y		
RCZ		Driver's door module	Driver's door module			Read ECU Information		Y		
RCZ		Driver's door module	Driver's door module			Read Fault Code		Y		
RCZ		Driver's door module	Driver's door module			Erase Fault Code		Y		

RCZ		Driver's door module	Driver's door module			Live Data		Y		
RCZ		Driver's door module	Driver's door module			Actuation Test		Y		
RCZ		Sun roof				Read ECU Information		Y		
RCZ		Sun roof				Read Fault Code		Y		
RCZ		Sun roof				Erase Fault Code		Y		
RCZ		Sun roof				Live Data		Y		
RCZ		Sun roof				Actuation Test		Y		
RCZ		Moving panel deflector				Read ECU Information		Y		
RCZ		Moving panel deflector				Read Fault Code		Y		
RCZ		Moving panel deflector				Erase Fault Code		Y		
RCZ		Moving panel deflector				Live Data		Y		
RCZ		Moving panel deflector				Actuation Test		Y		
RCZ		Folding roof				Read ECU Information		Y		
RCZ		Folding roof				Read Fault Code		Y		
RCZ		Folding roof				Erase Fault Code		Y		
RCZ		Folding roof				Live Data		Y		
RCZ		Folding roof				Actuation Test		Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Read ECU Information		Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Read Fault Code		Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Erase Fault Code		Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Live Data		Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Actuation Test		Y		
RCZ		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
RCZ		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
RCZ		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
RCZ		Service module / Independent telematic unit	BTA			Live Data		Y		
RCZ		Service module / Independent telematic unit	BTA			Actuation Test		Y		
RCZ		Rain and light sensor				Read ECU Information		Y		
RCZ		Rain and light sensor				Read Fault Code		Y		
RCZ		Rain and light sensor				Erase Fault Code		Y		
RCZ		Pedestrian impact detection unit				Read ECU Information		Y		
RCZ		Pedestrian impact detection unit				Read Fault Code		Y		
RCZ		Pedestrian impact detection unit				Erase Fault Code		Y		
RCZ		Pedestrian impact detection unit				Live Data		Y		
RCZ		Seat belt not fastened warning lights unit				Read ECU Information		Y		
RCZ		Seat belt not fastened warning lights unit				Actuation Test		Y		
RCZ		Control panel dot matrix display				Read ECU Information		Y		
RCZ		Control panel dot matrix display				Read Fault Code		Y		
RCZ		Control panel dot matrix display				Erase Fault Code		Y		
RCZ		Control panel dot matrix display				Live Data		Y		
RCZ		Control panel dot matrix display				Actuation Test		Y		
RCZ		Diesel additive pump	POMPE_MUX_MGI			Read ECU Information		Y		
RCZ		Diesel additive pump	POMPE_MUX_MGI			Read Fault Code		Y		
RCZ		Diesel additive pump	POMPE_MUX_MGI			Erase Fault Code		Y		
RCZ		Diesel additive pump	POMPE_MUX_MGI			Live Data		Y		

RCZ		Diesel additive pump	POMPE_MUX_MGI			Actuation Test		Y		
RCZ		Diesel additive pump	POMPE_MUX_TI			Read ECU Information		Y		
RCZ		Diesel additive pump	POMPE_MUX_TI			Read Fault Code		Y		
RCZ		Diesel additive pump	POMPE_MUX_TI			Erase Fault Code		Y		
RCZ		Diesel additive pump	POMPE_MUX_TI			Live Data		Y		
RCZ		Diesel additive pump	POMPE_MUX_TI			Actuation Test		Y		
RCZ		High frequency receiver				Read ECU Information		Y		
RCZ		High frequency receiver				Read Fault Code		Y		
RCZ		High frequency receiver				Erase Fault Code		Y		
RCZ		High frequency receiver				Live Data		Y		